



Quick Start Guide

1. How to power on the device



2. How to charge the device




3. How to charge your pen

← BACK



Recharge your pen, recharge your mind

Rest your pen on the left side to charge it.



ENGLISH

Please read the following information carefully to prevent incidents and avoid damaging your device. Any configuration or use other than what is in line with the suggested and intended use is not covered or guaranteed.

PRECAUTIONS

MAINTENANCE

Handle the **Montblanc Digital Paper**, the Digital Pen and its accessories with care.

DEVICE PROTECTION. We advise you to keep your device and pen in a protective cover like the Montblanc folio, especially during transportation. When dropped, cracked, burnt or bent the device could be damaged due to sensitive electronic components contained within. Only use the USB-C charging cable and accessories enclosed with the device or recommended by Montblanc.

To protect the screen of your **Montblanc Digital Paper**, ensure you are keeping the tip of the Montblanc Digital Pen clean. Dirt and other small particles can excessively wear down the tip and cause damage to the screen of your device. Please replace the nibs of your pen frequently to avoid scratching the surface of the device.

CLEANING INSTRUCTIONS. Prior to cleaning your **Montblanc Digital Paper** device and its accessories, ensure you unplug all cables and turn the device off (hold the power button for 4 seconds and tap

'Power off'). Use a slightly damp, soft and lint-free cloth. Refrain from using window cleaners, solvents, aerosol sprays, household cleaners, alcohol, ammonia, or abrasives as they could permanently damage your device. When cleaning, avoid getting moisture into any of the openings.

LEATHER. Leather is a natural material that is sensitive to the effects of light, humidity and water. To keep the leather on your product in perfect condition and prevent the color from fading, protect it from prolonged exposure to high temperatures and direct sunlight. In the event of contact with water, it should be dried promptly with a soft, smooth cloth. To maintain its natural softness, Montblanc recommends treating your leather product with a neutral leather care product.

HANDLING

Do not drop, bend, or puncture your device and digital pen; do not insert foreign objects into or place heavy objects on your device and digital pen; do not subject your **device and digital pen** to shock or vibration. Sensitive components inside might become damaged.

DIGITAL PEN. Your Montblanc Digital Pen is compatible with a variety of pen-enabled devices, syncing with Wacom Active ES Protocol (AES 2.1), Microsoft Pen Protocol (MPP 2.0), Universal Stylus Initiative Protocol (USI 2.0) and Wacom Generic Protocol (WGP). Please inform yourself about the compatibility with the device manufacturer.

Write with the **Montblanc Pen** as if you are writing with a pen on paper. Ensure you do not let your pen rest on the tip and do not apply excessive pressure during writing to protect its sensitivity.



Ensure you always keep your Montblanc Digital Pen charged by attaching it to the **Montblanc Digital Paper device** when not in use. Ensure that the Montblanc Digital **Paper device** is charged frequently and is not running out of battery. A permanent discharge of the Montblanc Digital Pen or device may damage the battery.

CONTACT WITH LIQUIDS. Don't use the **Montblanc Digital Paper** device or its accessories in the rain or near other wet locations, as it contains electrical components that can be damaged if it comes in contact with liquid. If your device gets wet, unplug all cables and let the device dry completely before turning it on by pressing the power button. Do not attempt to dry your **Montblanc Digital Paper** device or **pen** with an external heat source, such as a microwave oven or hairdryer.

DAMAGE OR ALTERATIONS. Do not make any changes to the device, pen, USB-C cable or accessories yourself. Any change will result in the loss of the warranty and possibly create a danger for you and your environment. For service and maintenance, contact a Montblanc Boutique or an authorized Montblanc Retailer.

Refrain from using the **Montblanc Digital Paper** device, pen or charging cable if they are not working properly or have been damaged.

OPERATING TEMPERATURE. Do not subject the device and pen to high pressure or place it near or in a high temperature location or heat source (e.g., sun, fire, microwave, heating, stove, sauna or steam room). Turn off the device in potentially explosive environments.

The device and pen can be used in locations with an ambient temperature of **0 °C to 40 °C (32 °F to 104 °F)**. You can store the device and pen at an ambient temperature of **-10 °C to 55 °C (14 °F to 131 °F)** and **-20 °C to 50 °C (-4 °F to 122 °F) respectively**. Using or storing the **Montblanc Digital Paper** device outside the recommended temperature ranges may damage the device.

WARNINGS

HEALTH

PHYSICAL DISCOMFORT. Repetitive motions such as pressing keys or writing over a prolonged time may result in occasional discomfort in hands, arms, shoulders, neck, or other parts of your body. In case of headaches, blackouts, seizures, convulsion, eye or muscle twitching, loss of awareness, involuntary movement, disorientation, or other discomfort, discontinue using your device or the pen and consult a physician. Ensure you avoid prolonged use, maintain some distance between the device and your eyes, use your device in a well-lit room and take frequent breaks to reduce any associated risks. Find a comfortable position for the pen in your hand, ensure you are switching positions frequently and take sufficient breaks.

PROLONGED HEAT EXPOSURE. Montblanc Digital Paper and pen are compliant with applicable regulations and safety standards on surface temperatures. Nonetheless, contact with the device when connected to a power source can cause discomfort or injury. Avoid prolonged skin contact and refrain from sitting or sleeping on the device and charging cable.

INTERFERENCE WITH OTHER ELECTRONIC EQUIPMENT. Although the device is designed, tested, and manufactured to comply with regulations governing radio frequency emissions in the U.S., the wireless transmitters and electrical circuits in the Montblanc Digital Paper Device and Montblanc Digital Pen may cause interference in other electronic equipment.

Please follow the advice below to limit the risks of radio-frequency interference:

- Consult a doctor prior to use if you have a pacemaker or other internal electronic device and, more generally, if you have a heart or other medical condition.
- Keep the device and charger at least 6 inches (15 cm) away from any implantable medical device (e.g., pacemaker, defibrillator, or other medical device).
- If there is any reason to suspect interference, turn off the device immediately.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

MAGNETS. Objects with magnetically stored data may be sensitive to magnetic or electromagnetic fields. Thus, you should refrain from placing items such as credit cards and hard drives near the device.

SAFETY

CHOKING HAZARD. Keep the device and its accessories away from children and pets. Plastic bags can be dangerous. Keep plastic bags away from babies and children to avoid danger of suffocation.

HIGH-CONSEQUENCE ACTIVITIES. The device is not intended for use in activities or situations where the failure of the device could lead to serious injuries or death. Exercise caution when using the device while walking or moving. Pay attention to your surroundings to avoid injury to yourself or others.

DISTRACTION. It is not recommended, and may in some areas even be prohibited or restricted, to use your device while operating a vehicle. If operation in vehicles is permitted, ensure you always give full attention to the operation of the vehicle. Generally, stop using your device if it becomes a distraction.

Follow the guidelines for communication devices provided by officials when travelling in airplanes or in locations where their usage is banned. Observe local guidelines and laws for mobile and communication devices (e.g. while driving).

CHARGING

Do not touch your device with wet hands while charging. Doing so may cause electric shock. While charging, keep the device away from highly humid environments, high pressure or water. Once the device is fully charged, do not leave it plugged in if it is not in use.

Your device may become warm while charging. If you notice your device becoming uncomfortably hot while or after charging, remove the device from the USB-C cable and wait until it cools down before use or continued charging.

HANDLING OF ACCESSORIES. Handle the USB-C cable with care. Do not place objects on the USB-C cable, bend it sharply, or apply heavy stress. Keep the cable away from liquids. Do not use the cable if it is damaged. Damage to the USB-C cable may result in malfunction, electric shock or fire.

Prevent the USB-C cable from contact with conductive materials, such as liquids, dust, metal powders, and pencil leads.

QUALIFIED ACCESSORIES. Only use Montblanc approved accessories (e.g., charging cable). Make sure to plug the charging cable into an outlet with a controlled output voltage of **DC 5 Volt and a maximum output current of 2 Ampere**.

Do not force a charging cable into a port, because this may cause damage to the device.

BATTERY

BATTERY DAMAGE. If you notice an unusual smell coming from your **Montblanc Digital Paper** device, Montblanc Digital Pen or the battery, or if you see smoke or liquids leaking from the device or battery, stop using the device immediately and take it to a Montblanc boutique or authorized Montblanc dealer.

Never use a device, pen or charging cable that is damaged in any way.

Do not handle a damaged or leaking Lithium Ion (Li-Ion) battery. For safe disposal of your Li-Ion battery, contact your Montblanc boutique or authorized Montblanc dealer.

LOW AIR PRESSURE WARNING. If the device or the pen with the battery is subjected to extremely low air pressure, it may result in an explosion or the leakage of flammable liquid or gas.



DISPOSAL

If you wish to discard this product, please contact your local authorities or dealer and ask for the correct method of disposal. Penalties may be applicable for incorrect disposal of this waste, in accordance with your national legislation.

GUARANTEE

The following Montblanc International Guarantee applies to Montblanc Products sold or presented for guaranteed service in any country (including the United States of America, Canada and Australia).

What the Montblanc International Guarantee Covers and For How Long

Your Montblanc Product has been manufactured according to the high-quality standards of Montblanc with all the care and patience dedicated to them by our devoted craftsmen. Nevertheless, the Montblanc Product is covered by this Montblanc International Guarantee against defects in manufacturing and materials. Please contact one of the authorised Montblanc boutiques, Montblanc dealers or Montblanc service centres located around the world, and they will be able to provide guarantee service as defined herein (for a complete list of authorized Montblanc boutiques, Montblanc dealers and Montblanc service centres, please consult the Montblanc website (www.montblanc.com)).

Montblanc warrants its product against defects in materials and manufacturing for a period of two (2) years from the date of purchase (the Guarantee period). If the product is returned during the Guarantee period, Montblanc will repair or replace any defective Montblanc Product or part free of charge within a reasonable time after the product is returned, subject to the right to charge for shipping. Upon expiration of the Guarantee period, any repairs will be subject to a service charge.

How to Obtain Service

You may obtain service by bringing or sending the Montblanc Product to your authorised Montblanc boutique, Montblanc dealer or to any Montblanc service centre as further indicated in this service guide. You are responsible for transportation costs, including but not limited to postage, insurance and packing materials. We recommend that any shipments to us include certified delivery and insurance.

In order to obtain service through this Montblanc International Guarantee, the returned Montblanc Product must be accompanied by the original Guarantee Certificate that was included with the Montblanc Product at the time of purchase, duly completed, dated, stamped and signed by an authorised Montblanc boutique or Montblanc dealer. Such Guarantee Certificate may only be completed by an authorised Montblanc boutique or Montblanc dealer.

What is not Covered under the Montblanc International Guarantee

The Montblanc International Guarantee does not cover:

- (a) defects and damages due to loss, theft, fire or other causes beyond our control.
- (b) defects and damages resulting from misuse, negligence or accident.
- (c) defects and damages caused by improper use (knocks, dents, crushing, etc.), alterations, tampering, dismantling or services and repairs completed by anyone other than an authorised Montblanc boutique, Montblanc dealer or Montblanc service centre, or by the use of components or accessories (such as bottled ink or cartridges) other than those produced or recommended by Montblanc.
- (d) defects and damages due to normal wear and tear.
- (e) Montblanc Products where the serial number has been removed or is not clearly legible, or where any part of the original Montblanc Product has been removed, changed, altered, replaced, erased or defaced.
- (f) routine maintenance and cleaning.

(g) battery cells, chargers, accessories, leather and metal.

Montblanc Service Contracts

Only authorised Montblanc boutiques, Montblanc dealers and Montblanc service centres are entitled to provide guarantee service as defined herein. For more information and a complete list of authorised Montblanc boutiques, Montblanc dealers and Montblanc service centres, please consult the Montblanc website www.montblanc.com or ask the authorized Montblanc boutique or Montblanc dealer indicated on your Guarantee Certificate or in your sales documentation.

Additional guarantee conditions applicable in the United States of America and Canada only:

Montblanc Limited Warranty

EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, THE MONTBLANC INTERNATIONAL GUARANTEE SET FORTH ABOVE IS A LIMITED WARRANTY AND SHALL BE THE EXCLUSIVE MANUFACTURER'S WARRANTY IN LIEU OF ANY OTHER EXPRESS WARRANTIES. NEITHER THIS LIMITED WARRANTY NOR ANY OTHER WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, SHALL EXTEND BEYOND THE PERIOD OF TWO (2) YEARS FROM THE DATE OF PURCHASE. FOR A PERIOD OF TWO (2) YEARS FROM THE DATE OF PURCHASE MONTBLANC WILL, AT ITS SOLE DISCRETION, REPAIR OR REPLACE ANY DEFECTIVE MONTBLANC PRODUCT OR PART UNDER THE LIMITED WARRANTY FREE OF CHARGE SUBJECT TO THE RIGHT TO CHARGE FOR SHIPPING COSTS, AND SUBJECT TO THE FOLLOWING CONDITIONS: THE RETURNED MONTBLANC PRODUCT MUST BE ACCOMPANIED BY THE GUARANTEE CERTIFICATE (INCLUDED WITH THE MONTBLANC PRODUCT), DULY COMPLETED, DATED, STAMPED AND SIGNED BY AN AUTHORISED MONTBLANC BOUTIQUE OR DEALER. SUCH GUARANTEE CERTIFICATE MAY ONLY BE COMPLETED BY AN AUTHORISED MONTBLANC BOUTIQUE OR MONTBLANC DEALER. THE SERIAL NUMBER ORIGINALLY IMPRINTED ON THE MONTBLANC PRODUCT IS CLEARLY LEGIBLE AND NO PART OF THE ORIGINAL MONTBLANC PRODUCT OR ORIGINAL SERIAL NUMBER HAS BEEN REMOVED, CHANGED, ALTERED, REPLACED, ERASED OR DEFACED. IN ADDITION TO THE FOREGOING, ALL OTHER CONDITIONS SET FORTH IN THE MONTBLANC INTERNATIONAL GUARANTEE ARE APPLICABLE TO THE MONTBLANC LIMITED WARRANTY IN THE UNITED STATES OF AMERICA AND CANADA. FAILURE OF ANY OF THESE CONDITIONS VOIDS ALL WARRANTY RIGHTS. THIS WARRANTY IS THE SOLE AND EXCLUSIVE REMEDY. MONTBLANC SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Montblanc does not authorise any distributor or dealer of its products to make any warranties beyond this Limited Warranty or to otherwise assume for Montblanc any obligations or liability in connection with the sale or distribution of its products. Some states, provinces or territories do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.

A warranty claim may be sent to Montblanc North America LLC or Richemont Canada Ltd. at the following addresses, or for a complete list of authorised Montblanc boutiques, Montblanc dealers and Montblanc service centres, please consult the Montblanc website www.montblanc.com, in each case using the procedure outlined in 'How to Obtain Service':

Montblanc North America LLC

15100 Trinity Blvd, Suite 300 Fort Worth

TX 76155

United States

(Please send products via insured carrier only, no drop off available at this location)

Ph.: +1 800 995 4810

Email: service@montblanc.com

Montblanc Canada Ltd.

4610 Eastgate Parkway Unit 1

L4W 3 W6 Mississauga Ontario

Canada

Ph.: +1 905 602-1262

Fax: +1 905 602-6805

Specific guarantee applicable in Australia only:

Mandatory Statutory Rights

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. The Mandatory Statutory Rights apply only to Montblanc Products sold in Australia and presented for guarantee intervention in Australia. The Montblanc International Guarantee gives you further benefits, which are in addition to your rights under the Australian Consumer Law. If you seek to rely on your Mandatory Statutory Rights under the Australian Consumer Law in relation to a defect in goods supplied, you may be entitled to recover any reasonably foreseeable loss or damage that results from the defect. This may include the costs associated with transporting the Montblanc Product to an authorised Montblanc boutique, Montblanc dealer or Montblanc service centre.

In Australia, the Montblanc International Guarantee is provided by:

Montblanc service centre

Level 4, 450 St Kilda Road

Melbourne VIC 3004

Australia

Ph: +61 3 8866 9500

Email: service@montblanc.com

A claim under this Guarantee may be sent to the Montblanc service centre at the address above, or for a complete list of authorized Montblanc boutiques, Montblanc dealers and Montblanc service centres, please consult the Montblanc website www.montblanc.com, in each case using the procedure outlined in 'How to Obtain Service'.

How State and Other Laws Apply

The Montblanc International Guarantee gives you specific legal rights, and you may also have other rights which vary in the United States of America from State to State and may in addition vary from one country, province or territory to another.

E-Label Information

To view the E-label information of your device, you may go to the Settings > Legal & Regulatory > Regulatory certification

REGULATORY STATEMENT

FCC Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

If necessary, consult your Montblanc dealer or an experienced radio/television technician for help. Changes or modifications to this product not authorized by Montblanc could void the FCC Certification and negate your authority to operate the product.

FCC RF Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To satisfy RF exposure compliance, the End user must follow the specific operating instructions. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user's body or set the device to lower output power if such function is available.

IC Statement:

Industry Canada

Montblanc Digital Paper device complies with Industry Canada's licence-exempt RSSs Standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian CAN ICES-003(B)/NMB-003(B)

Radiation Exposure Statement:

This product complies with the Canada portable RF exposure limit set forth for an uncontrolled environment and is safe for intended operation as described in this guide. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user's body or set the device to a lower output power if such function is available.

The device with band 5150-5250 MHz is only intended for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

Informations d'étiquette électronique

Pour afficher les informations d'étiquette électronique de votre appareil, vous pouvez accéder au menu Paramètres > Juridique et réglementaire > **Sécurité et réglementation**

Déclarations de Conformité

IC: 20163-DWT01

HVIN: DWT-01

PMN: Montblanc Digital Paper

Industrie Canada

Le present appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage ;
2. L'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Déclaration d'exposition aux radiations

Le produit est conforme aux limites d'exposition, pour les appareils portables RF pour les Etats-Unis et le Canada établies pour un environnement non contrôlé. Le produit est sûr pour un fonctionnement tel que décrit dans ce manuel. La réduction aux expositions RF peut être augmentée

si l'appareil peut être conservé aussi loin que possible du corps de l'utilisateur ou que le dispositif est réglé sur la puissance de sortie la plus faible si une telle fonction est disponible.

Au Royaume-Uni et dans l'Union européenne, la limite du DAS est de 2,0 watts par kilogramme en moyenne selon une masse de 10 grammes de tissu pour une utilisation contre le corps. La valeur de DAS obtenue est de XX

Les dispositifs fonctionnant dans la bande de 5 150 à 5 250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

CAN ICES-003(B)/NMB-003(B)

Singapore Compliance Statement

This device is compliant with the IMDA standards. (DB106046)



EU Declaration of Conformity

Hereby, Montblanc-Simplo GmbH declares that the radio equipment type device and charging accessories complies with:

RE Directive 2014/53/EU

RoHS Directive (2011/65/EU)

Ecodesign Directive (2009/125/EC)

To view the full EU declaration of conformity, go to [WEBSITE](#)



Hereby, Montblanc-Simplo GmbH declares that the radio equipment device and charging accessories is in compliance with The Radio Equipment Regulations 2017.

The Montblanc device is imported in the UK by Richemont International Limited, 15 Hill Street, London, W1J 5QT, UK.

The full text of the UKCA declaration of conformity is available at the following internet address:
[WEBSITE](#)

Operation Frequency Device

When operating in the 5150 to 5350 MHz frequency range this device is restricted to indoor use, applicable in the following countries: Austria, Belgium, Bulgaria, Croatia, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Hungary, Iceland, Ireland, Italy, Latvia, Liechtenstein, Lithuania, Luxembourg, Malta, Netherlands, Northern Ireland, Norway, Poland, Portugal, Romania, Slovakia, Slovenia, Spain, Sweden, Switzerland, and Turkey. These restrictions are also applicable in the United Kingdom.

- 2402MHz~2480MHz (BT/BLE)
- 2412MHz~2472MHz (802.11/b/g/n HT20M)
- 13.56MHz (NFC)
- 5180MHz~5825MHz (802.11a/n/ac 20M/40M/80M)

Operation Frequency Montblanc Digital Pen

- 2402MHz~2480MHz (BT/BLE)
- 13.56MHz (NFC)

Output Power Device

Output Power BT: 20 dBm BLE: 20 dBm

WLAN 2400 MHz ~ 2483.5 MHz: 20 dBm

WLAN 5150 MHz ~ 5350 MHz: 23 dBm

WLAN 5470 MHz ~ 5725 MHz: 20 dBm

WLAN 5725 MHz ~ 5850 MHz: 14 dBm

NFC 13.56MHz: -17.58 dBuA/m@10m

Output Power Montblanc Digital Pen

Output Power BT: XX dBm BLE: XX dBm

NFC 13.56MHz: xx dBuA/m@10m

ENVIRONMENTAL COMPLIANCE

Reuse, recycling, and recovery.

You are urged to recycle this product when replacing it with a newer product or when it has outlived its useful life by bringing it to an appropriate collection point for recyclable materials in your community or region. By doing this, you can help improve the environment of your community as well as minimize the potential negative effects created should any hazardous substance that may possibly be present within waste material reach the environment during the disposal process.



Within the European Union, users are required not to dispose of Waste Electrical and Electronic Equipment (WEEE) as unsorted municipal waste, according to the WEEE Directive or the corresponding local laws of the Member States. Products for which this is applicable

will be marked with the WEEE symbol shown at the beginning of this note unless this is not feasible because of the size or the function of the product.

Montblanc products are subject to the Directive WEEE and therefore you should always collect them separately and bring them to the appropriate collection point in your community or region.

Caution: Do not handle damaged or leaking Li-Ion battery.

EU BATTERY DISPOSAL INFORMATION



Note: This symbol mark is for EU countries only. This symbol mark is according to the directive 2006/66/EC Article 20 Information for end-users and Annex II.

Your product is designed and manufactured with high quality materials and components which can be recycled and/or reused. This symbol means that batteries and accumulators, at their end-of-life, should be disposed of separately from your household waste. In the European Union there are separate collection systems for used Batteries and accumulators. Please, dispose of batteries and accumulators correctly at your local community waste collection/recycling center.

Disposal of the built-in lithium-ion battery

Please contact Montblanc Customer Care about the disposal of the built-in lithium-ion battery. Caution: Do not handle damaged or leaking lithium-ion batteries.



For customers in the USA and Canada recycling Lithium-ion Batteries

You can help preserve our environment by returning your used rechargeable batteries to the collection and recycling location nearest you. For more information regarding recycling of rechargeable batteries, call toll free 1-800-822-8837, or visit <http://www.rbrc.org/>. Caution: Do not handle damaged or leaking Li-Ion battery.

India E-Waste



Montblanc products are in conformity with the requirements of the reduction of hazardous substances of the E-waste (Management) Rules, 2022.

■ The content of hazardous substances with the exemption of the applications listed in SCHEDULE II of the E-waste Rules;

- Not over 0.1% by weight in homogenous materials for Lead, Mercury, Hexavalent Chromium, Polybrominated biphenyls, Polybrominated diphenyl ethers
- Not over 0.01% by weight in homogenous materials for Cadmium

For the proper recycling and disposal of this product after its end of life, please visit our website.

[WEBSITE](#)

REGULATORY COMPLIANCE MARK



The device has been tested and found to comply with RCM standards.