

SMART VIDEO DOORBELL

User Manual


Packing list

After opening it, please check whether the product is in good condition or not; confirm whether the accessories are complete as below.



Machine

Fittings:




Screws Package *2



Wooden Screw *4

Appearance introduction

Before use, please be familiar with the interface and button of the doorbell.



Notes: Long-press the RESET button for 5 seconds, loosen it when hear the voice prompt "restore factory settings, please don't power off". Then it can be restored to the factory default configuration.

Indicator Introduction

Blue light always on	Startup
Blue light flashes slowly	APP remote monitor and setup
Red light flashes slowly	Battery lower power


Operation manual

1.Device ready

First step: Install the backplane where you need to install the doorbell. (Expansion screws need to be used on cement and stone walls, wood screws or 3M glue can be used on wooden walls.)

Second step: Install the doorbell body into the backplane.

2.Download APP



iSee

Tips one: Scan QR code to download;

Tips two: Search and download "iSee" in the Appstore or Googleplay;


3.Device network configuration

01. User login

- Open "iSee", sign up a new account and log in(Figure1) ;
- If you have Wechat ,You can use" WeChat shortcut login" directly (Figure1) ;

02.Device preparation

After the doorbell is installed, short-press the bell button to wake the doorbell.(Figure 2)



(Figure 1)




(Figure 2)


Notes: There is voice instruction throughout the process of device configuration. After hearing the voice prompt "wait to be configured", you can start configuring the device.

03.Add device

- After login successfully, click "Add My Camera" (Figure 3), input "WiFi password" (Figure 4). Finish the network configuration of the camera according to the APP operation hint.



(Figure 3)



(Figure 4)

- Add My Camera (recommended): Connect the device to the router.
- Add My Camera (AP mode): Connect the device to the router via AP mode.
- Add Shared Camera: Add a device that others share to you.Add the camera via inputting the device serial number or sharing information code or scanning device QR code.

04.Access device


- Device or network failure;
- Offline
- Deep dormancy
- Dormancy

After login success, you can use the mobile phone access the device through the APP, The device has the following states:

05.Message push


When a visitor presses a button or an alarm is generated, the device sends a message to the phone. You can receive the message in the following two ways:

1.Receive the message via the APP



(Figure 1)

2.Receive the message via WeChat.




(Figure 2)

06.Bell Device Configuration

If you buy a Bell Device, you can associate the Bell Device with the Video Doorbell, and the bell device will also ring when you press the bell button.

First step: Long-press the volume button of the Bell Device until the indicator of the bell is no longer flashing.

2.Receive the message via WeChat.




(Figure 2)

06.Bell Device Configuration

If you buy a Bell Device, you can associate the Bell Device with the Video Doorbell, and the bell device will also ring when you press the bell button.

First step: Long-press the volume button of the Bell Device until the indicator of the bell is no longer flashing.

FAQ



(Figure 2)

06.Bell Device Configuration

If you buy a Bell Device, you can associate the Bell Device with the Video Doorbell, and the bell device will also ring when you press the bell button.

First step: Long-press the volume button of the Bell Device until the indicator of the bell is no longer flashing.

06.Bell Device Configuration

If you buy a Bell Device, you can associate the Bell Device with the Video Doorbell, and the bell device will also ring when you press the bell button.

First step: Long-press the volume button of the Bell Device until the indicator of the bell is no longer flashing.

Warranty Card

Product Name		Model	
Purchase Date		Purchase Store	
Cause			
Process			
Customer Name		Customer Gender	
Customer Phone		ZIP	
Address			

Warranty period:one year.
This warranty card is only for our company's products.