














NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +L-N/A-N/A-DFT-QPSK-Edge_1RB_Left-30-1000- PASS	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +L-N/A-N/A-DFT-QPSK-Edge_1RB_Left-1000-600 0-PASS
--	--








NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +L-N/A-N/A-DFT-QPSK-Edge_1RB_Left-6000-180 00-PASS	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +L-N/A-N/A-DFT-QPSK-Edge_1RB_Left-18000-40 000-PASS
---	--



NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +L-N/A-N/A-DFT-QPSK-Edge_1RB_Right-0.009-0 .15-PASS	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +L-N/A-N/A-DFT-QPSK-Edge_1RB_Right-0.15-30 -PASS
--	---



SS 	SS 
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +M-N/A-N/A-DFT-QPSK-Outer_Full-30-1000-PAS S	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +M-N/A-N/A-DFT-QPSK-Outer_Full-1000-6000-PA SS
	
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +M-N/A-N/A-DFT-QPSK-Outer_Full-6000-18000-P ASS	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +M-N/A-N/A-DFT-QPSK-Outer_Full-18000-40000-PASS PASS
	
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M

+M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-0.009-0.

15-PASS

+M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-0.15-30-PASS

PASS

NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M

+M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-30-1000

-PASS

NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M

+M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-1000-6000-PASS

00-PASS

NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M

+M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-6000-18000-PASS


000-PASS

NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M


+M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-18000-40000-PASS

0000-PASS


NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M
+M-N/A-N/A-DFT-QPSK-Edge_1RB_Right-0.009-
0.15-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M
+M-N/A-N/A-DFT-QPSK-Edge_1RB_Right-0.15-3
0-PASS



NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M
+M-N/A-N/A-DFT-QPSK-Edge_1RB_Right-30-100
0-PASS









NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M
+M-N/A-N/A-DFT-QPSK-Edge_1RB_Right-1000-6
000-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M
+M-N/A-N/A-DFT-QPSK-Edge_1RB_Right-6000-1
8000-PASS

NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M
+M-N/A-N/A-DFT-QPSK-Edge_1RB_Right-18000-
40000-PASS




ASS	PASS
	
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +H-N/A-N/A-DFT-QPSK-Edge_1RB_Left-0.009-0. 15-PASS	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +H-N/A-N/A-DFT-QPSK-Edge_1RB_Left-0.15-30- PASS
	
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +H-N/A-N/A-DFT-QPSK-Edge_1RB_Left-30-1000- PASS	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M +H-N/A-N/A-DFT-QPSK-Edge_1RB_Left-1000-60 00-PASS
	
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M
+H-N/A-N/A-DFT-QPSK-Edge_1RB_Right-6000-1
8000-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+50-M
+H-N/A-N/A-DFT-QPSK-Edge_1RB_Right-18000-
40000-PASS



NTNV-DC_66A_n78A-3700-3800-PC2-30-5+60-M
+L-N/A-N/A-DFT-QPSK-Outer_Full-0.009-0.15-PA
SS



NTNV-DC_66A_n78A-3700-3800-PC2-30-5+60-M
+L-N/A-N/A-DFT-QPSK-Outer_Full-0.15-30-PASS



NTNV-DC_66A_n78A-3700-3800-PC2-30-5+60-M
+L-N/A-N/A-DFT-QPSK-Outer_Full-30-1000-PASS

NTNV-DC_66A_n78A-3700-3800-PC2-30-5+60-M
+L-N/A-N/A-DFT-QPSK-Outer_Full-1000-6000-PA
SS

