








ASS	PASS
	
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-0.009-0. 15-PASS	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-0.15-30- PASS
	
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-30-1000 -PASS	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-1000-60 00-PASS
	
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M


+M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-6000-18
000-PASS




+M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-18000-4
0000-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M
+M-N/A-N/A-DFT-QPSK-Edge_1RB_Right-0.009-
0.15-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M
+M-N/A-N/A-DFT-QPSK-Edge_1RB_Right-0.15-3
0-PASS







NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M
+M-N/A-N/A-DFT-QPSK-Edge_1RB_Right-30-100
0-PASS








NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M
+M-N/A-N/A-DFT-QPSK-Edge_1RB_Right-1000-6
000-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +M-N/A-N/A-DFT-QPSK-Edge_1RB_Right-6000-1 8000-PASS	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +M-N/A-N/A-DFT-QPSK-Edge_1RB_Right-18000- 40000-PASS
	
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +H-N/A-N/A-DFT-QPSK-Outer_Full-0.009-0.15-PA SS	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +H-N/A-N/A-DFT-QPSK-Outer_Full-0.15-30-PASS
	
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +H-N/A-N/A-DFT-QPSK-Outer_Full-30-1000-PAS S	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +H-N/A-N/A-DFT-QPSK-Outer_Full-1000-6000-PA SS




PASS 	00-PASS 
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +H-N/A-N/A-DFT-QPSK-Edge_1RB_Left-6000-18 000-PASS	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +H-N/A-N/A-DFT-QPSK-Edge_1RB_Left-18000-4 0000-PASS
	
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +H-N/A-N/A-DFT-QPSK-Edge_1RB_Right-0.009-0 .15-PASS	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M +H-N/A-N/A-DFT-QPSK-Edge_1RB_Right-0.15-30 -PASS
	
NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M	NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M

+H-N/A-N/A-DFT-QPSK-Edge_1RB_Right-30-100
0-PASS




+H-N/A-N/A-DFT-QPSK-Edge_1RB_Right-1000-6
000-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M
+H-N/A-N/A-DFT-QPSK-Edge_1RB_Right-6000-1
8000-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+90-M
+H-N/A-N/A-DFT-QPSK-Edge_1RB_Right-18000-
40000-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+L-N/A-N/A-DFT-QPSK-Outer_Full-0.009-0.15-P
ASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+L-N/A-N/A-DFT-QPSK-Outer_Full-0.15-30-PAS
S



NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+L-N/A-N/A-DFT-QPSK-Outer_Full-30-1000-PA
SS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+L-N/A-N/A-DFT-QPSK-Outer_Full-1000-6000-P
ASS



NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+L-N/A-N/A-DFT-QPSK-Outer_Full-6000-18000-
PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+L-N/A-N/A-DFT-QPSK-Outer_Full-18000-4000
0-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+L-N/A-N/A-DFT-QPSK-Edge_1RB_Left-0.009-0
.15-PASS


NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+L-N/A-N/A-DFT-QPSK-Edge_1RB_Left-0.15-30
-PASS



-0.15-PASS





30-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-M+L-N/A-N/A-DFT-QPSK-Edge_1RB_Right-30-1000-PASS

NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-M+L-N/A-N/A-DFT-QPSK-Edge_1RB_Right-1000-6000-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-M+L-N/A-N/A-DFT-QPSK-Edge_1RB_Right-6000-18000-PASS

NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-M+L-N/A-N/A-DFT-QPSK-Edge_1RB_Right-18000-40000-PASS





NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-


NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+M-N/A-N/A-DFT-QPSK-Edge_1RB_Left-0.009-
0.15-PASS











NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+H-N/A-N/A-DFT-QPSK-Edge_1RB_Left-6000-1
8000-PASS




NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+H-N/A-N/A-DFT-QPSK-Edge_1RB_Left-18000-
40000-PASS



NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+H-N/A-N/A-DFT-QPSK-Edge_1RB_Right-0.009
-0.15-PASS



NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+H-N/A-N/A-DFT-QPSK-Edge_1RB_Right-0.15-
30-PASS



NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+H-N/A-N/A-DFT-QPSK-Edge_1RB_Right-30-10
00-PASS

NTNV-DC_66A_n78A-3700-3800-PC2-30-5+100-
M+H-N/A-N/A-DFT-QPSK-Edge_1RB_Right-1000-
6000-PASS

