

CH18 Hand Control Instructions

1. Product Overview

Product Name: Hand Control

Product Model No.: CH18

FCC ID: 2AEQWCH18HHC003

2. Environment requirement

Operation temperature: $+10^{\circ}\text{C} \sim +40^{\circ}\text{C}$.

Storage temperature: $-10^{\circ}\text{C} \sim 65^{\circ}\text{C}$.

Operating Humidity: 10%~80%RH, non-condensing.

Storage Humidity: 10%~ 85%RH, non-condensing.

3. Directions for Operation

In order to operate, place three 1.5V AAA batteries in the remote control and use in conjunction with the CB18 control box. In addition, the PSK2920A power supply switch must be connected as the power supply for the control box. Detailed operation directions below:

Match Code:



Press and hold the button, approx. 15 seconds, until the remote's front indicator lights up. Then, connect it to the control box Power plug. After the beep sound, the pairing is complete and remote can operate.





4. The port is introduced

All motorized functions of the bed are controlled by the remote control.

4.1.BackrestLift.



Press this button to lift up the backrest. Keep the button pressed and release when the desired tilt is achieved.



Press this button to lower the backrest. Keep the button pressed and release when the desired tilt is achieved.

4.2.FootrestLift.



Press this button to lift up the footrest. Keep the button pressed and release when the desired tilt is achieved.



Press this button to lower the footrest. Keep the button pressed and release when the desired tilt is achieved.

4.3.Bed Tilt.

If the optional bed Tilt is NOT installed on your bed, these buttons are without operation.



Press this button to lift up the head end of the bed. Keep the button pressed and release when the desired tilt is achieved.



Press this button to lower the head end of the bed. Keep the button pressed and release when the desired tilt is achieved.

4.4.Massage Function



Press this button to increase the intensity of the back massage.



Press this button to reduce the intensity of the back massage.



Press this button to stop the back massage.



Press this button to increase the intensity of the foot massage.



Press this button to reduce the intensity of the foot massage.



Press this button to stop the foot massage.

4.5. Backlit illumination of remote control



To illuminate the buttons for better night view when press this button . The light will turn off automatically after approximately 10 seconds.

Note: The light also turns on when pressing any of the other buttons.

5. Matters needing attention:

- 5.1 Do not mix old and new batteries or different types of batteries in remote.
- 5.2 When the battery power is weak, electrolyte leakage may occur, and will damage the remote. Once the power is low, replace the battery as soon as possible.
- 5.3 If the remote will not be used for a long period of time, remove the batteries to avoid electrolyte leakage.
- 5.4 The battery should not be exposed to direct sunlight, fire, or other excessive heat. To protect the environment, used batteries should be recycled in a proper manner.

6. Additional attention for user:

6.1 This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

6.2 This device complies with part 15 of the FCC Rules. Operation is subject to the following two

conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

6.3 This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. To maintain compliance with FCC RF exposure compliance requirements, please using a minimum separation distance of 5 mm from the device.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

6.4 For Intentional and unintentional radiators the manual shall caution the user that changes or modifications not expressly approved by the party responsible for compliance could void the users authority to operate the equipment