




Welcome

Hi, I'm Jamie Siminoff, inventor of your Ring Video Doorbell Pro.

Congratulations on purchasing the world's most advanced doorbell!

With Ring, you'll always know who's at your door, whether you're across town, on vacation, or just can't come to the door. As my wife likes to say, "Ring is like caller ID for the front door."



If you need extra help...

Our support team is available 7 days a week, and our online help center is accessible 24/7.

Visit our online help center at: ring.com/help

Contact our support team directly at:

800-656-1918
help@ring.com

Step 1

Download the Ring app

The Ring app will walk you through the entire process outlined in this manual, but in case you like reading small print we've included this manual as well.

Visit: ring.com/app

Visit the online setup guide

We have an online guide with videos and tutorials on setting up and using your Ring Video Doorbell Pro.

View the online setup guide at: ring.com/setup

Step 2

Say "Hello" to your Ring Video Doorbell Pro

Front

Mounting holes

Setup button

Back

Terminals (attach your existing wiring here)

4 Faceplates
Pick the one that best matches your home...or your mood. Change it any time.

Step 3

Check out all the cool stuff in the box

- 1 Ring Screwdriver** - Use the Phillips end for tightening the screws that hold the doorbell wiring and the doorbell in place, and the star-shaped end for tightening the security screw.
- 3 Anchors** - For concrete, stucco, or brick installs.
- 1 Drill Bit** - Use to drill holes if using the anchors.
- 3 Screws** - For attaching Ring Doorbell to your wall.
- 2 Security Screws** - Use one to secure the faceplate.
- 2 Extra Wires** - Use these if you have trouble attaching your existing wiring to the back of your Ring Doorbell.
- 2 Wire connectors** - Use to connect the extra wire (above) to your existing wiring.
- 1 Pro Power Kit** - Install the Pro Power Kit after installing your Ring Doorbell. It's got its own manual.

Step 4

Remove your existing doorbell

To get started, shut off power at the breaker.

Then remove your existing doorbell from the wall and disconnect the wires.









i As a reminder, this entire process is explained in a video inside the Ring app.

Step 5

Install anchors (on stucco, brick, or concrete)

On **stucco**, **brick**, or **concrete**, use the provided bit to drill two holes in your wall, and install the anchors.

If you're installing on **wood** or **siding**, put the anchors in that drawer of stuff you never use and skip this step.



Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

IMPORTANT NOTE:

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

High Power Radars: High power radars are allocated as primary users (meaning they have priority) in the 5250MHz to 5350MHz and 5650MHz to 5850MHz bands. These radars could cause interference and/or damage to Wireless LAN devices used in Canada.

Les utilisateurs de radars de haute puissance sont désignés utilisateurs principaux (c.-à-d., qu'ils ont la priorité) pour les bandes 5250 - 5350 MHz et 5650 - 5850 MHz. Ces radars pourraient causer du brouillage et/ou des dommages aux dispositifs LAN-EL.

IMPORTANT NOTE:

IC Radiation Exposure Statement:

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance **20cm** between the radiator & your body.

Cet équipement est conforme aux limites d'exposition aux rayonnements IC établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé avec un minimum de 20cm de distance entre la source de rayonnement et votre corps

CAN ICES-3 (B)/NMB-3(B)