封底

For FAQs and More Information, Please Visit:

choetech/support

www.choetech.com

support@choetech.com

b2b@choetech.com

http://www.facebook.com/choetechofficial

http://www.twitter.com/CHOETECH

封面

choetech

User Manual

Model: JP387Pro P/N: B760

01 English
04 中文(简体)
07 日本語
10 한국어
13 中文(繁體)
16 Français
19 Polski
22 Magyar
25 Čeština
28 العربية

Package List

1 x Qi2.2 25W MagLeap Wireless Charger, 1 x User Manual

Specifications

Cell Capacity/Energy	5000mAh/38.7Wh (2 cells in series)
Rated Capacity	5500mAh (5V ⎓ 3A)
USB-C Input	5V ⎓ 3A, 9V ⎓ 3A, 12V ⎓ 2.5A, 15V ⎓ 2A, 20V ⎓ 1.5A
USB-C Output	5V ⎓ 3A, 9V ⎓ 3A, 12V ⎓ 3A, 15V ⎓ 3A, 20V ⎓ 2.25A
Wireless Output	25W (Max)
Total Output	5V ⎓ 3A
Conversion efficiency	≥70%

Product Diagram

① Wireless Charging Area (compatible with Qi-enabled phones and earbuds)
② Power Switch
③ Power Indicator
④ USB-C Input/Output
⑤ Stand



Indicator Description

- Orange Indicator Light: Wireless charging status
- Four Blue Indicator Lights: Power bank battery level display

Battery Level Display (Blue Indicators)

- First blue light always on: 5%–25%
- Second blue light always on: 25%–50%
- Third blue light always on: 50%–75%
- Fourth blue light always on: 75%–100%

Low-Current Mode Display (Breathing light alternates with battery level)

- First running light illuminated
- Second running light illuminated

How to Use

1.Press the power button and check the power level.



2.Two Ways to Charge Your Phone.
Charge Your Phone Wirelessly
Charge Your Devices via USB-C port



3.Recharge Your Power Bank.



Safety Precautions

Warning: Always follow these guidelines when using this product:

a) Do not insert hands or fingers into the product.
b) When not in use, disconnect the power supply.
c) Do not expose the power bank to rain or snow.
d) To reduce the risk of injury, closely supervise the product when used near children.
e) Do not use a power adapter that exceeds the rated power or is damaged or modified,as it may cause fire, explosion, or personal injury.
f) Due to the fire and burn risks associated with the built-in battery, do not disassemble,compress, burn the product, or expose it to temperatures above 60°C/140°F.
g) To ensure product safety, do not disassemble the power bank or use a non-manufacturer-recommended power adapter. If repairs are needed, have them performed by a professional using the same replacement parts to avoid the risk of fire or injury due to improper handling.
h) Do not expose the power bank to flames or high-temperature environments. Exposure to flames or temperatures above 100°C/212°F may cause an explosion.
i) To extend the lifespan of the power bank, it is recommended to charge and discharge the power bank approximately every three months when it is not in use. This helps maintain battery activity and prevent natural aging of the battery.
j)When there is a metal object at the position of the wireless charging coil, and the size is large(larger than the diameter of a RMB 1 coin), the wireless charging circuit will indicate that there is a foreign object and stop the wireless charging output.
k)The magnet may interfere with the magnetic charging of the product or cause failure; to avoid interference between other devices or products, please keep magnetic chip cards (such as ID cards and credit cards) and medical devices (such as pacemakers, defibrillators, hearing aid,etc.(at least 20cm away from the products,and more than 30cm in wireless charging.
l)If the battery is not replaced properly, there is an explosion risk. Only batteries of the same type or equivalent type can be used for replacement. And only maintenance personnel can replace it, not ordinary personnel.
m)Batteries must not be exposed to environments such as direct sunlight, fire or similar overheating conditions.
n)If consumers charge with a power adapter, should purchase a power adapter that has obtained CCC certification and meets the standard requirements for use.
o)Product should be placed on the desktop when using, if it needs to be used in contact with the human body, the contact time should be less than 10 seconds.
p)Do not use after soaking in water
q)Please use the product in a temperature range of 0-35°C and humidity of 20-70% RH. Keep it away from moisture, heat, and fire.

包装清单

1 x Qi2.2 25W MagLeap 无线充电器，1 x 说明书

规格

电芯容量/能量	5000mAh/38.7Wh（2节电芯串联）
额定容量	5500mAh (5V ⎓ 3A)
USB-C 输入	5V ⎓ 3A, 9V ⎓ 3A, 12V ⎓ 2.5A, 15V ⎓ 2A, 20V ⎓ 1.5A
USB-C 输出	5V ⎓ 3A, 9V ⎓ 3A, 12V ⎓ 3A, 15V ⎓ 3A, 20V ⎓ 2.25A
无线输出	25W (最大)
总输出	5V ⎓ 3A
转换效率	≥70%

产品示意图

① 无线充电区域(兼容支持 Qi 协议的手机及耳机)
② 电源开关
③ 电量指示灯
④ USB-C 输入/输出
⑤ 支架



指示灯说明

- 橙色指示灯： 无线充电状态
- 四个蓝色指示灯： 移动电源电量显示

电量显示（蓝色指示灯）

- 第一个蓝灯闪烁： 0%–5%
- 第一个蓝灯常亮： 5%–25%
- 第二个蓝灯常亮： 25%–50%
- 第三个蓝灯常亮： 50%–75%
- 第四个蓝灯常亮： 75%–100%

小电流显示（跑马灯与电量轮流显示）

- 跑马灯第一个灯亮
- 跑马灯第二个灯亮

使用方法

1.按下电源按钮查看电量。



2.两种充电方式
1)磁吸无线充电
2)通过 USB-C 接口充电



3.为移动电源充电。



安全注意事项

警告：使用本产品时，请始终遵循如下规范：

a)请勿将手或手指伸入产品内部。
b)不使用本产品时，请切断电源。
c)请勿将移动电源暴露在雨雪环境中。
d)为降低受伤风险，在儿童附近使用本产品时，请密切看护。
e)请勿使用超过额定功率或已损坏、改装的电源，以免引发火灾、爆炸或人身伤害。
f)由于内置电池有着火和烧伤风险，请勿将产品拆卸，挤压，焚烧，或受热于60℃/140°F以上。
g)为确保产品安全，请勿私自拆卸移动电源或使用非制造商推荐的电源适配器，若需维修，应由专业人员使用相同的替换部件操作，避免因错误操作导致火灾或人身伤害。
h)请勿将移动电源暴露在火源或高温环境中。暴露在火源周围或在100℃/212℃及以上的温度中可能引起爆炸。
i)为了延长移动电源的使用寿命，建议在不使用时每三个月对移动电源进行一次充放电。这有助于保持电池活性并防止电池自然老化。
j)若无线充电线圈位置存在金属物体，且尺寸较大（大于1元硬币直径），无线充电电路将提示存在异物并停止无线充电输出。
k)磁体可能干扰产品的磁吸充电功能或导致失效；为避免对其他设备或产品造成干扰，请确保磁条卡（如身份证、信用卡)及医疗设备（如心脏起搏器、除颤器、助听器等）与产品保持至少20厘米距离，无线充电时则需保持30厘米以上间距。
l)如果电池更换不当会有爆炸危险，只能用同样类型或等效类型的电池来更换;仅维修人员可更换，非一般人员更换。
m)电池不得暴露在诸如日照，火烤或类似过热环境中。
n)消费者若使用电源适配器充电，则应购买配套使用获得CCC认证并满足标准要求的电源适配器。
o)产品使用时应放置在桌面，如需接触人体使用，接触时间应小于10s。
p)浸水后禁止使用。
q)请在0-35°C的温度范围和20-70% RH的湿度条件下使用本产品。请远离潮湿、高温和火源。

FCC Compliance Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Warranty

简中:品质保证 | JP: 品質保証 | KR: 품질보증 | 繁中： 品質保證 |
FR: Garantie de qualité | PL: Zapewnienie jakości |
HU: Minőségbiztosítás | CZ: Záruka | ضمان الجودة :AR

24-Month Warranty
简中:24个月质保期
JP:24ヶ月保証
KR: 품질 보증 기간 24개 월
繁中: 24個月質保期
FR:Période de garantie de 24 mois
PL:24 miesiące gwarancji
HU:24 hónapos garanciaidő
CZ:24měsíční záruka
AR: ضمان لمدة 24 شهرا

Lifetime Technical Support
简中:终身技术支持
KR:평생 기술 지원
JP:生涯テクニカルサポート
繁中: 終身技術支持
FR:Soutien technique permanent
PL:Dożywotnie wsparcie techniczne
HU:Egész életen át tartó technikai támogatás
CZ:Doživotní technická podpora
AR: دعم فني مدى الحياة

choetech	V1	Date/日期 2025/11/21	Designer/设计师	张体韶	Product Editor/产品编辑	陈秋瑜	Verifing/审核 刘艳霞
			Scale/比列	1:1	Hook Up/挂钩	/	Other/其他 /
Model/型号 B760	COLOURS 颜色	CYAN MAGENTA YELLOW BLACK					
Size/尺寸 70x100mm	Material Technology/材质工艺 128g铜版纸/双面4C印刷/骑马钉						
Manual 说明书	Change/变更						