





FRONT

SPECIFICATIONS • Earbud Weight: 4.5 grams • Speaker Driver Size: 10 mm • Supported Profiles: HFP, HSP, A2DP, AVRCP • Bluetooth Version: 5.0 • Earbud Charging Time: Up to 1.5 hours • Working Voltage: 5V • Standby Time: Up to 70 hours • Playtime (Normal mode): Up to 7 hours at 70% volume • Playtime (ANC mode): Up to 5 hours at 70% volume • Bluetooth Range: 10m • Number of Microphones: 3 • Working Temperature: 0°C to +45°C	CHARGING CASE SPECIFICATION • Charging Case Weight: 48 grams • Charging Port: Type-C • Number of Earbud Charges from Case: Up to 4 times • Case Charging Time: Up to 2 hours • FCC ID:2AEZG-I3	PACKAGE CONTAINS  Insmys-I3 Earbuds x 1  Charging case x 1  Large Ear Tips x 2  Medium Ear Tips x 2  Small Ear Tips x 4  USB Type-C Charging Cable x 1	POWER ON The earbuds will automatically turn on on opening the charging case.  POWER OFF The earbuds will automatically turn off on closing off the charging case. PAIRING • Open the charging case. • Turn on the Bluetooth of your device. • Select 'Add Device' and from the list of devices, select Insmys-I3. • Your Insmys-I3 are now paired with your device and ready to use. • Note: Your Insmys-I3 will automatically connect to the last paired device as soon as you open the charging case.	RESET • Make sure that Insmys-I3 are fully charged and the case is open throughout the process. • Unpair/forget the earbuds from the 'saved devices' on your Bluetooth settings. • Place both the earbuds inside the case. • Open the charging case. • Long press the button on the charging case for 10 seconds while it's charging. Note: The 4 LEDs will flash in white 5 times indicating that the earbuds are reset. CHOOSING YOUR EAR TIP SIZE Earphones are fitted with medium-size tips. However, if you find they don't fit perfectly, please remove and try the small and large ear tips. Follow the images and chart to learn how to wear the earbuds in the right manner. 	SMART SOUND FEATURES HYBRID ANC The Insmys-I3 feature 3 advanced microphones on each earbud that capture ambient/environmental noises. These noises are processed by the hybrid noise-cancellation system that equalises them before they reach your ears, making sure that you get the best sound. Long press the right earbud for 2 seconds to enter the ANC mode  TRANSPARENCY MODE Transparency mode ensures that you get to hear the outer sounds and know what's going on around you, without affecting the quality of what's being played on your earbuds. Long press the right earbud for 2 seconds to enter transparency mode from the ANC mode. 	How to clear the product memory of connected Bluetooth devices? Put the earbuds into charging case without closing the lid, long press 8 seconds to clear the paired Bluetooth device records. Clear successfully 4 lights will turn off after 3 seconds Failed 4 lights flash 10 times then go out. 	 This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: – Reorient or relocate the receiving antenna. – Increase the separation between the equipment and receiver. – Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. – Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.	
--	---	--	--	--	---	--	---	---

BACK

CONTROLS  Play/Pause Tap either earphone twice  Previous Song Tap the left earphone thrice  Next Song Tap the right earphone thrice  Volume Up Tap the right earphone once	CONTROLS  Volume Down Tap the left earphone once  Answer/End a Call Tap either earphone once to answer Tap either earphone twice to end  Reject Call Touch and hold either earphone for 2 seconds  Voice Assistant Touch and hold the left earphone for 2 seconds	CHARGING EARBUDS Place both earbuds in the case to charge them. CASE Place both the earbuds in the case to charge them.    0-25%  25 - 50%  50 - 75%  75 - 100%	Warm Reminder Troubleshooting for Low Volume. Most Android phones do not support volume synchronization (the volume of the phone and the volume of the earbuds need to be adjusted separately). When the wireless earbuds are connected to the phone, adjusting the volume of the phone only increases the volume of the audio source. If the volume of the earbuds are not adjusted, music still low sound. The earphones volume need to be turned up through tapping the earphones.	WARRANTY The warranty covers your Insmys-I3 product, including accessories against manufacturing defects (if any) for 1 year from the date of purchase. Things that are not covered in the warranty • Unauthorized tampering, modifications or repairs of the product. • Physical damage of the product on the account of abuse, handling, storage, installation or testing including any use that is not in accordance with the product manual or documentation, or any other instruction provided along with the Insmys-I3 product.	CONTACT US Dear Valued Customer, We want you to be completely satisfied with your purchase. If there is any quality issue on your product, please contact our seller support first via Amazon message service or our support email insmy@insmy.com.cn. And we will provide you with the best and quickest support. Sincerely, INSMY	SAFETY FOR YOU AND YOUR Insmys-I3 Follow these tips and you & your Insmys-I3 will be happy together for a very long time.  Don't try to disassemble your Insmys-I3. There are no user serviceable parts inside it.  Do not expose Insmys-I3 to liquids, moisture or humidity. It has electronics and a battery in it. Neither of them likes getting wet.  Try not to drop your Insmys-I3 and keep it away from sharp objects such as keys in your pockets.  Don't use abrasive cleaning solvents to clean your Insmys-I3. Wipe them down with a slightly damp cloth if and when necessary.  Remove and clean the earbud tips regularly, to ensure that you always enjoy the best sound possible from your Insmys-I3.  Do not expose Insmys-I3 to extremely high or low temperatures as this may damage the battery or even deform the plastic parts. Don't throw your Insmys-I3 in a fire to dispose it.The internal battery may explode.  Never listen to music at high volumes or you may permanently damage your hearing.  Pay attention to your surroundings and never wear ANY headphones while riding, driving or walking in traffic do not come with any warranty.	product Important Prompt The product can be charged by 5V Chargers/USB ports only. Adapters over 5V such as quick chargers are not allowed, which may cause fire or explosion. Please refer to this manual before using the product	True wireless earbuds Model No.: i3 FCC ID: 2AEZG-I3 Size: L4.0cm*W2.3cm  Note: The headphones are too small to fit on the label , and are stored in the instruction manual.
---	--	---	--	--	---	---	--	---