


User Manual

Bluetooth Earbuds

LEB59

Location of controls


Front



Side



Back Side



1. LED indicator light
2. [-] button:
 - Quick press = decrease volume
 - Long press = skip to previous song
3. [O] button:
 - Long press = power ON/OFF; reject a call
 - Quick press = play/pause; answer/end call
4. [+] button:
 - Quick press = increase volume
 - Long press = skip to next song
5. Micro USB charging port
6. Microphone

On an iPhone
• Go to **SETTINGS > BLUETOOTH**
(Make sure Bluetooth is turned ON)




On a Blackberry
• Go to **SETTINGS/OPTIONS > BLUETOOTH**
• Enable **BLUETOOTH** (Make sure Bluetooth is turned ON)



On an Android Phone
• Go to **SETTINGS > BLUETOOTH > MENU > Search for devices** (Make sure Bluetooth is turned ON)



On other Cell Phones/Devices
• Review the instruction manual that came with your phone/device.



5. When the Bluetooth enabled device finds the earbuds, select "MERCURY BTE22" from the list of found devices.
6. If required, enter the password 0000. Select OK or Yes to pair the two units.
7. After successful registration, a tone will be heard and the LED Bluetooth indicator light will flash BLUE twice every few seconds.

NOTE: If you would like to connect the earbuds to your device, you must unpair them from the recently paired device first. In your device's Bluetooth settings, select "MERCURY BTE22"; then select "unpair"; once earbuds have been unpaired, they automatically go into pairing mode again.

The screenshots above are typical of many Bluetooth enabled devices in the market today, and to assist in the explanation of the pairing process. Your Bluetooth enabled device's interface or interaction with the earbuds may slightly differ from the illustrations above.

Using the earbuds

Powering ON/OFF

- To turn on, long press the [O] button until you see a BLUE light. To turn OFF, long press the [O] button until you see a RED light.
- Check that your Bluetooth features are turned ON. If you have already paired the earbuds with a Bluetooth enabled device, it will automatically connect.
- If you are using the earbuds for the first time, go to the "Pairing the Earbuds" section of this User Manual, and pair the earbuds to your desired Bluetooth device.

Adjusting the volume

- Quick press the [+] button to increase the volume.
- Quick press the [-] button to decrease the volume.

Answering / ending a call

- To answer a call, quick press the [O] button.
- To end a call, quick press the [O] button.

Rejecting a call

- Long press the [O] button to reject a call.

Playing music

To enjoy listening to music wirelessly on your Magnetic Sports Earbuds, make sure you are connected to a Bluetooth enabled device. (see "Pairing the Earbuds"). Once connected, press PLAY on your Bluetooth device. When playback has begun, control the music and volume with your connected device or the buttons on the earbuds.

Play/ Pause

- Quick press the [O] button to pause the music.
- To resume music playback, quick press the [O] button again.

Skipping Songs

- Long press the [+] button to skip to the next song.
- Long press the [-] button to skip to the previous song.

Adjusting the volume

- Quick press the [+] button to increase the volume.
- Quick press the [-] button to decrease the volume.

Troubleshooting tips

I can pair the Magnetic Sports Earbuds with my Bluetooth device, but I cannot hear any music.

1. Make sure your Bluetooth device supports A2DP profile.
2. Turn up the volume on your Bluetooth device.
3. You may have to unpair the earbuds, then re-pair to your device.

My Bluetooth device is not able to pair with the Magnetic Sports Earbuds.

1. Long press the [O] button until a tone is heard and the LED Bluetooth indicator light alternately flashes RED and BLUE.
2. Keep the earbuds and Bluetooth enabled device within 3 feet of each other during the pairing process.
3. Check that your device's Bluetooth feature is turned ON.
4. Try repeating the pairing process. See "Pairing the Earbuds."
5. Make sure the earbuds are fully charged.

I cannot get the Magnetic Sports Earbuds into pairing mode.

1. Long press the [O] button until a tone is heard and the LED Bluetooth indicator light alternately flashes RED and BLUE.
2. The earbuds are now in pairing mode.

Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with a dry cloth.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
10. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
11. Only use attachments/accessories specified by the manufacturer.
12. Use only with a cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination during lightning storms or when unused for long periods of time.

13. Unplug the apparatus during lightning storms or when unused for long periods of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged; liquid has been spilled or objects have fallen into the apparatus; the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
15. **WARNING:** The mains plug is used as a disconnect device; the disconnect device shall remain readily operable.
16. **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing, and objects filled with liquids, such as vases, shall not be placed on apparatus.
17. **CAUTION:** This equipment is a Class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.




CAUTION: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Caution:** Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Charging the earbuds

1. Plug the small end of the Micro USB charging cable into the Micro USB charging port on the earbuds.
2. Plug the large end of the Micro USB charging cable into a USB port on your computer or other USB charging device.
3. The LED charging indicator light is RED when charging. It will turn BLUE when the earbuds are fully charged.
4. Set your Bluetooth enabled device to search for Bluetooth devices.



I Make sure you charge the earbuds for at least 3 to 4 hours before using it for the first time.

Pairing the earbuds

1. Make sure the earbuds are turned off.
2. Long press the [O] button until a tone is heard and the LED Bluetooth indicator light alternately flashes RED and BLUE.
3. Keep the earbuds and Bluetooth enabled device within 3 feet of each other during the pairing process.
4. Set your Bluetooth enabled device to search for Bluetooth devices.



I If there are no paired devices in range when the earbuds are turned on, it will go into pairing mode automatically. If a paired device is in range, the earbuds will connect to it automatically.