



FCC ID: 2AF7A-A100

1 × Micro USB Cable 1 × 3.5 mm Audio Cable

1 × User Manual

The diagram shows the back of a rectangular device with several ports and buttons. A circular callout provides a magnified view of the bottom-left section, highlighting the USB flash drive port, the Micro USB charging port, and the charging indicator LED. Labels with leader lines point to each of these features.

- Inserted an audio cable in the powered-on state, it will enter the Aux-in mode automatically.**
- Built-in reset button:** Press the reset button in the jack with a needle to reset speaker.
- USB flash drive Port**
Inserted an USB flash driver in the powered-on state, it will play the music stored in the driver automatically after beeps.
- Micro USB Charging Port:** Use CV / 5V 1A adaptor to charge the speaker
- Charging Indicator:** Red light will stay on when charging, turn off after finish charging.
- Micro SD Card Slot**
In the powered-on state, insert a Micro-SD card, it will play the music stored in the card automatically after beeps.

Tips:

1. For the first time of setting up the TWS system, the speaker you press the Bluetooth button one will work as the main speaker and the other one as the dependent speaker.
2. After the first connection, the main speaker will keep working as the main speaker and the dependent one will keep working as the dependent one in the future connection.
3. After setting up the TWS system, the dependent speaker's blue LED indicator stays on and the main one's LED indicates your operation.
4. The true wireless stereo function supports only 2 speakers.
5. After the TWS system is set up successfully, you just need to operate either speaker. The other one will do the same operation simultaneously.

Copyright © MIFA. All rights reserved.
MIFA, the MIFA logo and other MIFA marks are all owned and registered by MIFA INNOVATIONS LLC. All other trademarks are the property of their respective owners. The information contained here is subject to change without prior notice.