

Music and Play Button Music Play Operate on the phone or Click MFB of the headset. (Music will play automatically on some mobile phones when it is connected with the Bluetooth device) Pause and Restart Music When listening to music, click MFB to pause music and click MFB again to restart music. Volume To adjust the volume when listening to music, press the V+ or V- to adjust the volume up or down. When you reach the max/min volume, you will hear a notfcaton tone. Play Previous Song Press backward buton. Play Next Song Press forward buton. Fast forward Long press forward buton. Fast backward Long press backward buton NFC Make sure your mobile operatng system is above Android 4.11 with NFC function. Operatng procedures as below: ◆ Open NFC function of the mobile phone ◆ Keep the back of the mobile phone (ensure the mobile screen is in the operatng state) touching the NFC positon of the headset (ensure the headset is powered of) for 2 seconds, you will hear the voice of powering on. At the same tme, there will be a pop - up window on the mobile phone: if it states connected with “Grv-E-Sport” YES or NO, please do not select anything right now! Keep the devices in this state, when you hear the warning voice again and the LED indicator fashes red and blue in alternatng colors, 4	the headset enters into pairing mode, select “YES” on the phone, then connect with the speaker. It will display on the phone if connected successfully. Please repeat above operaton if failed. ◆ The next tme you use the same headset, keep the back of the mobile phone touching the NFC positon of the headset, you can move the mobile phone away when you hear the reminder tone from the headset, there is no need to keep touching the headset, it will connect with the mobile phone automatically. ◆ If you want to disconnect the Bluetooth functon, keep the back of the mobile phone touching the NFC positon of the headset, the headset will disconnect with the mobile phone. If you want to turn of the headset, keep the back of the mobile phone touching the NFC positon of the headset for about 6 seconds. Warranty Instructions Your Gear 2S Headset comes with a 12 month product replacement warranty. To register and qualify under this warranty go to the online product registraton located at the Move&Groove URL listed below: WWW.SONYXER.COM Once you have registered your product and you would like to make a claim please email—support@mymoveandgroove.com for immediate assistance. Headset Specifications ◆ Size: 31×28×9mm ◆ Weight: 17.2g (Net Weight) ◆ Bluetooth version: 4.0 ◆ Bluetooth range: 33 Feet ◆ Charging port: Micro USB ◆ Battery: Rechargeable lithium polymer batery 3.7V; 120mAh ◆ Charge indicator: Red LED light (Charging) / Blue LED light (Charging completed) ◆ Standby tme: about 200 hours ◆ Talk tme: about 8 hours ◆ Music tme: about 6 hours ◆ Charging tme: about 2 hours 5	FCC Statement This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct theinterference by one or more of the following measures: --Reorient or relocate the receiving antenna. --Increase the separation between the equipment and receiver. --Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help. This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2)This device must accept any interference received, including interference that may cause undesired operation. Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. such modifications could void the user's authority to operate this equipment. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. RF exposure warning This device is measured RF output power is less than the SAR exclusion threshold value for human head and body The equipment must not be co-located or operating in conjunction with any other antenna or transmitter. 6	WWW.SONYXER.COM  Gear 2S GEAR 2S USER MANUAL
Controls ⌂ Mult -Function Buton (MFB) + Volume Up - Volume Down ⏮ Forward ⏭ Backward Operatng Instructions Power On When the headset is of, press and hold the Mult -Function Buton (MFB) for 2 seconds. The LED indicator will fash for one second in blue. At this tme you will hear the words “Power ON” from the headset. The headset will be paired with the last connected Bluetooth device or mobile phone automatically when turned on. Power Of When the headset is on, press and hold the MFB for 3 seconds. The LED indicator will fash once slowly in red. At this tme, you will hear the words “Power Of” from the headset. The headset will disconnect from your phone or device when turned of. Pairing Mode When the headset is of, press and hold MFB for 5 seconds untl the LED indicator fashes red and blue in alternatng colors. At this tme, you will hear the words “Pairing” from the headset. Turn the Bluetooth on for your device and search for the Headset name “ Gear 2S ”. Connect to the headset and enter “0000” if requested. ※ If you release the MFB before the headset goes into pairing mode, it will power on and connect with the last paired device. If you want to pair the headset with a new phone device, please power of the headset and start again, or press the vol+ and vol- buton concurrently to go into pairing mode again. Easy connecton functon If the headset doesn't connect with any phones when it is on, you can enter into speed pairing mode by pressing the vol+ and vol- buton concurrently and connect with your phone. 1	Answering calls If a call comes in when listening to music or headset is paired and standing by, press the MFB to answer the incoming call. You will hear the words “Call Answered” from the speaker of the headset. If the music is playing, it will pause automatically during the call, the music will start playing automatically when the call is terminated. Reject Calls If a call comes in, press and hold the MFB buton for 2 seconds to reject the incoming call. You will hear the words “Call Rejected” from the speaker of the headset. End Calls Press the MFB to terminate when you fnished your call, you will hear the words “Call Terminatd”. Volume To adjust the volume when talking on the phone, press the vol+ and vol- to turn volume up or down. When you reach the max/min volume, you will hear a notfcaton tone. Last Number Redial When listening to music or headset is paired and standing by, double click MFB to redial the last number. You will hear the words “Last Number Redial” from the speaker of the headset. If you are listening to music, it will pause automatically during the call. Mute When talking on the phone, press and hold vol+ or vol- for 2 seconds to mute your phone. You will hear the caller, but the caller will not hear you. There will be a warning tone every 10 seconds, reminding you that you are in mute mode. Quit Mute Press and hold vol+ or vol- for 2 seconds to exit mute mode. Switching Between Your Mobile Phone and Headset When talking on the phone, double-click the MFB to switch the voice 2	from your headset to your mobile phone. Double-click the MFB again to switch back to the headset. You will hear a tone to remind you that you have switched to the mobile phone. Reconnect When the headset is disconnected from your mobile phone, you will hear the words “Your headset is disconnected”. If you press the MFB, it will reconnect. You will hear the words “Your headset is connected” from the headset. ※ Some mobile phones may have a prompt screen, that will ask you if you would like to pair your device. Voice-Command Dial If your mobile phone supports this functon, press and hold vol+ or vol- for 2 seconds to actvate voice command. You will hear “voice dial” from the headset. By re-pressing and holding vol+ or vol- for 2 seconds during the voice dial mode, voice dial will be cancelled. ※ Please refer to the manual of your mobile phone for voice-command dial support. Connect with 2 mobile phones - First disconnect the Bluetooth device from your phone if it is already connected. - Press vol+ and vol- concurrently to put the headset in pairing mode. - Turn on and search Bluetooth device on your second phone until you fnd “ Gear 2S ” and select to begin pairing. - Please reconnect with your frst mobile phone device. - Now you should have two mobile phones connected with the headset. Transfer Calls When you are talking on the phone and receive another incoming call, press the MFB for 2 seconds to reject the incoming call. If you click vol+ and vol- concurrently (with the reminding tone), you will answer the incoming call. Your frst call will be placed on hold. When you click vol+ and vol- concurrently again, you will transfer back to your frst call. You should hear a beep. During this tme your second call will be placed on hold. You can also end the call by clicking the MFB. 3	WWW.SONYXER.COM  Gear 2S GEAR 2S USER MANUAL