

LIGHT UP ELECTRONIC WORD CLOCK WITH BLUETOOTH SPEAKER

INCLUDES

- 1x Word Clock
- 1x USB Power Cord

POWER:

The Word Clock is powered by connecting the included USB cable to a power outlet or by connecting the cable to a 5V USB port.

SETTING THE CLOCK:


1. Connect the clock to a power source.
The words will flash 2 times.
2. The clock will display "It Is Twelve O'Clock" (right).
3. Move the time forward by pushing and holding the Time Advance button, or backwards by pushing and holding the Time Reverse button.
4. When you have reached the desired time, release the button and the clock will display the time in five minute segments.

READING THE CLOCK:

- Every five minutes, the clock will change its display.
- The clock is read from top to bottom.
- The clock displays the time in terms of minutes past the hour up to 30 minutes and then minutes until the hour.
 - o It is: Five Minutes Past, Ten Minutes Past, Fifteen Minutes Past, Twenty Minutes Past, Twenty Five Minutes Past, Thirty Minutes Past (Hour).
 - o It is: Twenty Five Minutes To, Twenty Minutes To, Fifteen Minutes To, Ten Minutes To, Five Minutes To (Hour).

BLUETOOTH MODE:

Plug in the DC power port and connect to 5V power, press and hold the Bluetooth power button for 3 seconds, the Bluetooth indicator lights up, then flashes quickly, the speaker emits a power-on tone, releases the button, Bluetooth enters the search state, the mobile phone or other devices searches for the Bluetooth pairing name: SPEAKER, clicks the connection, and after the connection is successful, there is a prompt tone, turn on the music player and start to play music. Press and hold the Bluetooth power button for 3 seconds to turn off Bluetooth.



- ← Time Advance
- ← Time Reverse
- ← Power Port

Reads: IT IS TWELVE O'CLOCK



Reads: IT IS FIFTEEN MINUTES TO THREE O'CLOCK



Reads: IT IS TEN MINUTES PAST FOUR O'CLOCK

SAFETY WARNINGS: PLEASE READ ALL SAFETY WARNINGS BEFORE USE

- Do not use attachments of any kind.
- For indoor use only.
- Do not expose to extreme temperatures or moisture.
- This item does not have serviceable components. Do not disassemble.
- Not intended for children under 14 years of age.
- Do not submerge in water.
- Thoroughly inspect products before every use. If the product appears worn, frayed/splintered, cracked, or broken in any manner, discontinue use and discard immediately.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.