


尺寸 : 700x100mm

Quick Start Guide for Video Doorbell Perform the In-app Setup Wobell App is available for iOS, Android. This app name is Wobell  	Attention: After installing Android App, select the appropriate APP in accordance with the following figure, to ensure that APP can receive push alarm and related operations at any time. 	Step 1: Open the App,click the"Set Up Device" 	Step 2: Select "New User" if it's a brand new Wobell device; "Add User" if your Wobell has been connected to other users. 	 New User	Step 3: Click "Next" after installing your Wobell and connecting to the power supply. 	Step 4: Short press the "Pairing" button on the bottom of your Wobell, click "Next" after hearing a voice prompt of "Pairing". 	Step 5: Click "Next". It will enter into your mobile phone. Wi-Fi setup automatically. Click to connect with your "Wobell" - device. 	Step 6: Choose Wi-Fi hotspot like"Wobell-xxxx" and then connect it. Proceed to the next step when the signals prompted for the Wi-Fi user. 	Step 7: Return to the App, and click "Next" 
Step 8: Device is pairing, when succeed, it will jump to the next step automatically 	Step 9: After connected, you can name your Wobell now 	Step 10: Find your network and input the correct Wi-Fi password and click "Next". 	Step 11: Congrat! You can use your Wobell now. 	 Wobell installed and works well, please click "Add user"  Add user	Step 1: Short press the "Pairing" button on the bottom of your Wobell, click "Next" after hearing a voice prompt of "Pairing". 	Step 2: Click "Next", it will enter into your mobile phone Wi-Fi setup automatically. Then find the correct Wi-Fi router of your Wobell and connect. 	Step 3: Return to the App, and click "Next". 	Step 4: After connected, you can name your Wobell now. 	Step 5: Congrat! You can use your Wobell now. 

正面

反面

尺寸 : 490x100mm

User's Guide for Video Doorbell

Product Overview

Our Wibed is a Wi-Fi enabled Smart Video Doorbell which helps you to see, hear and speak to anyone at your door from your smartphone or tablet from anywhere. This Video Doorbell supports two-way talking with built-in microphone, two-way audio, instant alert, motion detection and live monitoring.

Product Features

- White voice prompts for operation, push notifications with different tone.
- For Android smartphones, please enable all the functions before using the Wibed App after installing it on your phone to make sure that the doorbell works properly.
- Configurable events recording.
- Two-way audio with noise cancellation.
- Support multiple users connection. One doorbell can be connected with 4 smartphones, and one smartphone can be paired with 4 doorbells.
- Advanced motion detection which identifies human information harassment.
- 1080P 120FPS video quality and 120 degree wide angle view.

Product Specification Sheet


Item	170°/120° Wide angle view (max)
Wi-Fi Network	802.11b/g/n 2.4GHz with 2.4 meters both distance
Wi-Fi Mobile System	Android/iOS
Storage	Up to 32GB Micro SD card
Power Supply	4x AAA battery (not included)
Power Consumption	1.2W
Viewing Angle	120° (max) (open space without obstacles) (170° (max) (obstacle))
Wi-Fi Coverage	30 meters
Video Compression	H.264
Video Playback	Two-way audio with noise cancellation
Video Resolution	1080P 120FPS/1080P 30FPS

Multiple Users


Multiple Users	One doorbell can be connected with 4 smart devices, one smart device can be paired with 4 doorbells.
Working Temperature	-20° ~ 50° C
Storage Temperature	-40° ~ 70° C

Installing your Wibed


At first introduction of the Wibed:



Check out all the accessories in the box






Step 1: Remove your existing doorbell from the wall and disconnect the wires.



Step 2: Install the back patch board of the doorbell to the wall using the provided screws. And connect the back patch board to your existing wires.



正面



反面

Tips:

It's suggested to keep the distance between the Wobell VideoDoorbell and the router in your house within **15 meters**; If the distance is more than **15 meters**, it's recommended to contact Wobell seller to buy a WiFi range extender.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.