

ENJOYOU™

SH-01

FCC ID:2AFIISH-01

Bluetooth Headset Operation Manual

Introduction

Congratulations, and thank you for choosing SH-01 Bluetooth Headset.

This manual will help you operate the Headset, but you should first familiarize yourself with the Bluetooth functionality of your mobile phone or other devices before using the Headset. To enjoy your time with our product.

Safety rules:

1.Please follow the rules described in this manual closely to ensure your safety. Before using this Stereo Headset, we would strongly encourage you to read through this user manual.

2.Be more wary of any edges, uneven surfaces, metal parts accessories and its packaging so as to prevent any possible injury or damage.

3.Do not modify, repair or dismantle this Bluetooth Stereo Headset. Doing so may result in fires, electric shocks, complete breakdown of this Sport Bluetooth Stereo Headset, etc. All of which, are not covered under warranty.

4.Do not use any diluents or volatile liquid to clean the Sport Bluetooth Stereo Headset.

5.Do not use the Sport Bluetooth Stereo Headset in a hazardous location.

Accessories list

Bluetooth headset x1                      USB charge cable x1

Eargel x2                                      User manual x1

(Accessories will be different according to different models. If you have any questions please contact us).

Charging the battery

Battery must be fully charged before first time to use.

1.Open the USB cover and insert USB cable to charge the headset.

2.The red indicator on the headset will be on during charging. If the battery is fully charged,the red light will turn off and the blue indicator will turn on.

3.Pls take it off from the charging device in time after the headset is fully charged.

Overview of SH-01

1

2

3

4

5

6

7

8

1

2

3

4

5

6

7

8

Multifunction button

Turn on /Turn off,pairing, play/pause, Answer / end / reject a call, last number redial.

ON/OFF

Power on

Press and hold the multifunction button for about 3 seconds, the blue lights flash once.

Power off

Press and hold the multifunction button for about 4 seconds, the red lights flash twice.

Volume up button

Short press the button to increase the volume.

Long press to the next song during playing the music.

Volume down button

Short press the button to decrease the volume.

Long press to the previous song during playing the music

Pairing the headset

1.You are required to pair the headset with your mobile phone before using it. Press-and hold multifunctional button, the indicator light flashes red and blue alternately to go into pairing mode after 5 seconds.

2.Activate Bluetooth on your mobile phone.

3.Set your phone to discover "SH01" and follow the instruction.

4.If your phone asks for passkey or PIN-code, please enter: "0000".

5.When the Bluetooth device and "SH01" are paired, the blue LED indicator flashes twice.

Rejecting/connecting/holding/continuing/ending a call

When Headset is turned on and there is an incoming call, the blue indicator light flashes fast, you will hear incoming prompts operation.

(1) Rejecting a call

Press the multifunction button for 2 seconds to reject the call.

(2) Answering a call

Short press multifunction button to answer the call.

(3) Holding

Press multifunction button 2 seconds to hold the call.

(4) Continue

Press the multifunction button for 2 seconds to continue the current call.

(5) Hang up

Short press multifunction button to end a call .

Playing music

Play the music on your mobile phone, the music will be transmitted to your headset automatically.

Low battery

When the battery is low,the LED indicator light will flashes in red and you will hear the voice prompt of "battery low",The red indicator light turns on during charging, the blue indicator light turns on when charging completed, Charging time: Approximately 1.5-2hours.

Notice

1.If SH-01 headset is not in pairing mode, your mobile phone won't find the headset, please set the headset into pairing mode before making your mobile phone searches for SH-01.

2.If no pairing is possible for a period of time(approximately 5 minutes) the headset will power off automatically.

Warm tips

You Must select a qualified charger from a regular manufacturer.

You Must charge the Bluetooth headset If it has been not used for more than 12 months.

Warning

1.Avoid display your device to very cold or very hot temperatures (below 0°C or above 45°C).extreme temperatures can cause the deformation of the device and reduce the charging capacity and life of your device.

2.Do not use the device during a thunderstorm, thunderstorms can cause the device malfunction and increase the risk of electric shock.

3.Do not remove or modified headset for any reason,otherwise may lead to headset fault or burned, please send headset to authorized service center for repairs.

4.Place the device and all accessories out of the reach of children and pets ,Small parts may be swallowed cause suffocation and serious consequences.

Technical specification

Bluetooth Version: 4.0

Bluetooth Profile: A2DP/HFP/HSP/AVRCP

Solution: CSR8645

Noise Reduction

Talk Time: 5 hours

Music Time: 4.5 hours

Wireless Range: 10m

Charging Time: 2 hours

Dimension: 36.5 x 31.8 X 12 mm

FAQ

Q: Why can not turn the headset on?

A: Make sure your device is fully charged before using it for first time.

Your device can not be turned on if battery level is very low.

Q: there is no sound when playback?

A: Check the connection between your device with phone or computer, if the connection is not established, please reconnect again. And adjust the volume level to a suitable level.

Q: Phone or computer can't find your device ?

A: Check the Bluetooth is "visible" in your phone or computer, if pair time out, pairing mode will exit, please re-enter pairing mode . If your phone application have some problems, please re-start the phone . If your device has problem, re-start or reset it .

Safety rules

1.Do not remove or modified headset for any reason otherwise may lead to headset fault or burned and which is not list in the warranty paper.

2.Do not put the device approach to the liquid or it will be damage seriously and it is exceed the warranty paper .

3.Do not put the device into environment of temperature too low or too high(below zero or above forty-five Celsius degree)

4.Please avoid using the indicator light near children or animals' eyes.

5.Please do not use the equipment in thunderstorm weather. Thunderstorms can result in operation of the equipment and increase the risk of electric shock;

6.Do not put the headset into the water.

After-sales service and support

If the product you bought have a damage caused by not man made reason, please return to us or merchant to guarantee.

Produced by puhua technology co.,Ltd

4/F BLDG-B,Forzen Technology Park,Fuyuan 2nd Road, Fuyong Town,Baoan District,Shenzhen,China,

Place of origin: Shenzhen China

【Warranty instruction】

Warranty period is for one year

■ Please make sure of the following matters

1.Please fill out and keep this card properly to make sure that the products get the normal warranty service when you purchase this products.

2.During the warranty time, the user can obtain free maintain service if occurred barrier and use according to the instruction manual.

3.Please provide the warranty card along with your product and make sure that the information is true or it is invalid.

4.If the warranty period has expired, you still can get the company provides Warranty service, but need to pay the appropriate fees.

■ Warranty is unavailable if :

1.The defects resulting from improper or unreasonable use or maintenance, failure to follow operating instructions.

2.The defects caused by the dismantle movement of a non-our-company authorized maintainer.

3.If do not use with the instruction request such as non standard and not meet the specification power or high voltage to damage with it .

4.NO warranty card and purchase invoice ,warranty card has been changed or warranty card is not complete or not match with damage product.

5.The defects caused by the drop ,scratch or Transport collision etc. non quality problem after purchase.

6.The defects caused by the Force majeure(Such as lightning,floods, fires and other natural disasters)

SH-01

Guarantee card 【User receipt】

【Distributor return receipt】

Product name:

Product type:

User name:

User address:

Contact NO.:

Postcode:

Purchase Date:

Distributor company name and address(Effective with seal)

Name:

Address:

Telephone No.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.