



HEREMI

S3 Black Rose Smart Bracelet



User Manual



Get it on
Google play




Available on the
App Store

A Read the instruction before using the product.

1. Please read the instructions carefully before using the device; Follow the operation instructions to avoid unnecessary trouble.
2. This manual is based on the default settings of the device.
3. The images in this manual instruction may not be full match to the actual product but for reference? please understand.
4. Please properly keep instructions for future maintenance.

B Appearance instruction.



C The attachment with product.



Host



Battery



Cross screwdriver

D The Steps of Changing Battery



Picture 1

Step 1: Using Phillips screwdriver to open the battery cover.



Picture 2

Step 2: Put battery with the anode upward.

Step 3: Close the battery cover with Phillips screwdriver.

E、 Function introductions.

1.Alert Function.

Including phone call alerts、 get-up alerts、 Drinking alerts、 Sedentary alerts、 Memo alerts, etc.

2.UV Detection and Protection.

When detecting ultraviolet intensity, please don' t touch sensor areas frequently. APP will show the current UV intensity maximum

3.Searching Bracelet

Open APP and search bracelet, the bracelet will vibrate and shine with colorful lights

4.Motion Detection. (Pending)

The APP will show your daily walking time、 running time、 running steps and mileage.

5.Calorie consumption

APP records your daily calorie consumption.

6.Anti-lost.

When the distance between mobile and bracelet over Warning range (about 10 meters), it will vibrate and shine.

7.Clock display

When you move your hand or tap on the bracelet, twelve LED lights activate to display the time. On the hour, the

clock face conveniently lights up, while it flashes quickly for three seconds when the minutes hit multiples of five (e.g. 1.05pm, 1.10pm, and 1.15pm etc).

F、 Get Started

1.Android application downloads: Go to Google play -> Search "Smart Girl"-> Download and Install. (Supports Bluetooth 4.0/ Android 4.3 +)

2.iPhone application downloads: Go APP store search "Smart Girl" to download and install out application. (Supports Bluetooth 4.0/ IOS7.0 above system)

G、 Common problem.

1 How to connect the phone with the device?

First make sure IOS /Android device Bluetooth is turned on. Click on the Bluetooth connection button enter the APP settings page, search the Bluetooth device name, connect and binding equipment.

2 How long a battery can be used?

S3 smart bracelet uses the CR1632 button batteries, sustainable standby for 3 months.

3 Bracelet waterproof it?

Life waterproof

4 Why bracelet steps are gone in the morning.

Bracelet date will be zero at 00:00 am on each day, and record new data again.

H、 Trouble Diagnoses.

1 . Powered clock LED lamp is not bright.

(01) No touch between the pole and the copper sheet.

(02) No power in the battery.

(03) Check if the positive pole or negative pole is matched.

2 . Device can not be found by the BT.

(01) Check if the power supply is OK to the device.

(02) Restart the Bluetooth in the phone.

(03) Restart the APP.

(04) Restart the phone.

3 . Data transfer fail between the device and the phone.

(01) Restart the APP.

(02) Check if the APP is the latest version.

(03) Restart the phone.

(04) Change the battery.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Warranty card

Product name : _____ Model : _____

Name : _____

Contact phone number : _____

Address :

Distribution Company : _____

Contact Person : _____

Distribution company address: _____

Sales date: _____

The following circumstance does not belong to the warranty scope.

- 1.The damage of users using improper maintenance.
- 2.The damage is caused due to force majeure.
- 3.The company reserves the right to the cause of the problem to out products were identified and the interpretation of the above terms and conditions.