

English Manul of boAt Rugby :

Thank you for you chose our Stereo bluetooth speaker. In order to maintain good performance for this unit, please read this user manual carefully before using and make sure to use it in a proper way.

IMPORTANT SAFETY INSTRUCTION

Please protect the unit and accessories well. Please use them under the clean environment.

Do not expose the unit in the raining or moist environment.

Do not throw or trample the unit.

Do not use the unit near any heat source such as stove, radiators or any apparatus that can produce heat.

Please turn off the unit before cleaning it. Please clean the unit only by using the soft anti-static dry cloth.

When the unit is charging or under normal operation, it will become a little hotter, which is a normal phenomenon.

Please do not disassemble the unit and repair it by yourself.

FEATURES

Stereo bluetooth speaker..

Driver: 2pcs 2" full range drive and 1pc passive radiator.

Frequency Response : 60Hz~18kHz.

SNR: >65dB @1W; THD:<10% at the Max Volume; Loudness: SPL>75dB @1kHz sine wave.

Compatibility: works with most Bluetooth smartphones, tablets, music devices, Bluetooth 2.1 or above.

Internal rechargeable Li-ion battery, single fully charge with 6-hour operating lifetime.

Voice prompt for convenient feedback during Bluetooth Mode.


Phone holder function.

5V/1A battery charging

TECHNOLOGY SPECIFICATION

Driver Unit Size	2pcs 2" full range drive and 1pc passive radiator.
System Frequency:	60Hz~18kHz.
S/N Ratio	65dB @1W;
T.H.D.:	THD:<10% at the Max Volume
Supply power	Macro USB Charging

Operation Instructions:



1. Aux-in slot
2. DC-IN 5V/1A
3. Microphone
4. Power on/off
5. volume down
6. Short pressing for Play/Pause,
7. volume up
8. Mode indication Led

Charging Led Indication

Light Indication:

Charging LED, charging---solid red, fully charged-LED off

Mode LED

Bluetooth mode, pairing-- blue fast flashing, paired and connected--blue slow flashing

AUX-in mode, solid red

Voice Prompt (for Bluetooth mode only):

1. power on-----“Ready”
2. pairing-----“Discovering”
3. paired and connected----“pairing successful”

e) Hand free function.

1. When there's an incoming call, short press handfree button to answer, when you want to hang up the call please short press the handfree button.
2. When there's an incoming call, you do not want to answer it, just long press the handfree button to reject it.

BLUETOOTH

Power on the unit, it will enter into the Bluetooth status. And then please open the Bluetooth function on your mobile phone, it will begin to search for the Bluetooth device. This unit's Bluetooth name is “boat Rugby”. Connect it, finally your phone will match with this unit successfully.

AUX IN

When the unit is ON, and also it was connected with other audio service by AUX cable at the same time, it will enter into the AUX mode.

CHARGING

Connect the mini speaker to a 5V USB charger by using the USB cable (included with the package) or connect to a PC/laptop. The battery can be fully charged by 4hours.

TROUBLE SHOOTING

Problem	Possible cause	Suggested solution
No sound	Battery empty	Charge the battery
	Audio input cable loose	Check connections and insert fully into slots/jacks
	Audio input damaged	Call local support center
Weak sound	Low battery	Recharge the battery
Sound is distorted	Low battery	Recharge the battery
	Poor song quality	Check song quality

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.