

1 EUT Internal Antenna Variant



EUT Internal View


2 External Antenna Variant



EUT Internal View of External Antenna Variant




RPSMA Connector used for External Antenna Variant




U.F.L to RPSMA of External Antenna

3 EUT Overall Internal View



EUT Overall Internal View



Internal PCB Front View



Internal PCB Rear View

Note: The samples used for the appendix are only for the reference.