

Brookstone®

Wireless Sport Earbuds

WITH LIGHT UP NECKBAND



FCC INFORMATION

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.
2. This equipment must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2AFVN-AR115A3XX

CAUTION

- Listening to audio at a high volume may affect your hearing.
- Prolonged use may cause discomfort. If you experience discomfort, remove the earbuds.
- Do not drop, crush, bend or apply excessive force to the device.
- Do not expose the device to moisture, extreme or prolonged heat, cold, humidity, or other adverse conditions. Avoid storage in damp, humid or wet locations.
- The unit can only be opened by qualified personnel.

LITHIUM-ION BATTERY WARNING

This device contains a rechargeable Lithium-Ion battery. The battery must be recycled or disposed of properly. Contact your local waste management office for information on battery recycling or disposal.


Use only the supplied cable to recharge the battery. Improper charging may damage the battery and the device.

Do not attempt to open the rechargeable battery or battery pack. There are no serviceable parts inside.

Keep the battery out of reach of children. If swallowed, consult a physician immediately.

Do not dispose of battery in a fire as it may explode. Battery may also explode if damaged. 

LOCATION OF PARTS AND CONTROLS



CHARGING THE BATTERY

Charge the battery before first use.

If the earbuds are not used for a long period of time, the battery may require recharging.

To charge the battery:

1. Plug the charging cable's USB connector into a USB port on an active device.
2. Plug the charging cable's Micro USB connector into the Micro USB port on the right earbud. The LED Indicator turns red during charging. The indicator turns off when the earbuds are fully charged.

The earbuds are automatically powered off during charging.

PAIRING WITH BLUETOOTH®

1. Prepare your device (e.g., smartphone) to pair using Bluetooth®, making sure that the device is within 33 feet of the earbuds. Refer to your device's owner's manual for information on using the Bluetooth® function.
2. With the earbuds powered off, press and hold the Multi-Function Button until the LED Indicator quick flashes blue and red alternately, indicating that the earbuds are in pairing mode.
3. On your device, search the list of available devices and select FREELY. Note that it may take a few seconds for the earbuds to be listed as an available device. Depending on your device, you may have to tap SCAN to update the device list. Consult your device's owner's manual.
4. If prompted, type the password or PIN 0000.

The earbud's LED Indicator will double-flash blue at 3 second intervals, indicating that the device is paired.

The devices will remain paired, even after being turned off, until you cancel the pairing. Consult your device's owner's manual for information on cancelling pairing.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Brookstone is under license.