



TrueBuds

Bluetooth Wireless Earbuds



CC-TWS-CC1

Operation Manual

Please read the manual before operating this product

M&S Accessory Network declares that radio equipment CC-TWS-CC1 is in compliance with Directive 2014/53/EU.

The EU Declaration of conformity is available at <https://gabbagoods.com/pages/compliance-documents>

Contents

- Introduction
- Package contents
- Turning On/Off Pairing
- TrueBud Touch Functions
- TrueBud Touch Functions Cont.
- Charging
- Specifications
- Support

Compatible with all Bluetooth enabled devices.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc.



COCA-COLA, COKE, the Contour Bottle Design, the Dynamic Ribbon Device and the Red Disc Icon are trademarks of The Coca-Cola Company and, in Canada, Coca-Cola Ltd. ©The Coca-Cola Company. All rights reserved. Produced by M&S Accessory Network Corp. under a trademark license from The Coca-Cola Company.


Introduction

Thank you for purchasing these Coca-Cola True Wireless Earbuds (TrueBuds). To get the best use of this item, please read the user manual to make yourself familiar with the features and functions.

Safety Rules

1. Please follow the rules depicted in this manual closely to ensure your safety. Before using the product, we would strongly encourage you to read through this user manual.
2. Be wary of any edges, uneven surfaces, metal parts, accessories and its packaging to prevent any possible injury or damage.
3. Do not modify, repair, or dismantle the product. Doing so may result in fire, electric shock, complete breakdown of the product, etc. All of which are not covered under warranty.
4. Do not use any diluent or volatile liquid to clean the product.
5. Do not use the product in a hazardous location

Package Contents



Turning ON/OFF & Pairing

To turn ON
The TrueBuds will be on when they are removed from the charging case. You can also press and touch the TrueBuds for 2 seconds to power them on.

To turn OFF
Place TrueBuds back into the charging case and close the top. You can also press and touch the TrueBuds for 4 seconds to power them off.

To Pair TrueBuds
When you remove the TrueBuds from the charging case they will automatically pair to each other and you will hear a voice prompt “bt pairing mode”. Now they are ready to be paired with your device.

Open the Bluetooth function on your smart device and make sure the Bluetooth settings are turned on. In the list of discovered devices you will see: “Coca-Cola TrueBuds”. Tap or select it to connect. Once connected the blue LED light will start to flash very slowly.

Once the TrueBuds are successfully paired for the first time, they will automatically connect to your device whenever they are in range.

FCC Compliance Statements

FCC ID:2AFX-TWS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

TrueBud Touch Functions

Touch Control	Left TrueBud	Right TrueBud
2 Second Touch	Power On	Power On
4 Second Touch	Power Off	Power Off
Single Touch	Play / Pause Answer / End a Call	Play / Pause Answer / End a Call
1 Second Touch	To go back to the previous track	To skip to the next track
Double Touch	To reduce music volume	To increase music volume
Long Touch	Reject an incoming call	Reject an incoming call
Triple Touch	SURI	Redial

You can use your smart device to control the volume of your TrueBuds

Charging

Place the TrueBuds into the charging case and use the supplied charging cable in order to start charging. Plug the Type C end into the charging port on the case and plug the USB end to a PC or Wall Adapter to start charging.

While charging the Charging Case the LED light will flash red and the LED light will stay red once fully charged. While charging the TrueBuds the LED light will turn red and the LED light will power off once fully charged.

*Before initial use it is recommended to charge TrueBuds for a minimum of 3 hours.



Specifications

Product: Bluetooth Wireless Earbuds
Bluetooth Version: 5.3
Bluetooth Range: 10 meters
Playback Time: 7 Hours
Charging Time: 2 Hour
Standby Time: 100 Hours



Support

If you have problems with your device, please consult the instructions in this manual.

Manufacturer Warranty
We stand by our products! That's why we guarantee them from any functional defects for one year from the original date of purchase. Should you have an issue please call us at (877)995-8505 or email us at info@mnsbrands.com

CC-TWS-CC1
Manufactured, marketed, and distributed Under License by M&S Accessory Network Corp., 10 W. 33rd St., New York, NY 10001
Designed in the U.S.A | Made in China.
For support call: (877) 995-8505 or Email: info@mnsbrands.com

