

Mi A1

The diagram illustrates the Mi A1 smartphone. The front view shows a white bezel with a large screen displaying the time '02:00' and the date 'Saturday, August 16'. Below the screen are three capacitive touch buttons: a circular 'Menu Button' on the left, a central 'Home Button' with an orange dot, and a circular 'Back Button' on the right. A 'USB Type-C Port' is located at the bottom center. The side view shows the 'Volume Buttons' (a small circular button and a larger rectangular button) and the 'Power Button' (a rectangular button) on the right edge.

Thank you for choosing **Mi A1**

Long press the power button to turn on the device.
Follow the on-screen instructions to configure the device.

For more information

Visit our official website: www.mi.com

Android One

With software designed by Google, Android One phones have access to Google's premiere security features, applications and innovations on your phone, such as free unlimited high quality storage with Google Photos.

SIM Card Tray:

- Tray 1 supports Nano-SIM card;
- Tray 2 supports Nano-SIM card/Micro SD card.

The diagram shows two SIM card trays. Tray 1 is labeled 'Nano-SIM'. Tray 2 is labeled 'Nano-SIM' and 'Micro SD'.

About Dual SIM:

When 2 SIM cards are in use, one SIM will offer 4G/3G/2G while the other will offer only 3G/2G.

Important Safety Information

Model: MDG2

SAR 10g limit: 2.0 W/Kg, SAR Value: Head:1.75 W/Kg, Body: 0.76 W/Kg (MAX, 5mm distance).
SAR 1g limit: 1.6 W/Kg, SAR Value: Head: 1.00 W/Kg, Body-worn: 0.29 W/Kg (MAX, 10 mm distance).
Hotspot: 0.29 W/Kg (MAX, 10 mm distance).

Temperature: 0°C—40°C

Install the adapter near the device in an easily accessible position.

androidone

androidone

androidone