

LIT PARTY INSTRUCTION MANUAL

DO NOT PRINT THIS LAYER

PRINT BACK TO BACK

FRONT

BACK



BLUETOOTH PAIRING YOUR SPEAKER

- 1 Turn On your Speaker.**
Your Lit Speaker will be on Bluetooth Mode when powered on. You'll hear an automated voice saying "Bluetooth Mode".
- 2 Search pairing name "iHip LIT Speaker" in your device and pair it.**

When successfully paired, an automated voice will say "connected".

TWS FUNCTION

- 1** Long press the "MODE" button of two speakers at the same time to pair with each other.
- 2** Search pairing name "iHip LIT Speaker" in your device and pair it.

When successfully paired, an automated voice will say "connected".

FM MODE

▶▶/SCAN

Long press to automatically search the channels.
Short press to start/pause.

CHARGING YOUR SPEAKER

When the battery is low there will be a voice message "Low battery, please charge."
When charging, the LED indicator will show a RED light and will turn off when fully charged.

Package Includes: 1- Speaker, 1-User Manual, 1-Charging Cable



Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

SPECIFICATIONS

- Bluetooth Version: V5.0
- Bluetooth range: Up to 33ft
- Battery: 500mah rechargeable battery
- Input: DC 5V / 0.4A
- Speaker output: 1x5W
- Play time: about 2 hours at 100% phone volume; about 6 hours at 50% phone volume.
- Charging time: about 2 hours
- Cable included: 19.6in USB charging & 3.5mm auxiliary 2 in 1 cable

1 Power Button

On: Slide the "ON/OFF" Switch to the ON position.
Off: Slide the "ON/OFF" Switch to the OFF position.

2 Speaker Controls

◀◀/V-

Short press to previous song // Long press to decrease the volume.

▶▶/V+

Short press to next song // Long press to increase the volume.
There will be a tone when maximum volume is reached.

▶▶/SCAN

Short press to start/pause music.

MODE

Short press the "MODE" button to switch the mode.

3 Mic Port *

For Karaoke Mode, plug in a 6.5mm jack microphone in Mic slot.
*(Not included in the product)

4 DC/5V AUX Port

Using the 2-in-1 cable included in your package, connect the micro-USB end to the DC/5V AUX Port of the speaker and connect the AUX end to your device.

5 SD Card Mode

Plug in the SD card into the TF slot.

6 USB Port

Plug in the USB into the USB slot

7 Phone Stand



© 2020 Zeikos, Inc. iHip is a trademark of Zeikos, Inc., iPod, iPhone and iPad are trademarks of Apple Inc., The "Android" name, the Android logo, and other trademarks are property of Google LLC, Registered in the U.S. and other countries. The illustrated product and specifications may differ slightly from that supplied. All other trademarks and trade names are those of their respective owners. United States and international patent pending. All Rights Reserved. For ages 12+up. This is not a toy. Designed by iHip, Manufactured in China.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by "iHip" is under license. Other trademarks and trade names are those of their respective owners.

Limited One Time Warranty.

To activate your product warranty go to our website.
www.iHip.com & register this product.

Supplier's Declaration of Conformity
47 CFR § 2.1077 Compliance Information
Unique Identifier Trade Name: iHip, Model No.: CVS-12
Responsible Party – U.S. Contact Information



19 Progress St
Edison, NJ 08820
www.iHip.com



#iHip



Find us on Facebook.
Keyword: iHip: Portable
Entertainment

10" inches

3.15" inches