

NOVA HEADPHONES INSTRUCTION MANUAL

DO NOT PRINT THIS LAYER

PRINT BACK TO BACK

FRONT

BACK



Instructions Manual

BLUETOOTH PAIRING YOUR HEADPHONES

- 1
- Turn On your Headphones.
- Long Press (3 seconds) the Multi-function button
- You'll hear an automated voice saying "Power on"
- A blue light will flash 3 times to indicate that the headphones are on.

*It will be on Bluetooth Mode by default when powered on.
An automated voice will say "Bluetooth Mode"
The LED light will flash blue and red*

- 2
- Search pairing name "iHip Nova Headphones" in your device and pair it.

*When successfully paired,
an automated voice will say "connected",
the LED light will slowly flash blue.*

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
- FCC Radiation Exposure Statement
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.



© 2020 Zeikos, Inc. iHip is a trademark of Zeikos, Inc., iPod, iPhone and iPad are trademarks of Apple Inc., The "Android" name, the Android logo, and other trademarks are property of Google LLC. , Registered in the U.S. and other countries. The illustrated product and specifications may differ slightly from that supplied. All other trademarks and trade names are those of their respective owners. United States and international patent pending. All Rights Reserved. For ages 12+up. This is not a toy. Designed by iHip, Manufactured in China.
The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by "iHip" is under license. Other trademarks and trade names are those of their respective owners.
Limited One Time Warranty.

To activate your product warranty go to our website.
www.iHip.com & register this product.

iHip

19 Progress St
Edison, NJ 08820
www.iHip.com

#iHip

Find us on Facebook.
Keyword: iHip: Portable
Entertainment

SPECIFICATIONS

- Bluetooth Version: V5.0
- Bluetooth Range: Up to 33ft
- Frequency: 20Hz-20KHz
- Battery: 3.7V/200mah
- Input: DC 5V / 0.1A
- Play Time: about 6 hours
 (at 100% volume)
- Charging Time: about 2.5 hours

CHARGING YOUR HEADPHONES

- When the battery is low:
 An automated voice will say "Low battery, please charge"
 The headphones will power off
- Plug in the charging cable included to the micro usb charging port.
 The LED light will be RED when charging.

The LED light will turn blue when fully charged.

POWER OFF

- Long press (3 seconds) the Multi-function button, an automated voice will say "Power off", the LED indicator light will turn red and flash 3 time.
- The headphones will automatically power off if not connected to a device within 5 minutes.

FM MODE

- ▶|| (multifunction)
Short press to start/pause automatically searching the channels
Short press to previous channel // Long press to decrease the volume.
- +
- Short press to next channel // Long press to increase the volume.
There will be a tone when maximum volume is reached.

Package Includes: (1) 7.5" Wireless Headphones,
(1) User Manual, (1) 19" Charging Cable, (1) 39" Aux Cable.

LEFT SIDE



- 1 SD Card Mode
Insert the SD card into the TF slot.
- 2 Controls
Short press to previous song // Long press to decrease the volume.
+
Short press to next song // Long press to increase the volume.
There will be a tone when maximum volume is reached.
▶|| (multifunction)
Short press to start/pause music.
Short press to answer the incoming call.
Long press to reject the incoming call.
Double click to redial the last phone number called.
1.5 seconds long press to switch the Mode.
- 3 Micro-USB Charging Port
- 4 AUX IN
The headphones will power off when plugged in to the AUX cable.
- 5 LED Light Indicator
- 6 Mic