
POWER BOAT

Bluetooth Earphone

BT565T

ClickTantra ClickTantra.com

Product Details



After use of headset in sweat, please wait for upto 5 minutes before putting the device on charging.

In The Box

1. Power Boat Wireless Headset
2. USB Charging Cable
3. Starter Kit

Getting Started

Fully charge the headset before use. The Red LED will show while charging, and will turn Blue once fully charged. Charging time is approximately 2 hours. Always use good quality AC 5V Power Adapter to charge the headset. Using any incorrect power supply device may cause damage and void the warranty. Do not put and leave the headset in charging mode after fully charge, it may shorten the life of the battery inside.

Turning On/Off

1. Press and hold the Multi-Function Button for 5 seconds to turn it on. Blue and Red LED will start flashing alternatively.
2. Press and hold the Multi-Function Button for 4 seconds to turn it off. Red LED will flash for 3 seconds.

Bluetooth Pairing

1. Turn On the headset.
2. Activate the bluetooth function of your device and search for available devices.
3. Select "Tantra Power Boat" from the list of available devices and connect. LED indicator will turn Blue once connected.

Connectivity Issue

1. Enter passcode "0000" if your phone prompts for a passcode.
2. If pairing fails, restart your phone and remove all the excessive unused names from the list of paired devices in your phone.
3. If "Tantra Power Boat" is already showing in "My Devices" or "Paired Devices" in your mobile phone, click on setting icon next to it, select "Forget This Device" or "Unpair".
4. To factory reset Tantra Power Boat, press and hold both, Volume "+" and "—" buttons together for 10 seconds.

Managing Phone Call

Answering a call
Short press Multi-Function Button to answer an incoming call.

Rejecting a call
Press and hold Multi-Function Button for 2 seconds to reject an incoming call.

Ending a call
Short press Multi-Function Button to end the call.

Re-dialing a call
Double press Multi-Function Button to redial the last dialed number.

Mute a call
When on call, press Volume + and — buttons together to mute. Repeat to un-mute.

Controlling Music

Previous Track
Press and hold the Volume — button.

Next Track
Press and hold the Volume + button.

Adjust Volume
Short press Volume + button to increase and Volume — to decrease the volume.

Play/Pause Music
Once connected, short press Multi-Function Button to play or pause music.

Voice Command

When connected, long press Multi-Function Button to activate voice prompt command of your smart phone.

LED Indication

Power on	Blue & Red (Flash Alternately)
Power off	Red LED for 3 Seconds
Charging	Solid Red LED
Full charged	Solid Blue LED
Pairing	Blue & Red (Flash Alternately)
Connected	Blue LED (Slow Flash)
Low power	Red LED(Quick Flash)

Compatible With



Tantra Power Boat headset is compatible with Bluetooth enabled Mac and Windows computers without additional driver installations. Please perform the following steps in case of any problem:
1. Run Windows or Mac OS update to get the latest driver.
2. Install the latest drivers if using 3rd party Bluetooth receiver.
3. Check the Bluetooth settings and configurations.
4. Adjust the input and output sound sources to Tantra Power Boat.

Warranty

Tantra Power Boat comes with 1 year limited Hardware Warranty from the date of purchase. We have thoroughly tested the product in each testing category to meet the highest quality standards. In the unlikely case that the product proves to be defective, TANTRA will repair or replace the product free of charge. No warranty will be extended to any product damaged by misuse, natural disasters or any circumstances beyond TANTRA's control.

Support

For Support/Feedback contact:
Consumer Care Executive through-
Email: support@ClickTantra.com
Or Call at: 9999-363-373

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the
instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help
This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.