






Power Port	DC 5V±10%
Power on/off	Press the button for 3 seconds to turn on/off the camera
Status light	• Red light solids on: the camera network is abnormal • Red light blinks: awaiting WiFi connection, or currently connecting (faster blinking) • Blue light solids on: camera running correctly
SD card slot	Support local SD Card storage (Max.128G)
Reset	Press and hold on for 5 seconds to reset the camera
Charging indicator	• Red indicator solids on: battery is charging • Blue indicator solids on: charging completed
Battery capacity	6700mAh (Two 18650 lithium-ion batteries)

Mode 1 Bottom Bracket Installation



1. Fix the bracket to the wall with the mounting screws
2. Install the camera in the bracket and lock it with the screw

Mode 2 Side Bracket Installation



1. Fix the mounting bracket in the angle wall mount
2. Fix the angle wall mount to the wall
3. Install the camera in the bracket and lock it with the screw