

Attachment 1

➤ Test Setup Photograph

<Conducted Emission>

Test Mode : Mode 1: Transmit (Power by Adapter)

Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 1: Transmit (Power by Adapter)

Description : Back View of Conducted Emission Test Setup



Test Mode : Mode 2: Transmit (Power by Notebook PC)
Description : Front View of Conducted Emission Test Setup



Test Mode : Mode 2: Transmit (Power by Notebook PC)
Description : Back View of Conducted Emission Test Setup



<Radiated Emission>


Test Mode : Mode 1: Transmit (Power by Adapter)

Description : Front View of Radiated Emission Test Setup (Bi-Log)



Test Mode : Mode 1: Transmit (Power by Adapter)

Description : Back View of Radiated Emission Test Setup (Bi-Log)




Test Mode : Mode 2: Transmit (Power by Notebook PC)

Description : Front View of Radiated Emission Test Setup (Bi-Log)



Test Mode : Mode 2: Transmit (Power by Notebook PC)

Description : Back View of Radiated Emission Test Setup (Bi-Log)



Test Mode : Mode 1: Transmit (Power by Adapter)
Description : Front View of Radiated Emission Test Setup (Horn)



Test Mode : Mode 1: Transmit (Power by Adapter)
Description : Back View of Radiated Emission Test Setup (Horn)

