

User Manual

Model:FX1.8

Brand:EKS

Thank you for purchasing this mobile. For the best performance, we recommend that you read the manual carefully.

CALL LOGS	3
PHONEBOOK	5
PROFILES	6
MULTIMEDIA.....	8
MESSAGE	10
GAMES.....	14
TOOLS.....	15
INTERNET	18

SETTINGS	19
----------------	----

Call logs

You can view your recent call situation.

[Missed calls]: Show all missed calls list, select a view after a missed call occurred the date and time, phone number and times.

[Dialed calls]: Show all dialed calls list, select a view after a dialed calls occurred in the date and time, phone number and times.

[Received calls]: Show all answered the phone list, select a view after a phone that has the date and time of occurrence, telephone number, frequency

[Rejected calls]: Show all refused to answer the phone list, select a view after a missed call occurred the date and time, phone number and times.

Press the OK softkey to enter the options menu can be more than the number of call records in the following:

-
- Details: View the current record date, time, type.
 - Call: Call the current number
 - Save: You can save the current record to the phone or

SIM card

- Write message: send the current record of SMS
- Add to contacts: the number of the record the name

added to the existing record which

- Add to blacklist: the current record to reject a call which

Delete: Delete the currently selected record

- Delete all: Delete all call records
- Mark: Mark to operation

[Delete all]: Delete all call records

[Call times]: Last time zero starting time for last call statistics, a total of dialed calls, received calls, all calls total, all the time can also be zero.

[GPRS counter]: Display the SIM card GPRS data.

Phonebook

You have phonebooks in this mobile phone: SIM card and the mobile. The mobile can store 500 phone numbers and the SIM card's capacity depends on its type.

In standby mode, enter a number, press the call key pieces to make a call, press the OK key to save

- If 'To SIM' is selected, users can edit name and number.
- If 'To phone' is selected, the user can edit the name, mobile number, image, ringtone, caller groups

Into the phone book list, the list on the left displays a small icon indicates that the record exists SIM card or mobile phone, the right is the record of the name and number information.

Standby mode, press the right soft key to enter into the

address book or from the menu

Into the address book, do the following:

[New]: Create a record to phone or SIM

[Delete multiple]: Choose one or more records to delete

[Import/Export]: Copy/Import/Export records to T-Card or phone

[Others]

[Memory status]: Query the current SIM card and mobile phone storage capacity.

Profiles

[Add]: Add the new profile

[Delete]: Delete the profile

[Settings]: set the selected mode

[Rename]: Rename the profile

[Ring settings]

- SIM call ring: set the SIM card of the ringing tone

-
- SIM message ring: set the SIM card message tone

[Adjust volume]

- Caller ringtone: set the ringing tone volume
- Message ringtone: ring volume settings information
- Alarm & calendar volume; set the alarm tone
- Call volume: Set the volume of calls
- Power ringtone: the voice of setting switch

[Ring type]

- Call alert: a ring, vibration, silent, vibration and ringing and ringing after the first five vibration incoming call alert for you to choose
- Message alert: a ring, vibration, silent, ringing and message alert vibration four ways for you to choose
- Alarm & calendar remind: a ring, vibration, silent, ringing and message alert vibration four ways for you to choose

[Other alert rings]

- Key tone: set the key tone of voice
- Battery low alert: Choose open the alert of battery low
- Power ringtone: Set the sound is turned Off
- Dial tone: Activate dial tone

Multimedia

Image viewer

View the image which in phone memory or T-card

Video palyer

Use the function of video player

Music

Play audio files, MP3 songs; to play audio files, MP3 songs, press the Up and Down keys to adjust the volume, press the left and right keys to select the present, the next song, press the OK button for the on / off Music

[Music list]: Into playlist interface. Can be added to the play

list editing and other operations

[Add]: Add songs or music playlist bookmark

[Set as ringtone]: The song is set to call or alarm tone

[Repeat]: Choose one/all repeat

[Shuffle]: Choose shuffle to play the music

[Settings]:

- Equalizer: Choose a variety of equalizer effects
- BT stereo output: Set the BT output
- BT stereo headset: Set the BT headset

[Open review]: Open the function of review

[Exit]: Exit menu audio player

Recorder

[Start recording]: Start recording

[Record file list]: The memory card inside the recording file list

[Storage]: Set the locate of storage

[File format]: Set the format of record file

FM radio

[Auto search and save]: Channel auto search and save

[Channel list]: View channel list

[Save]: Save the channel to the channel list

[Manual search]: Manually enter the channel and find

[Open speaker]: Choose whether to open the microphone

[Background play]: Choose whether to open the Background Play

[Record]: Record the FM

[Timing record]: Set the time to record

[Record file list]: The list of FM record file

[Storage]: Set the location of storage

[Help]: FM Help

Message

The Messaging function is a network service. Sending and

receiving Text can only be used if the service is proposed by your network operator.

You can send ordinary Text messages. The SMS is sent to the Text messages center in the network firstly, and then to the target user. If the receiver's mobile is power off or cannot receive messages, the network will store the message temporarily and the store duration is determined by the user configuration and the service provider. I

The message will be directly stored in the SIM card if the capacity is not full. A blinking icon at the head row of the main screen will be displayed if the capacity is full.

Messages unread

If the Text message has been sent to the receiver, a beep will sound. (If the tone for Text messages and message report are activated).

Write message

[New SMS]

- Send: Enter the appropriate number of the recipient or from the phonebook add
- Insert template: to the content of the message currently being edited into the common language
- Add contact info: Insert the contact person
- Add phiz: emoticons into the meaning of the representative
- Save as draft: will save the information to Drafts
- Exit: Exit message

Inbox

- Reply: reply to SMS to each other.
- Delete: Delete short message
- Call: choose a voice call or a call to the sender IP calls
- Lock: lock cannot be deleted
- Move: Move the message to SIM or phone

-
- Copy: Copy the message to SIM or phone
 - Mark: single marker or markers in whole or in text messages stored in SIM, mark or unmark after delete records
 - Sort: In accordance with time / contact / theme / message type sort
 - Add sender to: add to new contact or add to existed contact.
 - Delete repeated number: choose to delete the same number of records.
 - Add to blacklist: Add the sender to blacklist

Outbox

Reading or processing stored in the Outbox of the SIM card message.

Drafts

Reading or processing stored in the Drafts of the SIM card

message

Sentbox

Read and process the mail stored in the SIM card has been sent information

Security inbox

View the message which is locked

Templates

Use the function of templates

Broadcast message

Use the function of broadcast message

Voice mail server

use the function of voice mail server

Games

Tetris

Provide the tetris game

Tools

My Files

[MemoryCard]: SD card needs to support T card

[New folder]: Create a new folder.

[Delete]: delete the specified folder.

[Details]: View the folder or file for more information

[Edit]: the selected folder or rename the file or copy

[Search]: Enter the folder name to find out.

[Sort]: By the way you choose to sort the files.

[Mark]: Select Mark / Unmark single / all

[More]

- Memory Card capacity: View the memory card capacity
- Format MemoryCard: Format memory card

Alarm

This machine has three alarm times available for your settings. Access any time, you can set its status to on / off,

ring time, repeat mode, ring tones, alarm clock name, etc.

Calculator

Can be continuously mixed arithmetic, the operation is simple, practical, convenient

Calendar

Press the left soft key to access the calendar display interface, the first line shows the year, month, and the third line shows the week, the middle section shows the specific date of a month, the last line shows the right and left soft key in the message. Interface in the calendar, press the arrow keys on the date forward one week, press the arrow keys to move one week after the date, press the left arrow key date forward one day, press the right arrow keys to move the day after the date, select the date to a dark display

[Add new schedule]: a new agenda

[View schedule]: View the schedule one day save

[All schedule]: View the schedule all day

[Clear tasks today]: Clear the calendar day

[Clear all]: Empty all the schedules

[Go to date]: Enter the dates you want to find, the cursor will jump to that date quickly

[Weekly]: the week / month display calendar.

World clock

View the time of countries

Ebook

View the “txt” document

Bluetooth

[Open Bluetooth]: Choose to activate the Bluetooth

[Bluetooth visibility]: Bluetooth visibility set

[Paired device]: Search and paired Bluetooth devices

[Device name]: Local Bluetooth name

[Bluetooth file storage]: Storage location

[Help]: : Help Documentation

Torch light

Choose to open the torch

STK

Full name of the SIM card application tool kit (SIM Application Tool kit). It can provide you with flexible information functions, such as stock information, traffic information, weather and so on. STK functionality provided by the network operator decision. The business needs the support of SIM cards and network

Internet

Use the function of internet

[**Bookmark**]: Website of interest can be saved in the bookmarks and the bookmarks can be edited or direct them to surf.

[**History**]: Mobile recently logged in the menu page is saved,

you can directly select the records inside the surf

[Offline pages]: Throughout the course of mobile browsing, save the snapshot shown here

[Homepage]: Open the home page

[Settings]: Set account/homepage/content/restore default

[Exit]: Exit browser

Settings

Call setting

[Call divert]: SIM Call Transfer

- Call forwarding unconditional: Set a forwarding number, for forwarding all calls are.
- Call forwarding on busy: set the forwarding number, transfer calls when in busy
- Call forwarding on no reply: Set a forwarding number, in case of no response transfer

- Diver if unreachable: to set the forwarding number in the phone unable to connect the case of transfer

- Cancel all diverts: cancel all of the transfer

[**Call waiting**]: Open the SIM call waiting

[**Call barred**]: SIM Call Barring

[**Hide ID**]:SIM to hide the machine when the power numbers.

*** SIM card, operators need to support**

[**Others**]:

[IP prefix]: select IP prefix

[Call time minute reminder]: Select the open or closed during a voice call has prompted

[Auto redial]: Select whether to open automatically redial function

[Vibration when connected]: Select the phone is turned on or off the tone when

[Reply SMS after reject]: Select whether to reject messages

or return after any key answer

[Flight mode]: Manually open the flight mode

[Flight mode—select when power on]: Each boot will be asked whether to open flight mode

[Auto record voice call]: Auto record the voice call

Phone settings

[Date & time]

- Set time: set the phone to display the time
- Set date: set the phone to display the date
- Time format: Set the display time format
- Date format: Set the date display format
- Update time settings: Select open update time

[Language settings]: Select phone display language.

[Shortcut settings]: Set the function of shortcut

[Auto power on/off]: Set the time and frequency of Automatic Turning

[Restore factory settings]: restore the factory settings

Display

[Wallpaper settings]: Set wallpaper

[Idle display setting]: Set the idle

[Contrast]: adjust the screen's backlight brightness

[Display sleep]: Set the time of display light

[Keypad backlight time]: Set the backlight time key

Connections

[Network account]: Create or edit the network account

[New connection]: Create a new Internet account

[Add from list]: from the system built-in Internet account to add a new account

[Search]: from the current logged on to Internet search to the card account information, which added to the list after the selected

[Delete]: delete the selected account

[Edit]: edit the currently selected account

[**GPRS service**]: Choose open or close GPRS service

[**Data connection settings**]: The type of data connection

[**Network selection**]: Choose auto or manual select network

Use the effect for menu list

Security

[**PIN**]: Select open or modify the phone's PIN code

[**Modify PIN2**]: PIN2 choose to modify the phone code

[**Phone locked**]: Set the phone locked

[**Modify the cellphone password**]: Modify the password of phone

[**Privacy**]: set access to enter the password to view functionality. (Including: call logs / message / camera / phonebook / my files / ebook / calendar / U disk/audio player/video player)

[**Auto keypad lock**]: Set the auto keypad lock

[Lock screen by end-key]: press the end key to select whether the off-screen function

[Guardlock]: To set the security password and open the feature, open the opportunity for the card and then prompts for security password, if the wrong password is entered three times, the phone can receive within 24 hours of alarm information

[Fixed dialing]: Set the fixed dialing function

[Blacklist]: Set the blacklist with call or message

FCC Warning

This device complies with part 15 of the FCC Rules.

Operation is subject to the condition that this device does not cause harmful interference.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular

installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- ▶ -Reorient or relocate the receiving antenna.
- ▶ -Increase the separation between the equipment and receiver.
- ▶ -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- ▶ -Consult the dealer or an experienced radio/TV technician for help.

This Smartphone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety

margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: FX1.8 (FCC ID: 2AGAK-FX18) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use at the ear is 0.299W/kg and when properly worn on the body is 0.458W/kg. This device was tested for typical body-worn operations with the back of the handset kept 1.0cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.0cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.0 cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.