



# Smart Glasses

Patented Product  
Counterfeiting not allowed  
5V Special




- 1.The glasses with a camera to take video and photo anywhere anytime,record every moment in your life in a easy way.Drop your heavy camera away from now on.
- 2.Wireless control via the APP ,to pre-view the recording files at real time, download the video/photo to your smart phone.

## Part Name



## Function Instructions



## Method of use

- Long press the power button for 3 seconds to turn on,RED and BLUE light flash,then come to solid BLUE,the device is in stand by mode.
- Double short press to take one pictures,the blue light flash one time for one picture.
- Short press to take video,the Blue light flash intermittently.  
Notes: ONE Button for TURN ON,VIDEO,PHOTO
- The video resolution is 1080P,can select 720P via APP
- To turn on the glasses first,connect to your computer with USB cable.the device will on USB mode and can used as flash card.Do not forget to turn on the device first.
- Turn on the video and connect to your computer,(means under the mode of USB),short press the first button,the mass storage device disappear,it can be used as Webcam now.
- Connect with USB cable to charge the device,the indicator is solid RED.and dies after full of charge. Suggest to use 5V cable to charge in case any damage to the device
- APP:** Download the APP on your smart phone according to your **Android/IOS** system  
**APP name:** lsmart DV  
**APP control:**
  - 1.Under the stand by mode(turn on the device),short press the Wifi button,green light flash.
  - 2.Connect the device with your smart phone .After connecting successful,the green light stop flashing.  
**Wifi name: SG2**  
**Password: 1234567890**
  3. Then you can use the APP to control,video recording and take pictures,pre-view the video recording .  
You can also download the recording files to your smart phone to share with your friends easily.

## Safe use items



- 1.The product is the standard 5V,can not use any charger above 5V to avoid the damage of the device.
- 2.Suggest full charge for the first time.be careful not to charge in high temperature or humid place
- 3.Turn off the device and well package when do not sue it.Put it in the dry and no dust condition.Do not expose in liquid or high moist condition.Also put away from high temperature and fire to avoid explosion and extremely cold.
- 4.Please do not use abrasive solvent to clean glasses,and do not use sharp objects to scratch glasses to avoid the damage
- 5.Please clean the product with specially glasses cloth after sweating.do not expose the glasses in the very high temperature long time to avoid the explosion.
- 6.Please do not dis-assembly the digital part as the device contains many components that may can not repair,and will cause the damage easily.
- 7.Please do not let children to play the glasses in case dangerous for small component.
- 8.The device will cover the former file with new one when the memory card gets no enough space.Please download and save the video and image to your computer in time to avoid any missing.
- 9.Please to specialized accessories such as charging cable.the un-specialized damage the device.Please use the product safely.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
Reorient or relocate the receiving antenna.  
Increase the separation between the equipment and receiver.  
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

## Guarantee of quality

|             |               |                   |  |
|-------------|---------------|-------------------|--|
| information | Type no.      | One year warranty |  |
|             | Order no.     |                   |  |
|             | Client phone  |                   |  |
|             | Purchase date |                   |  |
| signature   |               | Seller Stamp      |  |

1. This product is under the normal use of the free maintenance for one year since the acquisition date
2. More than the warranty period will charge for replacement of spare parts, maintenance fee;
3. During the warranty period, the below situations are not free repair:
  - A. failed to present the warranty card or purchase document (invoice or receipt)
  - B. for disassembling or damage of transformation;
  - C. because of the wrong use improper use or man-made damage;
  - D. in abnormal use environmental damages to the bad place;
  - E. look old scratch etc.

The pictures in this instruction brochure are for reference only, pls take the fianl object as the standard.