


X01
AI Glasses

AI Glasses

User's Manual
(English)

Appearance



Power Switch (Below Left Temple)
Slide forward to power on;
Slide backward to power off.

Button Functions (Above Right Temple)
A: Short press to take a photo;
B: Quickly double-press to start video recording; press once more during recording to stop;
C: Press and hold for 3 seconds to start recording audio. Press once during recording to stop.
D: During an incoming call, press once to answer / press and hold for 2 seconds to reject.
E: During an active call, press to end the current call.
F: Press and hold for 10 seconds to reset the product to factory settings (this will erase all saved data).

Touch Area (Outer Side of Right Temple)
A: During music playback, double-tap the touch area to start/pause music;
B: During music playback, triple-tap the touch area to skip to the next track;
C: Press and hold the touch area to activate the AI voice assistant;
D: During music playback or calls, swipe forward along the touch area to increase volume; swipe backward to decrease volume.

Red Light: Battery indicator. One red light indicates battery level within the 25% range. For example, if the current battery level is 75%, four lights will still be displayed; at 74% battery, three lights will be displayed.
Blue Light: Flashes when powered on but not connected. Turns off once connected.

Connection instructions

1. This smart glasses is a stand-alone product, many functions must be connected with the cell phone before use.
2. You can search “HeyCyan” in Google Play or iPhone App Store, download and install it to your cell phone.
3. You can also scan the QR code and select the corresponding system version to download.



- Open the installed app and follow the instructions to complete the registration;
- Select [Home] and click [Connect Device];
- Select the name of the searched device [X01];
- When you hear the ding-dong sound, the connection is successful.

Warm tips

- This product supports photo and video recording, but the power consumption is relatively high, when the power is lower than 15%, the device will deactivate the photo and video recording function, when the power is lower than 20%, the device will pause the transmission of data to the cell phone, and can be resumed after charging.
- This product supports wifi to transfer data to cell phone and save it, it needs the cell phone to allow APP to use the relevant permissions before it can be realized.

Precautions

- Prohibit charging in a waterlogged or humid environment.
- Please use the charging cable accompanying this product to charge.
- The material of this product is soft, please hold it gently and put it down, and it is forbidden to drop it; when you find the product broken, please pay attention to safety and avoid scratching your body.
- This product does not have waterproof function, it is strictly prohibited to let the product rain or soak in water.

※ This product supports photo, video function, it is strictly prohibited to use this product for clandestine photography and other behaviors, please strictly follow the local laws and regulations, healthy use of this product.

FCC Warning

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.