★	LEVEL 1 ENVIRONMENTAL RELATED SUBSTANCES TO BE CONTROLLED SHOULD NEVER BE USED			
ITEM	NAME	PART NO.	DESCRIPTION	QUANTITY

90mm 封面

封底

正面 125mm

Sablute

User Manual

TM286

TM286 Wireless Mouse

After-Sales

Email:sablute services@outlook.com

Website URL: sablute.com

MAM2

system support: win11/win10/win8/win7/mac/ios/ Android/windows xp...

-1-

Package Contents (attachment)

Mouse x1 Receiver x1 Instructions x1 Charging cable x1

Product Function Introduction



①Left Button
②Right Button
③Scroll Wheel
④Forward Button
⑤Back Button
⑥Adjust DPI Mode
⑦BT 1 Indicator Light
⑧BT 2 Indicator Light
⑨2.4 G Indicator Light
⑩Switching Connection Methods
⑪USB Receiver
⑫Power Switch

-2-

Product Specifications and Parameters

Height:	49.95±0.5 mm
Length:	140.46±0.5 mm
Width:	103.73±0.5 mm
Weight:	145 g±5 g
Operating Voltage:	3.7 V
Battery Capacity:	500 mAh
Operating Current :	<5 mA
Sleep Current:	<0.1 mA
DPI:	400-800-1200 -1600-2400

BT Mode

A. Pair Your First Device

-3-

1. Turn on the power switch.
2. Press and hold the Bluetooth button for 3 seconds or more. The light flashes rapidly, and the mouse will enter Discoverable mode for 2 minutes.
3. Complete Bluetooth pairing on your device, Use Bluetooth Named BT 3.0 Mouse or BT 5.0 Mouse.

B. Pair Your Second Device

1. Short press the Bluetooth button to switch channel.
2. Follow Steps 2 and 3 in "Pair Your First Device" to complete pairing.
3. Switch between devices.
   Short press the Bluetooth button to switch between up to 3 paired devices.(Up to 2 devices via Bluetooth and 1 device via the 2.4 GHz receiver).

-4-

What If the Mouse Does Not Respond?

1.Please charge the mouse with USB cable.
2.Make sure the power switch on the bottom of the mouse is "on"orat position.
3.Tryto restart the computer.
4. Is the USB connection of the mouse not responding?
5. If it is still unsuccessful,please email to **E-mail:sabluteservices@outlook.com**
Press and hold the **left, middle, and right buttons** of the mouse for 3 - 5 seconds, then plug the USB into the computer.



-5-

Trackball Maintenance



Socket

Step 1
Through the round hole on the bottom of the mouse, eject the trackball out of its socket.

Cotton Swab

Step 2
Take out the trackball, and wipe its socket with a cotton swab cautiously.

Step 3
Put the trackball back into the mouse.

-6-

Customer service

Buy on SABLUTE, You will get:

30-Day Money-Back Guarantee
90-Day Free Replacement
Hassle-Free Warranty Without Returning
Lifetime Customer Support

Contact us

For FAQs and more information, please visit:

Phone: 1-888-858-1618(US), Mon-Fri, 9am-6pm (Worktime), 1pm-2pm（Rest）

sablute.com/pages/contact
sabluteservices@outlook.com

-7-

FCC ID

This equipment has been tested and complies with the limits for Class B digital devices under Part 15 of FCC rules, designed to protect residential environments from harmful interference. The device emits radio frequency energy during use, and improper installation as per instructions may cause interference with wireless communications. If interference is detected (testable by power cycling), please take the following actions:

1. Adjust the position of the receiving antenna.
2. Increase the distance between the device and the receiver.
3. Connect the device to a different circuit outlet than the receiver.
4. Consult a technician or dealer for assistance.

Modifications not approved by the compliance responsible party will void the authority to operate the equipment. Operation is ubject to two conditions:

The device must not cause harmful interference.
The device must accept any interference received, including that affecting normal operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

尺寸：90*125mm

材质：100G书写纸 四色双面印刷 风琴折

材质厚度：0.12±0.02mm

备注：

1. 要求符合铭冠以下三大文件：
a. 《键盘类外观检验标准T-WQ-007/鼠标类外观检验标准TG-WQ-008/耳机类外观检验标准TG-WQ-005》
b. 《键盘&鼠标可靠性试验管理规范TG-WQ-004/耳机可靠性试验管理规范TG-WQ-006》
c. 《TG-HSF-300环保要求》
2. 产品须符合本公司环保最新Reach和RoHS等。
3. 标注：“ * ”为重点检测尺寸，重点在实际试配。

ITEM	DESCRIPTION	CHANGE BY	DATE

DIMENSIONAL TOLERANCE			
DIM	标签/贴纸类	吊卡/说明书 彩盒/吸塑类	印刷/镭雕类
0~50	±0.10	±0.25	±0.15
51~100	±0.15	±0.50	±0.20
101~150	±0.20	±0.75	±0.25
150<	±0.25	±1	±0.30
纸箱	单坑	双坑	三坑
0~1000	+3	+4	+5

DRAWN BY:			
CHECKED BY:			
APPROVED BY:			

MATERIAL		VER.	A0
QUANTITY	1	SHEET	1/1
TEXTURE		SCALE	1:1
FINISHED		UNITS	mm
		3RD. ANGLE'S	

TOGRAN 东莞市铭冠电子科技有限公司
TOGRAN ELECTRONIC Co., Ltd.

MODEL	TM286M05201R
DWG No.	
PART No.	3050006351

说明书