

User manual

Declaration

Please read the user manual so as to keep your mobile phone in the best condition, The manual has been verified and reviewed to guarantee the accuracy. Instructions and descriptions contained herein are accurate at the time of publication. However, mobile phones developed afterwards and the contents of their manual are subject to modification without further notification. Our company reserves the rights in relation to the manual

Contents

Overview.	1
1. Introduction	2
2. Function of main menu.....	2
3. PC connect.....	5
4. Maintenance and service.....	5

■ Overview

Please read the following concise rules carefully. Nonobservance to the rules may lead to danger or violence of the laws. The user's manual gives details about the safety precautions.

■ Emergency call

Make sure the equipment is in the covered area of the network service and the calling function is activated. As per the specific requirements, press the key of finish to clear the screen and return to the standby state. Input the emergency call number (112) and press the call key.

■ Function Description

The phone is a perfect combination of humanized design and exquisite workmanship, the streamline and ingenious body is comfortable to hold. With streamline and ingenious frame, it feels comfortable to hold the mobile phone in your hand. It supports TXT electronic book, Blue-tooth, dual SIM cards with one standby, network camera, camera, FM and etc. It makes your work more convenient and your free time more fun with the combination of keyboard, florid colored screen, pleasant bells, cartoon head portrait for incoming calls, strong file management function (supporting T-FLASH card), fashionable camera function and long time tape recording function, music player, video player.

1. Introduction

Insert the SIM card and the battery

Ask your SIM card dealer whether he has provided SIM card service and the method of usage who may be service provider or other dealers, SIM card and its contacts are vulnerable to scratch or bending. Attention shall be attached when use, insert or take out the card.

■ **Inserting/taking out T-FLASH CARD**

Only use approved and compatible T-FLASH card applicable to the mobile phone. Approved memory card trade standard is applied; however, certain bands may not be completely compatible with the mobile phone. Using incompatible memory card may damage not only the card and the mobile, but also the data stored in the card.

■ **Charging the battery**

Check the model number of the charger before using it to charge the mobile. Only use approved battery, charger and accessories applicable to the specific mobile model. Using other types of battery, charger and accessories may violate the certification or warranty terms of the equipment and may result in danger, Refer to the dealer for supply of relative approved accessories.

■ **Startup and shutdown**

Press the key of power supply to start up or shut down the mobile phone, If it is prompted to input PIN or UPIN, please input the required password (shown as **** on the screen).

2. Function of main menu

■ **Contact**

You may save the information of contacts including names and telephone numbers in the phonebook, which can save as much as 100 entries.

■ **Call logs**

Information, invites the menu→choosing if needing to check your communicating by phone

→ Communicate by phone center→ Communicate by phone taking notes→SIM card 1 communicates by phone recording/ SIM card 2 communicates by phone taking notes → SIM card 1/ SIM card 2 possessions telephone , SIM card 1/ SIM card 2 has not answered the phone , SIM card 1/ SIM card 2 already answers the phone or 2 already batches of SIM card 1/ SIM card telephone.

■ **Messaging**

You may select to send the finished message from SIM card 1 or SIM card 2.You may select multiple receivers to send the message to more than 1 person.

■ **Camera**

In the options of camera, you may set the photometry mode, flash light, exposure compensation, avoidance of flickering, postponing shooting, white balance, photo quality, photo size, special effect, profile and etc. You may enter the album to check the formats that the cell phone supports.

■ **Multimedia**

■ **Video Recorder**

In the options of the video camera, you may set the exposure compensation, avoidance of flickering, white balance, special effect, profile and etc.

■ **Image Viewer**

You can be in this to browse for pictures taken or stored in the phone .

■ **Video Player**

Check the video files in the memory card supported by the cell phone.

Play your favorite video files.

■ **Sound Recorder**

You can record the sounds that you want.

■ **My files**

You can insert the memory card and save files in it.

■ **Settings**

■ **Call settings**

You can some on the communications aspects of setting.

■ **Phone settings**

Refer to settings of basic functions, including city, time and format, display language, response time and restore factory setting: Enter the correct password of the phone will have to change your phone settings back to factory default state value, the user of the function be used with caution. (Default password: 1234).

■ **Display**

You may set functions in display.

■ **Security**

You may set functions in relations to cell phone security.

■ **Connections**

You can set the network account in this menu.

■ **Google**

Enter the google via the internet.

■ **Facebook**

Enter the facebook via the internet.

■ **Games**

We provide a games for your amusement.(Cobra)

■ **Calculator**

You can calculate in this function.

■ **Calendar**

You can see the date in it.

■ **Alarm**

Set the time of alarm clock, ring signal, ring mode, alarm ring mode and interval between repeated alarm rings.

■ **Profiles**

You may customize the profiles and activate any profile in order to use a specific function.

You may set the ring signal, ringing mode, prompt for connecting through, answer mode, and etc.

■ **Audio player**

The music player is used to play music files in supported formats in the current player's list.

You may view details of the music files and set the current music file as the ring signal for incoming call.

■ **FM Radio**

Turn on FM broadcast, and you may press the direction keys of left and right to manually tune the channel. Press the direction key of upward to turn on or off the auto-searching mode. Press OK to record the FM broadcast. Press the direction key of downward to turn on or off FM broadcast. In the options, you may set manually or automatically searching for channels, turning off the background during broadcasting as well as the format of recording thereof.

■ **Bluetooth**

You may establish wireless connection with other compatible devices with the Bluetooth technology; you may send images, videos, music files and etc. with the Bluetooth technology.

■ **TorchLight**

Here you can open or close the flashlight .

3. PC connect

■ **USB**

Use the T-Flash inserted in the mobile phone as U-Disk. You can transfer music, videos, games and other files form PC to the T-Flash by USB cable. Enjoy it anytime and anywhere.

4. Maintenance and service

Refer to the local dealer for supply of accessories. Hereafter are some precautions for usage of the accessories, Only use batteries, chargers and accessories approved by the manufacturer. Usage of other types of batteries, chargers and accessories may result in violence of the certification or warranty terms or even lead to danger, Keep the equipment dry, Don't keep the

equipment in under cooled places; otherwise, when the temperature rises to normal, moisture may be generated within the equipment, resulting in damage of the circuit board. .Only use matched or approved antenna .

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

15.21 Information to user.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 Information to the user.

Note: This equipment has been tested and found to comply with the limits for a Class B digital

device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses

and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause

harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of

the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 1.5 cm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these