

SAR Test Setup



Picture 1: Antenna 0 Back Side, the distance from EUT to the bottom of the Phantom is 10mm



Picture 1: Antenna 0 Back Side2, the distance from EUT to the bottom of the Phantom is 10mm



Picture 2: Antenna 2 Back Side, the distance from EUT to the bottom of the Phantom is 10mm



Picture 2: Antenna 0 and Antenna 2 Front Side, the distance from EUT to the bottom of the Phantom is 10mm



Picture 3: Antenna 0 and Antenna 2 Left Edge, the distance from EUT to the bottom of the Phantom is 10mm



Picture 4: Antenna 0 and Antenna 2 Right Edge, the distance from EUT to the bottom of the Phantom is 10mm



Picture 5: Antenna 0 and Antenna 2 Top Edge, the distance from EUT to the bottom of the Phantom is 10mm



Picture 6: Antenna 0 Back Side, the distance from EUT to the bottom of the Phantom is 0mm



Picture 6: Antenna 0 Back Side2, the distance from EUT to the bottom of the Phantom is 0mm



Picture 6: Antenna 2 Back Side, the distance from EUT to the bottom of the Phantom is 0mm



Picture 7: Antenna 0 and Antenna 2 Front Side, the distance from EUT to the bottom of the Phantom is 0mm



Picture 8: Antenna 0 and Antenna 2 Left Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 9: Antenna 0 and Antenna 2 Right Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 10: Antenna 0 and Antenna 2 Top Edge, the distance from EUT to the bottom of the Phantom is 0mm