


SAR Test Setup




Picture 1: Back Side, the distance from EUT to the bottom of the Phantom is 10mm



Picture 2: Back Side 2, the distance from EUT to the bottom of the Phantom is 10mm



Picture 3: Back Side 3, the distance from EUT to the bottom of the Phantom is 10mm




Picture 4: Front Side, the distance from EUT to the bottom of the Phantom is 10mm




Picture 5: Left Edge, the distance from EUT to the bottom of the Phantom is 10mm




Picture 6: Right Edge, the distance from EUT to the bottom of the Phantom is 10mm



Picture 7: Top Edge, the distance from EUT to the bottom of the Phantom is 10mm



Picture 8: Back Side 2, the distance from EUT to the bottom of the Phantom is 0mm




Picture 9: Back Side 3, the distance from EUT to the bottom of the Phantom is 0mm



Picture 10: Right Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 11: Back Side, the distance from EUT to the bottom of the Phantom is 14mm



Picture 12: Right Edge, the distance from EUT to the bottom of the Phantom is 24mm