

SAR Test Setup



Picture 1: Back Side, the distance from EUT to the bottom of the Phantom is 10mm




Picture 2: Back Side 2, the distance from EUT to the bottom of the Phantom is 10mm



Picture 3: Front Side, the distance from EUT to the bottom of the Phantom is 10mm



Picture 4: Left Edge, the distance from EUT to the bottom of the Phantom is 10mm



Picture 5: Right Edge, the distance from EUT to the bottom of the Phantom is 10mm



Picture 6: Top Edge, the distance from EUT to the bottom of the Phantom is 10mm



Picture 7: Back Side, the distance from EUT to the bottom of the Phantom is 0mm



Picture 8: Back Side 2, the distance from EUT to the bottom of the Phantom is 0mm



Picture 9: Front Side, the distance from EUT to the bottom of the Phantom is 0mm



Picture 10: Left Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 11: Right Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 11: Top Edge, the distance from EUT to the bottom of the Phantom is 0mm