



PLBAT-15

Product Manual



www.mrdjusa.com



PLBAT-15

Product Manual

Congratulations on your new PLBAT-15

PP SERIES Portable Speaker by Mr Dj

Here is what you'll find and get with your new Mr Dj Product:

1x15" Full Range Powered Speaker

150 Watts Max *P.M.P.O*

***Bluetooth*®Technology/SD/USB Inputs and Built-In Battery**

30 oz Woofer Magnet, 1 Voice Coil

Treble and Bass, Adjust frequencies to +/-12dB

Built-In Amplifier, FM built-in antenna

Built-in battery 12V 7 Ah

FCC Statements

1. Caution: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.



PLBAT-15

Product Manual

SAFETY AND WARNING !!! PLEASE READ !!!

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS



THE LIGHTING FLASH WITH ARROW SYMBOL WITHIN AN EQUILATERAL TRIANGLE IS INTENDED TO ALERT THE USER TO THE PRESENCE OF UN-ISOLATED DANGEROUS VOLTAGES WITHIN THE PRODUCT'S ENCLOSURE, THAT MAY BE OF SUFFICIENT MAGNITUDE TO CONSTITUTE A RISK OF ELECTRIC SHOCK TO PERSONS



THE EXCLAMATION POINT WITHIN AN EQUILATERAL TRIANGLE IS INTENDED TO ALERT THE USER TO THE PRESENCE OF IMPORTANT OPERATING AND MAINTENANCE (SERVICING) INSTRUCTIONS IN THE LITERATURE ACCOMPANYING THE APPLIANCE.

IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS

WARNING - When using electric products, basic precautions should always be followed, including the following:

- Read all instructions before using the product.
- Do not use this product near water, i.e. a bathtub, sink, wet basement, or swimming pool.
- This product, in combination with other headphones and speaker, may be capable of producing sound levels that could cause permanent hearing loss. Do not operate for long periods of time at a high-volume level or any level that is uncomfortable. If you experience any hearing loss or ringing in the ears, consult a doctor.
- The product should be located away from heat sources such as radiators, heat resistors, or any other product that produces heat.
- The product should be connected to a designated power supply described in these instructions.
- The power supply cord should be unplugged when left unused for a long period of time.
- Care should be taken so that objects do not fall or liquids are not spilled into the enclosure through its openings.
- The product should be serviced by quality personnel when:
 1. The power supply cord or plug has been damaged
 2. Objects have fallen, or liquid has been spilled in the produce
 3. The product has been exposed to rain
 4. The product does not appear to operate normally or exhibits a marked change in performance
 5. The product has been dropped, or the enclosure damaged
- Do not attempt to service the product beyond that described in the user-maintenance instructions. All other servicing should be performed by quality service personnel.

CAUTION

- Instructions are intended to alert the user to the risk of injury or material damage, should the unit be used improperly.
- Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well as to domestic animals or pets.

**PLBAT-15*****Product Manual*****SPECIFICATIONS**


System Specifications	
Frequency Response(-3dB)	45Hz - 18kHz
Frequency Range(-6dB)	40Hz - 20kHz
Max SPL Long-term @1m	98dB
Max SPL Peak @1m	121dB
Crossover	18dB/oct@ 3.5kHz(passive)
AUDIO	
MIC Input	
Input Type	bal. 1/4"
Input Impedance	3k Ohms
Input Sensitivity	-46dBu
LINE Input	
Input Type	bal. RCA
Input Impedance	10k Ohms
Input Sensitivity	-26dBu
LINE Output	
Output Type	bal. RCA
Output Impedance	10k Ohms
Output Sensitivity	26dBu
Frequency Equalizer	
Type	BT 2.1
Frequency	2400~2483.5MHz
Equalize Range	0 dB
Power Amplifier	
Rated Output Power	50 Watts
Max Output Power	150 Watts
Power Supply	110V/220V ~ 50/60Hz
Max Power Consumption	250VA
Rated THD	<0.5% (20Hz - 20kHz)
Frequency Response	+1/-2dB (20Hz - 20kHz)
Cooling	Convection Extrusion
Design	Class D
Dimensions	48X39.5X75CM
Weight	27.lbs. Net Wt.



PLBAT-15

Product Manual

BACK PANEL



1. MP3 Player L.E.D. Display Panel
2. I.R.(Infrared) Remote Control
3. Audio Control (Play, next, previous, EQ) MODE SELECTION
4. SD Card Slot
5. USB Slot
6. GUITAR IN (JACK Mic input)
7. 1/4 Mic input
8. Adjust the volume of MP3/LINE signal
9. Adjust the high tone of the output
10. Adjust the bass tone of the output

11. Adjust the volume of MIC/wireless microphone
12. This is the regulator of reverberation
13. Adjust the volume of GUITAR signal
14. DC POWER SUPPLY
15. RCA Line Input / Out
16. Power Cord Terminal
17. CHARGING LED (Red = Charging / Green = Full)
18. Power Switch
19. LED Switch
20. FM Antenna



Basic Operating Instructions

Before connecting the speaker, make sure the system is in “OFF” position and the controls on the minimum level, to prevent speaker damage / abuse.

- 1. Plug the Microphone (Included in Package) into the Quarter Mic Input
(Refer to Page 4- Illustration No. 6)**
- 2. Connect Your Selected Audio Source (CD, DECK, Mp3, DVD, etc) on “LINE IN/LINE OUT” input/output
(Refer to Page 4- Illustration No. 15)**
- 3. Turn on the systems. Mp3 LED will light up to indicate the speaker is on
(Refer to Page 4- Illustration No. 16 and 18)**
- 4. Insert USB or SD Card for MP3 Player (May Not Support Large Storage Cards - 16GB Tested)
(Refer to Page 4- Illustration No. 4 and 5)**
- 5. Set TREBLE and BASS controls to equalize the sound.
(Refer to Page 4- Illustration No. 9 and 10)**
- 6. Monitor LED Red Light (CHARGING)- When light comes on your speaker is detecting an overload
(Refer to Page 4- Illustration No. 17)**
- 7. Connect power cord to wall outlet then to the back of the unit
(Refer to Page 4- Illustration No. 16)**
- 8. Default Power Selected is 110-240V (For Asia / European Market) Please choose correct voltage.
(Refer to Page 4- Illustration No. 16)**
- 9. Select the Audio Player Mode to either USB / SD / FM*or Bluetooth® * through the selector.
(U - USB / S - SD Card / B - Bluetooth®)
(Refer to Page 4- Illustration No. 3)**

Note: * May Not Be Available On Select Models



PLBAT-15

Product Manual

Warranty - Please Register Online
www.mrdjusa.com

MR DJ USA warrants this product to be free of all manufacturing defects under normal use to the original purchaser for the following period:

PARTS - 90 DAYS / LABOR - 1 YEAR

To activate guarantee / warranty, the registration sheet must be filled in and mailed within TEN DAYS (10) of purchase. Proof of purchase will be needed.

This guarantee / warranty may not cover replacement of some parts, knobs, remotes or gift box (if supplied with unit / product). Any alterations, abuse, misuse, or accidental damage voids this guarantee / warranty. This will be determined by our Technical Department.

All handling and transportation charges must be prepaid and product must be dispatched in original packing together with this guarantee / warranty sheet. All products needing Warranty / Guarantee must have Return Merchandise Authorization (RMA) Number, without the RMA Number - Request for Warranty / Guarantee will be denied and returned to sender. Please refer to our website (www.MR DJusa.com) for further warranty / guarantee information and instructions. RMA's can also be requested via ONLINE

Please fill in the following data before using this unit.

MODEL NO. _____ SERIAL NO. _____
WHERE PURCHASED _____
PURCHASE DATE _____
NAME _____
ADDRESS _____
CITY/STATE _____
ZIP CODE _____
PURCHASED FROM _____
DATED _____

MR DJ USA INC
Tel: 213-744-1144
Fax: 213-749-2999
Toll Free: 1-877-418-8771
<http://www.MR DJusa.com>

YOU CAN ALSO REGISTER YOUR PRODUCT ONLINE - PLEASE VISIT - <http://www.mrdjusa.com/>

Note: Warranties and Guaranties are subject to MR DJ USA's Terms and Conditions which can be found online at www.MR DJusa.com
We have the right to refuse warranty and guaranty requests.

