


Westone®

 **Bluetooth®** Cable 2.0

User Manual



REGISTRATION

THANK YOU

for purchasing the Westone®
Bluetooth® Cable 2.0

Your warranty covers defects in materials and workmanship for a period of **ONE YEAR** from the date of the original retail purchase from a Westone authorized dealer. Proof of purchase is required to verify eligibility.

Please register your product to receive software updates on new product releases, promotions, and all of the latest updates from Westone Audio.

» Register at: www.westone.com/productregistration


PRODUCT TIPS

Get the most from your new Bluetooth Cable 2.0 by following these helpful tips:


- Avoid exposing your cable to extreme temperatures and prolonged exposure to direct sunlight.
- Do not immerse the cable and cable modules into water or liquids of any kind. The cable and cable modules are water resistant not water proof.
- Please avoid any shock damage or strong impacts to the cable or cable modules, as this can affect the performance of the cable.
- When removing earphones from the cable please grasp the cable connectors and not the cable. Failure to do so could affect the performance of the cable.

PRODUCT COMPONENT OVERVIEW


BLUETOOTH CABLE 2.0



PORTABLE CHARGING DOCK



CHARGING CORD



CONNECTING EARPHONES



How to attach earphones to the cable:

1. Identify the right and left MMCX connectors, each connector is marked "R" for right and "L" for left.
2. Identify the right and left earphones/earpieces. Match the appropriate earphone to the correct cable right + right or left + left.
3. Grasp the MMCX connector and insert it into the earphone by pushing it into the female MMCX connector in the earphone until it clicks into place.
4. Repeat for the other side.

DISCONNECTING EARPHONES



How to disconnect earphones from the cable:

1. Hold the earphone firmly with one hand, and the MMCX connector with the other hand.
2. Pull the MMCX connector straight out of the earphone. If you pull at an angle, the connector becomes harder to remove from the female socket.


CAUTION: *Never try to remove the cable from the earphone by pulling directly on the cable. This could damage or destroy the cable.*

PAIRING THE CABLE TO YOUR DEVICE

How to pair the cable to your device:

1. Hold down the power button for 5 seconds.
The indicator light located next to the power button will begin flashing red and blue to indicate the pairing process has begun. The voice prompt will indicate "Pairing".
2. To complete pairing the cable with your device follow these steps:
 - **iPhone:** Go to Settings/General/Bluetooth/On*
 - **Android:** Go to Settings/Bluetooth/On/Scan for devices*
 - **Windows:** Go to Settings/Bluetooth/On*
3. Select "Westone BT 2.0"
4. If your device asks for a passcode, enter four zeros (0000) for the passcode or accept the connection.
5. Once the device is successfully paired the indicator light will flash blue and the voice prompt will announce "connected".

**Pairing procedure can vary per device.*



CABLE FUNCTIONS

Power/Center Button	Action
Power On	Press and Hold (1 sec)
Power Off	Press and Hold (3 secs)
Enter Pairing Mode	Press and Hold (5 secs)
Play/Pause Music	Press and Release
Receive Incoming Call	Press and Release
Decline Incoming Call	Press and Hold (1 sec)
End Active Call	Press and Release
Reconnect to Last Device	Press and Release
Voice Search / Siri	Double Press and Release

Volume Up (+) / Right Button

Volume Up	Press and Release
Next Track	Press and Hold (1 sec)

Volume Down (-) / Left Button

Volume Down	Press and Release
Previous Track	Press and Hold (1 sec)

Clear Paired Device List (PDL)

Volume Up(+) & Volume Down(-)	Press and Hold (8 sec)
-------------------------------	------------------------

LED INDICATIONS

Event	LED Indication	Voice Prompts
Power On	<i>Red + Blue</i> LEDs Flash Once	Power On
Power Off	<i>Red + Blue</i> LEDs Flash Once	Power Off
Pairing Mode	<i>Red + Blue</i> LEDs Flash Alternately	Pairing
Searching	<i>Red</i> LED Flashes Twice	
Connected	<i>Blue</i> LED Flashes Three Times	Connected
Battery Low	<i>Red</i> LED Flashes Every Second	Battery Low
Clear Paired Device List	<i>Red + Blue</i> LEDs Flash Twice	

CHARGING DOCK FUNCTIONS


Status	LED Indication
Battery Dock is Charging	<i>Red</i> LED
Battery Dock is Charged	<i>Blue</i> LED
Dock and Bluetooth Cable are Charging	<i>Red + Blue</i> LEDs
Dock and Bluetooth Cable are Charged	<i>Blue</i> LED

CHARGING YOUR CABLE WITH THE PORTABLE CHARGING DOCK

Your cable arrives partially charged so it can be used immediately. In advance of charging your cable, you will need to charge the charging dock.


To charge the charging dock follow these steps:

1. To charge the dock, plug the provided USB cable into a USB port on any device.
2. Plug the mini USB end of the cable into the charging port located on the bottom of the charging dock. (1a)



To charge the cable using the charging dock follow these steps:

1. Open the charging dock cover (2) by sliding the lock release to the right.
2. Place the battery module into the charging dock with the logo face up.
3. Close the charging dock cover to begin charging the cable. (3)




NOTE: The cable can be charged with or without the USB cable plugged in.



WEARING THE CHARGING DOCK


NOTE:

The charging dock can be worn with the cable to increase the battery life between charges, thereby increasing the total use time of the cable.



IMPORTANT:


Never charge the charging dock when it is attached to the charging module and the cable is being worn.




WEARING THE CABLE

There are two ways to wear your cable:

1. Wear the cable around the back of your neck (1) when participating in high impact activities.



2. Wear the cable around the front of your neck (2) while participating in low impact activities.



ADDITIONAL INSTRUCTIONS

AND TROUBLESHOOTING

To pair the cable to a new device, follow these steps:

1. Ensure that the cable is in pairing mode.
2. There are two (2) ways to enter pairing mode.
 - a. Hold down the power button on the cable for five (5) seconds while turning on the device you wish to pair the cable with.
 - b. Clear the Paired Device List (PDL) by pressing and holding down the Volume Up (+) and Volume Down (-) buttons on the control module together for eight (8) seconds.
3. The cable will switch off if it is not connected to a device after five (5) minutes. A voice prompt will indicate "Power Off".
4. The cable will automatically try to reconnect to the last device it was paired with unless the PDL has been cleared.
5. The operation and enabling of Voice Search/

Siri can only be done on devices that support those functions.

6. When the cable battery power has reached 30% of remaining life, the indicator light will turn red for all events and a voice prompt will indicate "Battery Low". This voice prompt will repeat until all power is drained.

If the cable fails to pair to the selected device, follow these steps:

1. Disable and then enable the Bluetooth setting on the device, then search for "Westone BT 2.0" again.
2. Reboot the cable by turning it off and then on again.
3. Clear the Paired Device List (PDL) by pressing and holding down the Volume Up (+) and Volume Down (-) buttons on the control module together for eight (8) seconds.

WARRANTY INFORMATION

Limited Product Warranty

Westone warrants this product to be free of defects in material or workmanship for a period of one (1) year from the date of original retail purchase. This warranty is available only to the original purchaser, and only if purchased from an authorized Westone distributor or reseller. If your product is found to be defective during the warranty period, Westone will, at its sole option, either repair the product or replace the product with a new or factory reconditioned or substantially equivalent model. This limited warranty does not apply to loss, theft, or any defects attributable to damage beyond the reasonable control of Westone including damage caused by abuse, misuse, misapplication or modifications performed by anyone other than Westone. This warranty applies only to the external shell of the product, the internal components and cable.

Repair/Replacement Warranty

This Limited Warranty shall apply to any repair, replacement part or replacement product for the remainder of the original warranty period or for ninety (90) days, whichever period of time is greater. Any parts or product replaced under warranty will become the property of Westone.

Requesting Warranty Support

Valid warranty claims are generally processed through the point of purchase during the first thirty (30) days after retail purchase.

United States & Canada

If it is necessary to return your product to Westone for warranty or post-warranty service, contact Westone to request a return merchandise authorization (RMA) number. Go to **westoneaudio.com** to submit a Product Return Request Form. Please note you will be required to submit reasonable proof of purchase date, ownership, and that the product was purchased from an authorized Westone retailer. Once you receive your RMA number, package the product securely to prevent damage in transit, include the documentation, and send prepaid and insured through a trackable shipping carrier to:

Westone Laboratories, Inc.

Attn: Music Returns Dept.

2260 Executive Circle, Colorado Springs, CO 80906 USA

Westone will be responsible for shipping to the consumer after warranty repair/replacement only. The customer is responsible for all shipping/handling charges related to returning the product to Westone.

International

The warranty on this product if it is sold to a consumer outside of the United States and Canada shall comply with applicable law. To obtain warranty service, contact the dealer from which you purchased or the distributor that supplied this product. Additional charges and limitations may apply. If purchased through an authorized Westone retailer, but not through the local distributor or distributor's network, contact Westone directly (see United States & Canada instructions above). If purchased in an international location without a Westone distributor, contact Westone directly (see United States & Canada instructions above).

Limitation of Liability

Westone disclaims any and all implied warranties, warranties of merchantability and fitness for a particular purpose to the maximum extent permissible by law. Westone shall not be liable for any special, incidental or consequential damages caused by the use, misuse, or inability to use this product. If purchased under a government contract, those contract terms supersede terms stated herein. In some locations, implied warranties cannot be limited. Under certain conditions, these limitations or exclusions may therefore not apply to you. This warranty replaces all other warranties for this product.

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

SRRC

产品有毒有害物质或元素的名称及含量
根据中国《电子信息产品污染控制管理办法》

有害物质	有毒有害物质或元素					
	铅 (Pb)	汞 (Hg)	铬 (Cr)	多联苯 (C12H10)	多联苯 (C12H10)	多联苯 (C12H10)
外壳及附件	*	○	○	○	○	○
线材	○	○	○	○	○	○
电池	○	○	○	○	○	○
电池	*	○	○	○	○	○

○：表示该有害物质在该部件所有均质材料中的含量均在SJ/T11363-2006标准规定的限量要求以下。
*：表示该有害物质至少在该部件第一均质材料中的含量超过SJ/T11363-2006标准规定的限量要求。

注：表中符号“>C”表示有某种部件符合RoHS指令的要求，含有有毒有害物质或元素的部件均符合RoHS指令要求。本图仅供参考，不作为RoHS指令符合性声明的依据。



产品执行标准：信部无【2002】353号

CONTACT US

**Westone values your satisfaction.
If you have any questions or comments
about our products or service,
please contact us:**

Phone: 1-719-540-9333

Toll Free: 1-800-525-5071

Fax: 1-800-736-9576

Email: music@westone.com

Westone® Laboratories, Inc.

P.O. Box 15100, Colorado Springs, CO 80935

Physical Address:

2235 Executive Circle, Colorado Springs, CO 80906

Westone®

Designed in Colorado, USA

©2018 Westone Laboratories, Inc. | The "Bluetooth®" wordmark and logos are registered trademarks owned by Bluetooth SIG, Inc. any use of such marks is under license. | Qualcomm aptX is a product of Qualcomm Technologies International, Ltd. Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries, used with permission. aptX is a trademark of Qualcomm Technologies International, Ltd., registered in the United States and other countries, used with permission. Other trademarks and trade names are those of their respective owners. | Made in China | PN 78397-M 4.18

westoneaudio.com