



NTNV-N41-PC2-30-40-M-DFT-16QAM-Outer_Full-PASS



NTNV-N41-PC2-30-40-M-DFT-16QAM-Inner_Full-PASS



NTNV-N41-PC2-30-40-M-DFT-16QAM-Edge_1RB_Left-PASS




NTNV-N41-PC2-30-40-M-DFT-16QAM-Edge_1RB_Right-PASS





NTNV-N41-PC2-30-40-H-DFT-QPSK-Outer_Full-PASS



NTNV-N41-PC2-30-40-H-DFT-QPSK-Inner_Full-PASS










NTNV-N41-PC2-30-50-M-DFT-16QAM-Outer_Full-PASS



NTNV-N41-PC2-30-50-M-DFT-16QAM-Inner_Full-PASS

NTNV-N41-PC2-30-50-M-DFT-16QAM-Edge_1RB
_Left-PASSNTNV-N41-PC2-30-50-M-DFT-16QAM-Edge_1RB
_Right-PASSNTNV-N41-PC2-30-50-H-DFT-QPSK-Outer_Full-P
ASSNTNV-N41-PC2-30-50-H-DFT-QPSK-Inner_Full-P
ASS





NTNV-N41-PC2-30-60-L-DFT-QPSK-Outer_Full-P
ASS



NTNV-N41-PC2-30-60-L-DFT-QPSK-Inner_Full-P
ASS



NTNV-N41-PC2-30-60-L-DFT-QPSK-Edge_1RB_
Left-PASS



NTNV-N41-PC2-30-60-L-DFT-QPSK-Edge_1RB_
Right-PASS



NTNV-N41-PC2-30-60-L-DFT-16QAM-Outer_Full-P
PASS



NTNV-N41-PC2-30-60-L-DFT-16QAM-Inner_Full-P
PASS

NTNV-N41-PC2-30-60-L-DFT-16QAM-Edge_1RB
_Left-PASSNTNV-N41-PC2-30-60-L-DFT-16QAM-Edge_1RB
_Right-PASSNTNV-N41-PC2-30-60-M-DFT-QPSK-Outer_Full-P
ASSNTNV-N41-PC2-30-60-M-DFT-QPSK-Inner_Full-P
ASSNTNV-N41-PC2-30-60-M-DFT-QPSK-Edge_1RB_
Left-PASSNTNV-N41-PC2-30-60-M-DFT-QPSK-Edge_1RB_
Right-PASS



NTNV-N41-PC2-30-60-M-DFT-16QAM-Outer_Full-PASS



NTNV-N41-PC2-30-60-M-DFT-16QAM-Inner_Full-PASS



NTNV-N41-PC2-30-60-M-DFT-16QAM-Edge_1RB_Left-PASS




NTNV-N41-PC2-30-60-M-DFT-16QAM-Edge_1RB_Right-PASS




NTNV-N41-PC2-30-60-H-DFT-QPSK-Outer_Full-PASS



NTNV-N41-PC2-30-60-H-DFT-QPSK-Inner_Full-PASS



NTNV-N41-PC2-30-70-L-DFT-QPSK-Outer_Full-P
ASSNTNV-N41-PC2-30-70-L-DFT-QPSK-Inner_Full-P
ASSNTNV-N41-PC2-30-70-L-DFT-QPSK-Edge_1RB_
Left-PASSNTNV-N41-PC2-30-70-L-DFT-QPSK-Edge_1RB_
Right-PASSNTNV-N41-PC2-30-70-L-DFT-16QAM-Outer_Full-
PASSNTNV-N41-PC2-30-70-L-DFT-16QAM-Inner_Full-
PASS





NTNV-N41-PC2-30-70-M-DFT-16QAM-Outer_Full-PASS



NTNV-N41-PC2-30-70-M-DFT-16QAM-Inner_Full-PASS



NTNV-N41-PC2-30-70-M-DFT-16QAM-Edge_1RB_Left-PASS



NTNV-N41-PC2-30-70-M-DFT-16QAM-Edge_1RB_Right-PASS



NTNV-N41-PC2-30-70-H-DFT-QPSK-Outer_Full-PASS



NTNV-N41-PC2-30-70-H-DFT-QPSK-Inner_Full-PASS



NTNV-N41-PC2-30-70-H-DFT-QPSK-Edge_1RB_
Left-PASS



NTNV-N41-PC2-30-70-H-DFT-QPSK-Edge_1RB_
Right-PASS



NTNV-N41-PC2-30-70-H-DFT-16QAM-Outer_Full-
PASS




NTNV-N41-PC2-30-70-H-DFT-16QAM-Inner_Full-
PASS



NTNV-N41-PC2-30-70-H-DFT-16QAM-Edge_1RB_
_Left-PASS



NTNV-N41-PC2-30-70-H-DFT-16QAM-Edge_1RB_
_Right-PASS



NTNV-N41-PC2-30-80-L-DFT-QPSK-Outer_Full-P
ASS

NTNV-N41-PC2-30-80-L-DFT-QPSK-Inner_Full-P
ASS

NTNV-N41-PC2-30-80-L-DFT-QPSK-Edge_1RB_
Left-PASS

NTNV-N41-PC2-30-80-L-DFT-QPSK-Edge_1RB_
Right-PASS

NTNV-N41-PC2-30-80-L-DFT-16QAM-Outer_Full-
PASS

NTNV-N41-PC2-30-80-L-DFT-16QAM-Inner_Full-
PASS

NTNV-N41-PC2-30-80-L-DFT-16QAM-Edge_1RB
_Left-PASSNTNV-N41-PC2-30-80-L-DFT-16QAM-Edge_1RB
_Right-PASSNTNV-N41-PC2-30-80-M-DFT-QPSK-Outer_Full-P
ASSNTNV-N41-PC2-30-80-M-DFT-QPSK-Inner_Full-P
ASSNTNV-N41-PC2-30-80-M-DFT-QPSK-Edge_1RB_
Left-PASSNTNV-N41-PC2-30-80-M-DFT-QPSK-Edge_1RB_
Right-PASS

