








NTNV-N41-PC2-30-10-M-DFT-QPSK-Outer_Full-3
0-1000-Ant1-PASS



NTNV-N41-PC2-30-10-M-DFT-QPSK-Outer_Full-1
000-3000-Ant1-PASS



NTNV-N41-PC2-30-10-M-DFT-QPSK-Outer_Full-3
000-18000-Ant1-PASS




NTNV-N41-PC2-30-10-M-DFT-QPSK-Outer_Full-1
8000-30000-Ant1-PASS





NTNV-N41-PC2-30-10-M-DFT-QPSK-Edge_1RB_
Left-30-1000-Ant1-PASS




NTNV-N41-PC2-30-10-M-DFT-QPSK-Edge_1RB_
Left-1000-3000-Ant1-PASS













NTNV-N41-PC2-30-15-L-DFT-QPSK-Edge_1RB_
Left-3000-18000-Ant1-PASS



NTNV-N41-PC2-30-15-L-DFT-QPSK-Edge_1RB_
Left-18000-30000-Ant1-PASS



NTNV-N41-PC2-30-15-L-DFT-QPSK-Edge_1RB_
Right-30-1000-Ant1-PASS




NTNV-N41-PC2-30-15-L-DFT-QPSK-Edge_1RB_
Right-1000-3000-Ant1-PASS





NTNV-N41-PC2-30-15-L-DFT-QPSK-Edge_1RB_
Right-3000-18000-Ant1-PASS





NTNV-N41-PC2-30-15-L-DFT-QPSK-Edge_1RB_
Right-18000-30000-Ant1-PASS























NTNV-N41-PC2-30-20-H-DFT-QPSK-Outet_Full-3
0-1000-Ant1-PASS



NTNV-N41-PC2-30-20-H-DFT-QPSK-Outet_Full-1
000-3000-Ant1-PASS



NTNV-N41-PC2-30-20-H-DFT-QPSK-Outet_Full-3
000-18000-Ant1-PASS



NTNV-N41-PC2-30-20-H-DFT-QPSK-Outet_Full-1
8000-30000-Ant1-PASS



NTNV-N41-PC2-30-20-H-DFT-QPSK-Edge_1RB_
Left-30-1000-Ant1-PASS



NTNV-N41-PC2-30-20-H-DFT-QPSK-Edge_1RB_
Left-1000-3000-Ant1-PASS

