







NTNV-N41-PC2-30-20-M-DFT-16QAM-Inner_Full-
PASS

NTNV-N41-PC2-30-20-M-DFT-16QAM-Edge_1RB
Right-PASSNTNV-N41-PC2-30-20-H-DFT-QPSK-Inner_Full-P
ASS




	
NTNV-N41-PC2-30-30-L-DFT-QPSK-Outer_Full-P ASS	NTNV-N41-PC2-30-30-L-DFT-QPSK-Inner_Full-P ASS
	
NTNV-N41-PC2-30-30-L-DFT-QPSK-Edge_1RB_ Left-PASS	NTNV-N41-PC2-30-30-L-DFT-QPSK-Edge_1RB_ Right-PASS
	
NTNV-N41-PC2-30-30-L-DFT-16QAM-Outer_Full- PASS	NTNV-N41-PC2-30-30-L-DFT-16QAM-Inner_Full- PASS





NTNV-N41-PC2-30-30-H-DFT-QPSK-Edge_1RB_ Left-PASS	NTNV-N41-PC2-30-30-H-DFT-QPSK-Edge_1RB_ Right-PASS
NTNV-N41-PC2-30-30-H-DFT-16QAM-Outer_Full- PASS	NTNV-N41-PC2-30-30-H-DFT-16QAM-Inner_Full- PASS
NTNV-N41-PC2-30-30-H-DFT-16QAM-Edge_1RB_ _Left-PASS	NTNV-N41-PC2-30-30-H-DFT-16QAM-Edge_1RB_ _Right-PASS



NTNV-N41-PC2-30-40-L-DFT-QPSK-Outer_Full-P
ASS


NTNV-N41-PC2-30-40-L-DFT-QPSK-Inner_Full-P
ASS


NTNV-N41-PC2-30-40-L-DFT-QPSK-Edge_1RB_
Left-PASS


NTNV-N41-PC2-30-40-L-DFT-QPSK-Edge_1RB_
Right-PASS

NTNV-N41-PC2-30-40-L-DFT-16QAM-Outer_Full-
PASS

NTNV-N41-PC2-30-40-L-DFT-16QAM-Inner_Full-
PASS







	
NTNV-N41-PC2-30-50-L-DFT-QPSK-Outter_Full-P ASS	NTNV-N41-PC2-30-50-L-DFT-QPSK-Inner_Full-P ASS
	
NTNV-N41-PC2-30-50-L-DFT-QPSK-Edge_1RB_ Left-PASS	NTNV-N41-PC2-30-50-L-DFT-QPSK-Edge_1RB_ Right-PASS
	
NTNV-N41-PC2-30-50-L-DFT-16QAM-Outter_Full- PASS	NTNV-N41-PC2-30-50-L-DFT-16QAM-Inner_Full- PASS