

































	
NTNV-N41-PC2-30-50-H-DFT-QPSK-Outet_Full-3 0-1000-Ant1-PASS	NTNV-N41-PC2-30-50-H-DFT-QPSK-Outet_Full-1 000-3000-Ant1-PASS
	
NTNV-N41-PC2-30-50-H-DFT-QPSK-Outet_Full-3 000-18000-Ant1-PASS	NTNV-N41-PC2-30-50-H-DFT-QPSK-Outet_Full-1 8000-30000-Ant1-PASS
	
NTNV-N41-PC2-30-50-H-DFT-QPSK-Edge_1RB_ Left-30-1000-Ant1-PASS	NTNV-N41-PC2-30-50-H-DFT-QPSK-Edge_1RB_ Left-1000-3000-Ant1-PASS

