



4IN1 WIRELESS CHARGING AUTO CLAMP VENT MOUNT



Scan Here to Extend
Your Warranty

MANUAL

AWC8-1017

Please call or email us for customer support or for more information.
Toll Free: 877-405-2397
info@ArmorAllElectronics.com
V1.0 0125

Safety Instructions

Please read and understand all instructions before using this product. Failure to follow these safety instructions, could lead to fire, electrical shock, personal injury, property damage, or damage to the product. This product contains a non-replaceable rechargeable lithium-ion battery. When discarding, follow your local / state guidelines. If damage is caused by failure to follow the instructions, the warranty does not apply.

- Keep these instructions.
- Do not drop, puncture or disassemble this product.
- This product should not be exposed to dripping or splashing.
- Do not use the product in a strong magnetic field.
- Use a clean, soft cloth to clean. Do not use any corrosive cleaners/oils to clean.
- Keep your attention on the road. Do not operate the controls of this product while driving.
- Use only the included USB-C cable and a 5V/3A or 9V/2A charger for best performance.
- Do not place metal objects (e.g., coins, keys) near the charger to avoid interference.
- Ensure your device supports wireless charging or use the appropriate magnetic charging head.
- Clean the charging surface regularly to maintain optimal performance.
- Do not handle the unit or USB cord with wet hands.
- Do not charge or use the product if it has been submerged in water or if water has gotten inside the product.
- Do not expose the product to extremely high or low temperatures. Use this product in a location with a

temperature of 32°F - 95°F. Prolonged exposure to extreme heat or cold reduces battery longevity. Exposure to fire or temperatures above 170°F could cause serious damage and explosion.

- Do not use if damaged or modified or if you see any bulging, swelling, leakage, or other abnormality. Never insert objects other than the specified cables into the product. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion, or risk of injury.
- Do not modify or try to use for a non-intended purpose.
- Do not place anywhere where the product would become crushed or punctured.
- Charge using the correct charger, and make sure that the charger is inserted all the way.
- This product is not a toy. Keep out of reach of children or those that require supervision.

NOTE: Lithium-ion batteries will self-discharge over time. To ensure battery life, do not store the product in an uncharged state for a length of time. If left in a discharged state for too long a lithium-ion battery will no longer have the ability to be recharged.

Introduction

Thank you for purchasing the 4in1 Wireless Charging Auto Clamp Vent Mount. This innovative charger is designed to provide fast, efficient wireless charging while securely mounting your device in your vehicle. The device features dual sensors for prong operation, and interchangeable magnetic charging heads to charge various types of devices.

Features

- Supports up to 15W fast charging power and charges your Qi-compatible device wirelessly

- Includes 3 interchangeable magnetic attachments to charge any device- USB-C, 8-pin, Micro USB
- Smart sensor detects phone to automatically open and enables you to mount your phone with one hand
- Gently touch the sensor to open the mount and easily remove your phone
- For use with GPS directions, hands-free calls and more
- Requires power with included cable via USB port or car charger (not included)

Included

- 15W Wireless Charging Phone Mount
- Vent Hook
- Magnetic Charging Attachments (USB-C, 8-Pin, Micro USB)
- USB Power Cable
- Manual

At a Glance

-
- 1 Smart Sensor Auto Clamp Arms
 - 2 Qi-Compatible Charging Surface
 - 3 Touch Sensor
 - 4 Vent Hook
 - 5 Interchangeable Magnetic Charging Attachments

Get Started

Installation

- Remove all components from the packaging.
- Take the tightening bolt (the plastic ring) and slide it onto the ball joint of the vent mount. Ensure the open side of the ring faces outward (toward the wireless charger).



- Insert the ball joint into the socket on the back of the wireless charger. You may need to apply slight pressure to snap the ball into place.
- Once the ball is securely in the socket, rotate the tightening bolt until the wireless charger is fixed firmly at your desired angle. Adjust the angle as necessary before fully tightening.
- Turn the vent mount dial (rotating knob on the back of the mount) clockwise to extend the mounting arms.

Continued on reverse →

ONE YEAR WARRANTY

Xtreme, official licensee of Armor All™ warrants its products for ONE YEAR against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.


Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service at info@ArmorAllElectronics.com

EXTEND YOUR WARRANTY

Scan the QR Code on the front of this manual to extend your warranty from 1 Year to 2 Year Limited.

©2025 Energizer Auto. Armor All is a trademark of Energizer Auto and is used under license by Jem Accessories, Inc.



- Position the mount arms securely over one of the car's air vent blades.
- Once the arms are in position, turn the dial counterclockwise to tighten the mount onto the vent. Ensure it is snug and stable before proceeding.



Connecting Power

- Using the included USB-C fast-charging cable, connect the wireless charger to a 5V/3A or 9V/2A power adapter (not included) or connect directly into your car USB port.
- If using a car charger/power adapter, plug the charger into your car's USB port or a cigarette lighter adapter to power the device.
- Once plugged in, the wireless charger will power on, and the motion sensor will activate.

Operation

Placing your Device

- Once powered, bring your device close to the wireless charger. The motion sensor (effective within 0-5.91 inches) will detect your hand or device and automatically open the prongs.

- Place your device onto the charging pad, ensuring the device's wireless charging coil aligns with the charger's coil.
- Once your device is on the charger, the prongs will automatically close to securely hold the device in place.
- Charging will begin immediately, indicated by the blue LED light turning on.
- To remove your device, touch the touch sensor button located on the base of the charger.
- The prongs will open, allowing you to safely remove your device.

Magnetic Attachment Charging

- Select the appropriate magnetic head (USB-C, 8-Pin, or Micro USB) for your device.
- Attach the magnetic head to the mount. It will snap into place magnetically.



- Open the prongs using the motion sensor or touch sensor.
- Place your device on the charger and insert the magnetic attachment to the bottom of your device.
- Charging will begin immediately.

LED Indicator Guide

- Red and Blue Flashing (Start-Up): The charger is powering on.
- Red Light (Standby): No foreign objects detected. The charger is ready for wireless charging.
- Blue Light (Active Charging): Wireless charging is currently in progress.
- Alternating Red and Blue Flashing: A foreign object has been detected on the coil. Remove the object to resume charging.

Note: Wireless charging is faster than wired charging for this device.

Specifications

Specifications are subject to change without notice.

Specifications:

Input: 5V/3A, 9V/2A
Wireless Charging Output Power: 15W, 10W, 7.5W, 5W
Magnetic Head Output: 5V/2A
Motion Detector Distance: 0-5.91 inches
Vent Mount Max Length: 3.39 inches
Min Device Width: 2.56 inches
Max Device Width: 3.35 inches
Cable Length: 3.28 feet

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules, operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.