

MONSTER PRINTER SLUG	
BRAND: Monster	ADDITIONAL PRINTING PROCESSES:
CATEGORY: Automotive	SPOT UV: Gloss
PRODUCT NAME: 18W - FM Trans with Music EQ	METALLIC FOIL COLOR:
FILE NAME: MFT2-1000-BLK_Manual	DEBOSS:
ITEM NUMBER: MFT2-1000-BLK	EMBOSS:
	VARNISHING TECHNIQUE:
PRESS WORK: TRIM TO SIZE, SCORE, FOLD & GLUE WHEN SPECIFIED	PRESS SPEC COLOR REFERENCES
SCALE: 100%	☐ DIELINE
ASSEMBLED PACKAGE DIMENSIONS (in Inches)	☐ GLOSS UV SPOT
WIDTH: 2.694"	☐ EMBOSSING (RELIEF)
HEIGHT: 3.74"	☐ DEBOSSING (SUNKEN)
DEPTH: N/A	☐ FOLDING LINE
DIELINE OVERALL DIMENSIONS (in Millimeters)	☐ PRODUCT PLACEMENT
WIDTH: 546.975 mm	☐ FOILING
HEIGHT: 95 mm	☐ GLUE FOLD
PACKAGING MATERIALS, THICKNESS & SIZE	☐ SECURITY STICKER PLACEMENT
SUBSTRATE TYPE: Matte SV	☐ BLISTER OR INNER TRAY PLACEMENT
White board 250gsm + F-Flute + K175	☐ HOLOGRAPHIC CERTIFICATION PLACEMENT
WINDOW:	ADDITIONAL PANTONE COLORS (NOT CMYK)
INNER TRAY: White board 250gsm	SOLID COLOR NAME:
BLISTER:	NEON COLOR NAME:
Aluminum BAG:	METALLIC COLORS:
MAGNET:	VENDOR'S FOIL NAME/NUMBER:
VELCRO:	FILE SAVED AS:
SECURITY STICKERS:	.ai = FULLY EDITABLE
HANG TAB COLOR MATERIAL/SIZE:	.OUT.ai = OUTLINED
FOAM:	.pdf = Acrobat
CORRUGATED BOARD:	.jpg = Flat image
PAPERBOARD:	.png = DIGITAL (transparent background)
USER GUIDE: 128gsm	APPROVAL CHECKLIST:
PACKAGING TYPES	PRIMARY DESIGNER: Chris
FOLDING CARTON:	DATE: 07/2025
FOLDING CARTON WITH DOOR PANEL:	SECONDARY DESIGNER:
RIGID GIFT BOX:	DATE:
CLAMSHELL:	PROOF READ:
SLIDING/SLIPCASE:	DATE:
TRAPPED BLISTER CARD:	APPROVED BY:
BLISTER CARD:	DATE:
OTHER:	AUTHORIZATION SIGNATURES:

MFT2-1000-BLK Manual Artwork

Dimensions: 546.975mm x 95mm
Print 4 color, 2 sided, accordion fold



WIRELESS FM TRANSMITTER
Hands-Free Calling • Wireless Music • USB Charger



SCAN OR CODE
TO EXTEND YOUR
PRODUCT'S WARRANTY

Operation Manual
MODEL MFT2-1000-BLK
V1.1 0925

Safety Instructions

Please read all the instructions before using this product and keep this manual for future reference. Failure to follow the instructions could lead to fire, electrical shock, personal injury, property damage, or damage to the product.

- Do not use if the product has been dropped, punctured, or damaged in any way.
- Do not modify, open, or try to disassemble. There are no serviceable parts inside.
- Do not use this product outdoors.
- Do not expose the product to rain, moisture, or other liquid. Do not handle with wet hands. If the product becomes wet, immediately disconnect from the power source.
- Do not expose the product to heat sources, direct sunlight, or leave in a hot vehicle, which may cause damage.
- Do not expose the product to open flames.
- Do not expose the product to extremely high or low temperatures.
- Do not use this product in a strong magnetic field.
- Do not insert objects other than the intended cable connectors, flash drives, and TF cards into this product.
- Use a clean, soft cloth to clean. Do not use corrosive cleaners or oils.
- This product is not a toy. Keep out of reach of children or those that require supervision.

1

Introduction

Stream high-quality audio and hands-free calls through your car's FM radio using this 18W Bluetooth® FM Transmitter. Connect wirelessly to your Bluetooth device or use the USB/AUX/MicroSD ports to play audio, and charge your devices with the dual USB-A ports. Using the built-in equalizer (EQ), you can boost your bass and treble for a customized sound experience. The 1.8" color display lets you view your audio details, and watch as the EQ bounces to the beat of your music. The transmitter is powered by your car's DC12V/24V port, and you can easily control it with the buttons or voice commands (compatible with Siri® + Google Assistant™).

Features

- Stream music, calls, and other audio through your car's FM radio.
- Wirelessly connect to your Bluetooth® device, or the AUX/USB/MicroSD inputs (AUX cable included)
- Built-In QC 3.0 Fast Charge* (18W) USB-A port to charge your device on the go.
- Adjust the bass and treble with the built-in EQ that bounces to your music in real time
- View your incoming calls, song selection, car battery voltage, and more on the 1.8" color display
- Operate with the buttons or voice control with Siri® or Google Assistant™
- Connects to your car's DC12V/24V port with a 170" folding cigarette plug.

*QC 3.0 port will fast charge QC 3.0 compatible devices. Other phones will charge at the normal charging rate.

2

What's Included

- Wireless FM Transmitter
- 3.5mm AUX cable
- Quick Start Guide

Specifications

- Bluetooth Version: 5.3
- Bluetooth Transmission: Up to 33ft
- FM Frequency Range: 88.1-107.9MHz
- Input Voltage: 12V-24V
- Media Files Supported: MP3/WAV
- Inputs:
 - 3.5mm AUX (includes 1.7ft cable)
 - USB Flash Drive (64GB Max, sold separately)
 - MicroSD Drive (64GB Max, sold separately)
- Outputs:
 - USB-A 1: QC 3.0 (18W Max)
 - USB-A 2: 5V/1A (5W)
 - Max Combined Output: 18W

3

Product Diagram



4

Getting Started

Quick Start

- Remove all of the contents from the package.
- Connect the transmitter's cigarette plug to your vehicle's 12V or 24V port. You can fold the plug up to 170" for a more precise fit.
- The transmitter will automatically power on/off when you turn your vehicle on/off.

Media Playback Options

You can play audio in the following file formats: Bluetooth, MP3, WAV.

Your transmitter comes with the following input ports for media playback:

- AUX port (5.3mm, 1.7ft cable included)*
- USB port for flash drives (64GB Max)
- MicroSD port for MicroSD cards (64GB Max, card not included)

For optimal performance, we recommend pairing the transmitter to your Bluetooth device for wireless audio.

*NOTE: If you are connecting the AUX cord to an iPhone®, you may need an AUX-to-Lightning adapter depending on the model of your phone.

5

Pairing with Bluetooth

- Make sure the transmitter is plugged into your car's 12V/24V port. Turn your car on to power on the transmitter.
 - You will see the word "Unconnected" flashing in red on the display screen. This indicates that the transmitter is ready to be paired.
 - Open the Bluetooth settings on your smartphone and select "Monster MFT2-1000" from the list of available new devices.
 - The transmitter will automatically connect to your smartphone with Bluetooth.
- If you are unable to connect the transmitter to your smartphone, try the following:
- Ensure the speaker and your smartphone are turned on, and that your smartphone is fully charged.
 - Make sure your smartphone's Bluetooth setting is switched on.
 - Restart your smartphone.

6

Setting the FM Frequency

To stream audio through your car's FM radio station, you will first need to align the FM frequency on the transmitter and your car.

TIP: For the best audio quality, choose an FM frequency that is not used frequently. This varies by location, so we recommend checking which FM frequencies are least used in your area before setting your transmitter.


- Make sure your transmitter is powered on and connected to your device via Bluetooth, or that your audio is connected to one of the input ports.
- Choose which FM frequency you would like to use. Navigate to this frequency on your car's FM radio.
- NOTE:** The transmitter can be set between 88.1-107.9 FM.
- Find the matching FM frequency on your transmitter using the (CH+) and (CH-) buttons (for faster scrolling, press either the CH+ or CH- button one time to enter FM Search Mode, and then use the Multifunction Dial).
- When the FM frequency on your car radio matches the FM frequency on your transmitter, your audio will play through your car's stereo. You can now control the playback using your transmitter, your car stereo buttons, your smartphone, or voice commands.

IMPORTANT: Having trouble streaming audio through your car's stereo? See the troubleshooting section for help.

7

Operations

Display Diagram



8

Key Functions

POWER ON/OFF:

- Turn your vehicle on/off.
- Insert or remove the transmitter into/from your car's 12V/24V port.

CHANGE FM FREQUENCY:

- Long press the (CH+) and (CH-) buttons.
- Use the Multifunction Dial (you must press the CH+/CH- button one time to enter FM Search Mode).

NOTE: When changing the FM frequency on the transmitter, you must also adjust the frequency on your FM radio to match it.

ACTIVATE SIRI® / GOOGLE ASSISTANT™:

- Long press the "Next Song" button(▶▶) to activate voice control. When you release the button without using the voice assistant function, it will automatically exit within 5 seconds.
- If you accidentally activate the voice assistant, simply press the "Next Song" button(▶▶) to exit.

Audio Controls

This transmitter features an EQ with an adjustable treble and bass.

ADJUST THE VOLUME:

- Use the Multifunction Dial.

9

ADJUST THE BASS:

- Press the BASS button one time to enter bass adjustment mode.
- Once you are in bass adjustment mode, use the Multifunction Dial, (CH+)/(CH-), or (◀▶)/(▶▶) to change the bass to your desired level.
- When you are done adjusting the bass, press the BASS button one time to exit bass adjustment mode.

ADJUST THE TREBLE:

- Press the TREBLE button one time to enter treble adjustment mode.
- Once you are in treble adjustment mode, use the Multifunction Dial, (CH+)/(CH-), or (◀▶)/(▶▶) to change the treble to your desired level.
- When you are done adjusting the treble, press the TREBLE button one time to exit treble adjustment mode.

CHOOSE FROM PRE-SET EQ MODES:

- This transmitter comes with 6 preset EQ modes with custom bass and treble levels: Normal, Rock, Popular, Classical, Jazz, and Country. To choose a new mode:
 - Press + hold the Multifunction Dial to reach the settings page.
 - Use the Multifunction Dial to scroll to EQ Mode and press the Multifunction Dial one time.
- Once you are on the EQ Mode screen, use the Multifunction Dial to scroll to your desired preset EQ setting and press the Multifunction Dial one time to select it.

NOTE: The EQ mode you've selected will show as an icon on the main display.

NOTE: The EQ mode you've selected will show as an icon on the main display.

10

Music Controls

PLAY/PAUSE MUSIC: Press the Multifunction Dial.

PREVIOUS/NEXT SONG: Use the (◀▶)/(▶▶) buttons.

Call Controls

ANSWER AN INCOMING CALL/END A CALL: Press the Multifunction Dial one time.

REJECT AN INCOMING CALL: Press + hold the Multifunction Dial.

CONCEAL PHONE NUMBER: To hide a phone number from showing on your display during a phone call, press + hold the Multifunction Dial during the call.

REDIAL PREVIOUS NUMBER: Double-press (press two times) the Multifunction Dial.

11

Troubleshooting

Q: My transmitter is not turning on.

A1: Make sure the transmitter is inserted fully into your car's 12V/24V port.

A2: Make sure your car engine is running.

A3: Manually turn the transmitter on by pressing + holding the TREBLE button.

A3: Try plugging the device into a different socket, or test another device with a cigarette plug to ensure your 12V/24V port is working properly. If your issue is not resolved, contact the manufacturer.

Q: My transmitter is connected to my Bluetooth device, but I am not hearing my audio.

A1: Make sure the FM frequency on your radio matches the FM frequency set on your transmitter.

A2: Make sure the volume is turned up on your smartphone, car stereo, and transmitter. For best results, you may need to maximize the volume on your smartphone.

Q: My USB drive / MicroSD card isn't playing my audio.

A1: Place your audio into the root directory of the USB drive or MicroSD card. DO NOT copy audio inside folders or sub-folders. This transmitter may not recognize music stored in multiple folders.

12

A2: Make sure the FM frequency on your radio matches the FM frequency set on your transmitter.

Q: There is static or overlapping audio when I play my audio.

A1: This often happens when the transmitter is set to an FM frequency that is already being used by a local radio station. To ensure a clear signal from the transmitter to your radio, choose an FM frequency that is NOT broadcasting audio in your area. This varies by location, so look up the best frequencies to use in your location.

A2: Try turning up the volume on your smartphone or Bluetooth device to maximum, and then fine-tune it using your car stereo dials. Operating the volume with the car stereo alone is more likely to cause static in the audio.

Q: The volume is too low.

A1: Increase the volume of your smartphone or Bluetooth device. You may need to increase it to maximum volume. If the volume is still low, turn up the volume using your car's stereo dials.

A2: If you increase the volume and only static comes through, choose a new FM frequency.

13

Jem Accessories, Inc. Limited Warranty Policy for Monster Products Last Updated: March 27, 2020.

This limited warranty contains important information about your rights and obligations, as well as limitations and exclusions that may apply to you.

1. WHAT THIS LIMITED WARRANTY COVERS: PERIOD OF COVERAGE: Jem Accessories, Inc. ("Jem Accessories"), 32 Brunswick Ave, Edison, New Jersey, USA, warrants to the owner of the enclosed Monster branded product contained in this box ("Product") will be free from defects in materials and workmanship for a period of one year. Notwithstanding the foregoing, the Warranty Period for a factory refurbished Product is one (1) year, even if installed by a professional. If the Product fails to conform to this Limited Warranty during the Warranty Period, Jem Accessories will, at its sole discretion, either (a) repair or replace any defective Product or component, with proof of purchase using original documentation. Repair or replacement may be made with a new or refurbished product or components, at Jem Accessories's sole discretion. If the Product or a component incorporated within it is no longer available, Jem Accessories may, at Jem Accessories's sole discretion, replace the Product with a similar product of similar function. This is your sole and exclusive remedy for breach of this Limited Warranty. Any Product that has either been repaired or replaced under this Limited Warranty will be covered by the terms of this Limited Warranty for the longer of (a) ninety (90) days from the date of delivery of the repaired Product or replacement Product, or (b) the remaining Warranty Period. This Limited Warranty is not transferable from the original purchaser to subsequent owners.

2. TOTAL SATISFACTION RETURN POLICY: If you are the original purchaser of the Product and you are not satisfied with this Product for any reason, you may return it in its original condition to the retailer in compliance with the retailer's return policy.

3. WARRANTY CONDITIONS; HOW TO GET SERVICE: IF YOU WANT TO CLAIM UNDER THIS LIMITED WARRANTY Before making a claim under this Limited Warranty, the owner of the Product must (a) visit monsterbluetooth.com/support during the Warranty Period to provide notice of your warranty claim and describe the alleged failure, and (b) comply with Jem Accessories (or its authorized distributor's) return shipping instructions. Jem Accessories will have no warranty obligations with respect to a returned Product if it determines, at its reasonable discretion after examination of the returned Product, that the Product is an Indefinite Product (defined below).

4. WHAT THIS LIMITED WARRANTY DOES NOT COVER: This Limited Warranty does not cover the following (collectively "Indefinite Products"): (i) Products marked as "sample" or "Not for Sale"; or sold "AS IS"; (ii) Products that have been subject to: (a) modifications, alterations, tampering, or improper maintenance or repairs; (b) handling, storage, installation, testing, or use not in accordance with any quick start guide, manual or other instructions provided by Jem Accessories; (c) abuse or misuse of the Product; (d) breakdowns, fluctuations, or interruptions in electric power or the telecommunications network; or (e) Acts of God, including but not limited to lightning, flood, tornado, earthquake, or hurricane; or (iii) any non-Jem Accessories branded hardware products, even if packaged or sold with Jem Accessories hardware. This Limited Warranty does not cover consumable parts, including batteries, unless damage is due to defects in materials or

14

workmanship of the Product, or software (even if packaged or sold with the product). Jem Accessories recommends that you use only authorized service providers for maintenance or repair. Unauthorized use of the Product or software can impair the Product's performance and may invalidate this Limited Warranty.

5. DISCLAIMER OF WARRANTIES: Except as stated above in this limited warranty, and to the maximum extent permitted by applicable law, Jem Accessories disclaims all express, implied, and statutory warranties and conditions with respect to the product, including the implied warranties of merchantability and fitness for a particular purpose. To the maximum extent permitted by applicable law, Jem Accessories also limits the duration of any applicable implied warranties or conditions to the duration of this limited warranty.

6. LIMITATION OF DAMAGES: In addition to the above warranty disclaimers, in no event will Jem Accessories be liable for any consequential, incidental, exemplary, or special damages, including any damages for lost data or lost profits, arising from or relating to this limited warranty or the product, and Jem Accessories' total cumulative liability arising from or related to this limited warranty or the product will not exceed the amount actually paid for the product by the original purchaser.

7. LIMITATION OF LIABILITY: The Jem Accessories online services at monsterbluetooth.com ("services") provide you information ("product information") regarding your Jem Accessories products or other peripheral connected to your products ("product peripheral"). The type of product peripheral that may be connected to your product may change from time to time. Without limiting the generality of the disclaimers above, all product information is provided for your convenience, "as is" and "as available." Jem Accessories does not represent, warrant, or guarantee that product information will be available, accurate, or reliable or that product information or use of the services or product will provide safety in your home.

You use all product information, the services, and the product at your own discretion and risk. You will be solely responsible for (and Jem Accessories disclaims) any and all loss, liability, or damages, including to your wiring, fixtures, electricity, home, product, product peripheral, computer, mobile device, and all other items and pets in your home, resulting from your use of the product information, services, or product. Product information provided by the services is not intended as a substitute for direct means of obtaining the information. For example, a notification provided through the services is not intended as a substitute for audible and visible indications in the home and on the product, nor for a third party monitoring service that monitors alarm state.

8. YOUR RIGHTS AND THE LIMITED WARRANTY: This Limited Warranty gives you specific legal rights. You may also have other legal rights that vary by state, province, or jurisdiction. Likewise, some of the limitations in this Limited Warranty may not apply in certain states, provinces or jurisdictions. The terms of this Limited Warranty will apply to the extent permitted by applicable law. For a full description of your legal rights you should refer to the laws applicable in your jurisdiction and you may wish to contact a relevant consumer advisory service.

If you need to start a warranty claim for your Monster Smart device, please reach out to Customer Support by emailing customerservice@monsterbluetooth.com or calling our support number 866-246-2008. Please allow 7-10 business days to process warranty claims. Customers located outside of U.S. will be responsible for all shipping costs.

15

FCC Compliance Notice

Changes or modifications not expressly approved by the party responsible for compliance could void this user's authority to operate this device.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

FCC RADIATION EXPOSURE STATEMENT

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

16

MONSTER

The illustrated products and specifications may differ slightly from those supplied. The M Monster logo is a registered trademark of Monster, Inc. or its subsidiaries in the U.S. and other countries and are used under license. Google, Android, Android Auto and Google Play are trademarks of Google LLC. Apple, Apple CarPlay, and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries. All other brand names are trademarks of their respective owners. Neither Jem Accessories, Inc. nor Monster, Inc. is affiliated with the respective owners of their trademarks. Licensed and Manufactured by Jem Accessories, Inc. Edison, NJ 08817.

17