



INTRODUCTION

Thank you for your purchasing of the True Wireless LED Earbuds & Charging Case. This unit is perfect for hands-free calling, music.



- 1 CHARGING CASE

2 POWER INDICATOR

3 RIGHT EARBUD

4 LEFT EARBUD

5 EARBUD STATUS INDICATOR

6 CHARGING CONTACT
- 7 LEFT EARBUD POWER INDICATOR

8 RIGHT EARBUD POWER INDICATOR

9 MULTI-FUNCTION BUTTON (MFB)

10 EARBUD SOFT SILICONE TIP

SPECIFICATIONS

Power input:5V/1A
Charging time(earbuds):1.5 hours
Charging time(Charging case): 2.0 Hours
Playtime(Earbuds): 5 Hours
Playtime(with Charging case):16 Hours
Battery type: Earbuds 30MAh, charging Case 500MAh


WHAT'S INSIDE

- LED Earbuds
- Interchangable Earbuds Tips (S,M,L)
- Charging Case
- USB-C Cable
- User Manual

FEATURES

- True wireless Bluetooth 5.3® stereo earbuds and pocket sized RGB charging case with LED indicator
- Touch control on earbudsfor play/pause & answering phone calls
- Earphones can be used as a single use earbuds or as a pair
- Wirelessly recharge your earbuds with included charging case
- Portable and lightweight

GETTING TO KNOW YOUR PRODUCT



SMART TOUCH CONTROLLED EARBUDS

Multi fuction sensor allows turn on/off, play & pause your music or answer/end calls and use voice prompt with one simple touch.

WEARING YOUR EARBUDS

- Secure earbud tips on earbud.
- Secure earbuds in ear.

CHARGING THE CHARGING CASE

Insert the included USB-C cable to your charging source. When charging starts the last digit of the battery below 100% flashes & the LED lights go on for 30 seconds.

- **Charging:** The last digit of the battery below 100% flashes
- **Fully charged:** The charging case power indicator will read 100%

Note: When not in use the device will automatically shut down after 5 minutes.

BATTERY LOW WARNING

When battery is low, the charging case will slowly blink green every 30 seconds and the charging case power indicator will show the exact percentage of charge.

CHARGING THE EAR BUDS

Simply place your earbuds in the correct position in the charging case to start recharging. When charging, the charging case LEDs will light up in addition to green lights from the earbuds as well.

POWERING THE EARBUDS ON/OFF

Your earbuds will power on automatically when picked up from the charging case, no manual touch needed.

BLUETOOTH PAIRING

When the earbuds are picked up from the charging case, it is instantly in pairing mode. Search for “Xtreme XBE9-0136” on intended Bluetooth device. When successfully connected, you will here a sound.

CALL MODE

Answer/End a call	Short press MFB
Reject a call	Press MFB for 2 sec

VOICE ASSISTANT MODE

Activate voice assistant	Double click on the left or right ear to touch the function key
Exit voice assistant	Double click on the left or right ear to touch the function key

android® iphone® compatible

MUSIC MODE

Play/Pause	Short press MFB
Next track	Press the right ear MFB key three times
Previous track	Press the left ear MFB key three times

TROUBLESHOOTING

If you are unable to connect your earbuds to your bluetooth device, please try the following steps:

- Ensure your earbuds are turned on and fully charged
- Make sure your bluetooth setting is on
- Restart your bluetooth device

TIPS

- Turn off your earbuds before placing it in your pocket or bag, if the MFB is accidentally activated, you may place an unintended call
- Performance can be affected by the environment
- Interruption can be caused by obstacles between the earphones and the Bluetooth device, by wi-fi or other high frequency signals, or if the earphones are brought out of range of the Bluetooth device (approx. 33 ft)
- To maintain healthy battery performance, charge the charging case (and earphones) periodically, if not in use
- Once turned off, only way to turn on is to place and displace earbuds from the charging case'
- When only using 1 earbud, call mode functions are disabled

SAFETY AND CARE INSTRUCTIONS:

This product contains a non-replaceable rechargeable lithium-ion battery. When discarding, follow your local/state guidelines.

- Do not use abrasive cleaning solvents to clean the unit.
- Disconnect the USB cable once the product is fully charged.
- Do not expose to heat sources or leave in a location that is likely to get excessively hot.
- Do not let the product get wet.
- Do not disassemble.
- Performance can be affected by the environment or when the product becomes discharged.

Accordion-Fold Defined, black and white



• Interruption can be caused by obstacles between the product and the Bluetooth device, by Wi-Fi or other high frequency signals, or If the product is brought out of range of the Bluetooth device.

• Charge fully before storing for a long period. Note: Lithium-ion batteries will self-discharge over time.

To ensure battery life, do not store the product in an uncharged state for a length of time. If left in a discharged state for too long a lithium-ion battery will no longer have the ability to be recharged.

FCC STATEMENT

Any changes or modifications not expressly approved by the part responsible for compliance could void this user’s authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

FCC RADIATION EXPOSURE STATEMENT

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.



FCC ID: 2AHAS-XBE90136

ONE YEAR LIMITED WARRANTY

Xtreme warrants its products for one year against defects in manufacturing under regular consumer use with original receipt of retail purchase. We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt. *Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.

Xtreme’s warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact **Customer Service:**
customerservice@xtremecables.com



TRUE WIRELESS STEREO
EARBUDS
AND CHARGING CASE

COLOR CHANGING LEDS

User Manual
XBE9-0136, XBE9-0136-BLK
1123 V1.0

855.999.8041 | WWW.XTREMECABLES.COM