

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

5

Xtreme warrants its products for one year against defects in manufacturing under regular consumer use with original receipt of retail purchase.

We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty, please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt.

*Any customers outside of the U.S. will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied.

Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property.

For instructions about how to obtain warranty service for your product, please contact Customer Service:


customerservice@xtremecables.com

3 in 1 Foldable Wireless Charger
3.28ft Type-C to Type-C Charging Cable
20W PD Home Charger
User Manual

Input Interface: 3A USB Type-C Cable
Input Charging Cable: Type-C to Type-C 3A Cable
Input: 5V/2A 9V/2A
Phone Output: 5W/7.5W/10W
Airpods® Output: 5W
Apple Watch® Output: 2.5W
Total Output: 17.5W

Input: 100-240VAC, 50-60Hz, 0.5A
Output: 5V-3A, 9V-2.22A 12V-1.67A 20W Max

6



Wirelessly charge your Qi compatible smartphone, Apple Watch® and AirPods® with this charging station or can be folded for single-device charging. Powered using the included 20W PD Type-C wall home charger.

Works with: Qi compatible smartphones, Apple Watch® and AirPods®

- Place the wireless charging pad on a flat surface.
- Connect the included Type-C charging cable to the charging pad's Type-C port and the other end of the cable to the included 20W PD home charger. The charging pad will power on, and the two LEDs on the center pad will illuminate red.

Note: For proper operation it is recommended to use the supplied Type-C cable for supplying power to the charging station. Other Type-C cables' ratings may not match the charging stations power supply requirement.

The product is designed to charge Qi-enabled wireless charging phones, Apple watches, and AirPods charging cases. However, it will also charge various other Qi charging devices.



2

- To charge an iPhone or other Qi compatible wireless charging mobile phone, place it flat on the, left mobile phone charging pad area. The LED on the left side of the center pad will turn blue and the phone will start charging. When the phone is fully charged, the LED will turn red.
- To charge an Apple watch, place it over the charging disc on the center watch phone charging pad. It will start charging immediately. Charge the Apple watch flat or with the charging disk in the fully vertical upright position. For effective charging, do not charge with the charging disk at other angles. Monitor the watch's charging indication to identify when the watch is fully charged. The LEDs will remain red and will not change color during watch charging.
- To charge AirPods, place the AirPods in their Wireless Charging Case and place the case flat on the right AirPods charging pad. The LED on the right side of the center pad will turn blue and the AirPods case will start charging. When the case is fully charged, the LED will turn red.

After charging remove the phone, watch, and/or AirPods case from the wireless charging mat.

Other Qi compliance wireless charging products can be charged on the phone charging and AirPods wireless charging pads.

Charging times will depend on the specific device and its battery capacity. However typical charging times are 3.5 hours for a mobile phone, 2 hours for an AirPods case, and 2 ½ hours for an Apple Watch. The charging times are for general reference only.

To prevent damage to the phone or the charger:

- Remove metal cases, or cases with any magnet/metal components, from phone before charging.

3

- Do not place metal objects on the charger during charging.
 - Qi wireless chargeable phones with metallic looking finishes will charge normally.
- Note:** Very thick phone cases can obstruct wireless charging. For effective charging, it may be necessary to reposition the phone or remove the case.
- TIPS AND PRECAUTIONS:**
- Read all the instructions before using the product, and use the product as intended.
 - Keep close supervision of this product if being used around children.
 - Do not expose to rain or moisture, and do use near water such as swimming pools, bathtubs, or sinks.
 - Do not expose to heat sources, the sun, or leave in a hot vehicle.
 - Do not dispose of in a fire.
 - Do not place metal items on the surface of the product.
 - Do not cover the product with paper or other materials. Use in a well-ventilated area when charging.
 - Wireless chargers generate heat when charging, and the charge may temporarily stop charging if it gets too hot.
 - Do not disassemble, modify, or try to use for a non-intended purpose, and do not use if damaged or modified. Never insert objects other than the specified cables into the product.
 - Do not place magnetic strip cards or similar magnetically sensitive item between the phone and the charger. Wireless charging uses magnetic induction that could damage these items.
 - Consider tuning off your phones vibrating notifications during charging, as vibrations may cause your phone to shift position on the charger and stop charging.
 - Disconnect the USB cable once the products are fully charged.
 - Do not use abrasive cleaning solvents to clean the unit.

Note: Very thick phone cases can obstruct wireless charging. For effective charging, it may be necessary to reposition the phone or remove the case.

- Read all the instructions before using the product, and use the product as intended.
- Keep close supervision of this product if being used around children.
- Do not expose to rain or moisture, and do use near water such as swimming pools, bathtubs, or sinks.
- Do not expose to heat sources, the sun, or leave in a hot vehicle.
- Do not dispose of in a fire.
- Do not place metal items on the surface of the product.
- Do not cover the product with paper or other materials. Use in a well-ventilated area when charging.
- Wireless chargers generate heat when charging, and the charge may temporarily stop charging if it gets too hot.
- Do not disassemble, modify, or try to use for a non-intended purpose, and do not use if damaged or modified. Never insert objects other than the specified cables into the product.
- Do not place magnetic strip cards or similar magnetically sensitive item between the phone and the charger. Wireless charging uses magnetic induction that could damage these items.
- Consider tuning off your phones vibrating notifications during charging, as vibrations may cause your phone to shift position on the charger and stop charging.
- Disconnect the USB cable once the products are fully charged.
- Do not use abrasive cleaning solvents to clean the unit.

4