

XTREME™ L I T		PRINTER SLUG FOR TECH PACK	
BRAND: XTREME		ADDITIONAL PRINTING PROCESSES:	
CATEGORY: POWER		UV SPOT: GLOSS	
PRODUCT NAME: XWC8-1050-BLK		METALLIC FOIL:	
FILE NAME: XWC8-1050-BLK_UserManual		DEBOSS:	
ITEM NUMBER: XWC8-1050-BLK		EMBOSS:	
		VARNISHING TECHNIQUE: MATTE LAMINATION	
PRESS WORK: PRINT 1/1. TRIM TO SIZE, SCORE, FOLD WHEN SPECIFIED		PRESS SPEC COLOR REFERENCES	
SCALE: 100%		DIELINE	
ASSEMBLED PACKAGE DIMENSIONS (in Inches)		GLOSS UV SPOT	
WIDTH: 3"		EMBOSSING (RELIEF)	
HEIGHT: 4.9"		DEBOSSING (SUNKEN)	
DEPTH:		FOLDING LINE	
DIELINE OVERALL DIMENSIONS (in millimeters)		PRODUCT PLACEMENT	
WIDTH: 78.065mm		FOILING	
HEIGHT: 124.873mm		GLUE FOLD	
MANUAL MATERIAL, THICKNESS & SIZE		Ø20mm SECURITY STICKERS PLACEMENT	
SUBSTRATE TYPE:		BLISTER OR INNER TRAY PLACEMENT	
MATTE ART PAPER C2S, 100gsm		CLOTH LIFT TAG	
WINDOW:		ADDITIONAL PANTONE COLORS (NOT CMYK)	
INNER TRAY:		SOLID COLOR NAME:	
BLISTER:		NEON COLOR NAME:	
PLASTIC BAG:		METALLIC COLORS:	
MAGNET:		VENDOR'S FOIL NAME/NUMBER:	
VELCRO:		FILE SAVED AS:	
SECURITY STICKERS:		.ai = FULLY EDITABLE	
HANG TAB COLOR/ MATERIAL/ SIZE:		-OUT.ai = OUTLINED	
FOAM		.pdf = Acrobat	
CORRUGATED BOARD:		.jpg = Flat Image	
PAPERBOARD:		.png = DIGITAL (transparent background)	
USER MANUAL: PRINT 1/1 IN BLACK ONLY		APPROVAL CHECKLIST:	
PACKAGING TYPES		PRIMARY DESIGNER: Rita Manukyan	
FOLDING CARTON:		DATE: 05/15/25 Update: 08/08/2025	
FOLDING CARTON WITH DOOR PANEL:		SECONDARY DESIGNER:	
RIGHT GIFT BOX:		DATE:	
CLAMSHELL:		PROOF READ:	
SLIDING/SLIPCASE:		DATE:	
TRAPPED BLISTER CARD		APPROVED BY:	
BLISTER CARD:		DATE:	
OTHER:		AUTHORIZATION	
		SIGNATURES:	

Press Ready Artwork.

DO NOT PRINT THIS LAYER:
Printer Slug

PRINTABLE LAYER:
Manual Artwork

When folded, please make sure that this
title page is visible and not folded inside.

FRONT PAGE

FCC STATEMENT Any changes or modifications not expressly approved by the party responsible for compliance could void this user's authority to operate the equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does not cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct interference by one or more of the following measures: • Reorient or relocate the receiving antenna • Increase the separation between the equipment and receiver • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected • Consult the dealer or an experienced radio/TV technician for help FCC Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body  4	ONE YEAR LIMITED WARRANTY Xtreme warrants its products for one year against defects in manufacturing under regular consumer use with original receipt of retail purchase. We believe in our products and want to provide you with a replacement, if needed, but we have to know about the problem while the product is still under warranty. If you discover a defect covered by this warranty please contact us about receiving a replacement. In order to use the products warranty the customer must provide proof of the retailers receipt. *Any customers outside of the US, will be responsible for shipping and handling charges if a replacement is required that is not due to a manufacturing defect. If there is not a manufacturing defect, shipping and handling will be applied. Xtreme's warranty is limited to our products only. Our warranty does not cover the replacement or repair cost of any third-party accessory, electronic device or personal property. For instructions about how to obtain warranty service for your product, please contact Customer Service: customerservice@xtremecables.com EXTEND YOUR WARRANTY Scan the QR code below, or on the front of this manual to extend your warranty from 1 Year to 2 Year Limited.  Scan to Extend Your Warranty 5	XTREME™ POWER <i>Wireless Charging</i> ORGANIZER TRAY  XWC8-1050-BLK User Manual V1.0 0625 855.999.8041 WWW.XTREMECABLES.COM  Scan to Extend Your Warranty
--	--	---

BACK PAGE

SAFETY AND CARE INSTRUCTIONS Read all the instructions before using the product and store them for future reference. Failure to follow these safety instructions could lead to fire, electrical shock, personal injury, property damage, or damage to the product. • Do not expose to rain, moisture, or other liquid. Do not use near water such as swimming pools, bathtubs, or sinks. If the product becomes wet, immediately unplug from power source. Do not handle the product, USB cord, or wall adapter with wet hands. • Do not charge or use the product if it has been submerged in water, or if water has gotten inside the product. • Do not use this product in temperatures that exceed 133°F. • Do not expose to heat sources, the sun, or leave in a hot vehicle. Do not dispose of product in a fire. • Do not expose the product to extremely high or low temperatures. Prolonged exposure to extreme heat or cold reduces battery longevity. Exposure to fire or temperatures above 170°F could cause serious damage and explosion. • Do not drop. • Do not disassemble, there are no serviceable parts inside. • Do not modify or try to use for a non-intended purpose. • Do not use if damaged or modified or if you see any bulging, swelling, leakage, or other abnormality. Damaged or modified batteries may exhibit unpredictable behavior resulting in fire, explosion, or risk of injury. • Do not place the product anywhere that it would become crushed or punctured. • Never insert objects other than the specified cables into the product. • Do not use the charger more than its output rating. Overloading outputs above the rating may result in a risk of fire or injury. • Charge using the correct wall charger, and make sure the charger is inserted all the way into the electrical outlet. • Place the charger on a flat, sturdy surface during charging. Charge in a well-ventilated area and make sure it is not covered with any material. Wireless chargers generate heat when charging, and the product may temporarily stop charging if it gets too hot. • Disconnect the product once your device is fully charged. • This product is not a toy. Keep out of reach of children or those that require supervision. • Do not use abrasive cleaning solvents to clean the product. 1	INTRODUCTION Thank you for choosing the Xtreme Wireless Charging Organizer Tray! Refuel your wireless-compatible device while you work with this 15W wireless charger has a built-in storage tray, it's the perfect, two-in-one solution to keep your devices fully fueled while you reduce clutter around your home or office. FEATURES • 15W Wireless Fast Charge* • Dual Design (Charge + Organize) • Smudge-Free Design • Compatible with iOS and Android *For maximum fast charging, you will need an 18W QC 3.0 wall adapter or a USB-C to USB-C cable with a PD 2.0 wall adapter (sold separately). Please check your device's specifications for maximum charging speed capability. SPECIFICATIONS • Dimensions: 132 x 846 x 343 in • Dimensions (Tray Only): 846 x 748 x 31 in • USB-C Input: 5V/3A, 9V/2A • Wireless Charging Output: 5W / 7.5W / 10W / 15W MAX WHAT'S INSIDE • 15W Wireless Charging Organizer Tray • 3ft USB-C to USB-A Cable • User Manual 2	CHARGING OTHER DEVICES USB-C Charging Port + LED Indicator Light  Storage Tray 15W Wireless Charger • Plug the included USB-C cable into the product's USB-C charging port. Plug the other end into a USB outlet or wall adapter (sold separately). The charger will automatically power on once it is plugged in, and the LED indicator light will turn solid red. • Place your compatible smartphone or device on the charging area. The LED indicator light will flash green to indicate your device is charging. • When your device is fully charged, the LED indicator light will turn solid green. NOTE: The LED indicator light will flash red if a foreign object is detected in the charging area. If this happens, remove any objects on the charging area and attempt to charge your device again. TIPS • For best performance, remove any bulky or thick cases from the device you are charging. • Do not place metal debris or magnetic cards on the charger, as it may cause overheating. • Slight heating during charging is normal. • Keep the charger away from fire sources or corrosive environments. • Avoid obstructing the wireless charging area with metal objects or thick phone cases. • Do not attempt to disassemble or modify the charger. • Keep the charger away from water and moisture to prevent damage. 3
---	--	---