





Basic Information

Product Name	TWS earphones
Model No	F15
Type	Half in-ear
Bluetooth	V5.0
Bluetooth Profile	AVRCP/A2DP (SBC) /HFP
Bluetooth distance	>10m
Frequency	20Hz-20KHz
Speaker size	Φ13mm
Sensitivity	112.5±3dB
Earbuds Battery	25mAh
Charging Case Battery	250mAh
Playing Time	Earbuds: 3H With Charging case : 12H
Type< Input	DC 5V==500mA
Earbuds Charging Time	1.5H
Case Charging Time	1.5H
Net weight	41G




Power on

Take out earbuds from charging case and then long touch 3 seconds

Power off


Put into charging case
Long touch 5 seconds
Turn off the device after 5 mins without connecting the earphones



PAIRING

1. Take out earbuds from charging case
2. Turn on your mobile phone's Bluetooth and search for the pairing name;
3. Select 'F15' and connect to it
4. After Pairing successfully, earphone play prompt voice 'connect'

Wearing Method



Operation	Left/Right
Power On/Power Off	Long press 3S/Long Press 5S
Play/Pause	Click
Previous/Next	Double Click
V+/V-	Triple-click
Answer/Hang up	On Call: Click
Reject	On Call: Long press 1.5S
Siri Voice Assistant	Long Press 1.5S

Earbuds Indicator Light	
Power on	Blue light flash 3times
Power off	Red light flash 3times
Pairing	Main earbuds: Red&Blue lights flash alternately; Vice Earbuds: Light off
Connect	Light off
Charging	Blue light on
Charge Over	Red light off
Charging Case Indicator Light	
Charging	Red light flash
Charge Over	Red light on
Earbuds Charging	Battery > 10%: Blue light on Battery < 10%: Blue light flash
Earbuds Charging over	Blue light off

Attentions

- Please store and use this product in normal temperature environment;
- Do not expose the product to rain or wet environment;
- Do not throw, to avoid product damage caused by falling;
- Do not disassemble, repair and transform the product;
- Do not use chemical solvent to wipe the product;
- Do not discard or put in high temperature (temperature above 60 degrees) and fire, so as not to cause danger.

Warranty Card

Client Name _____
Client Telephones _____
ADDs(incl post code) _____
BuyingDate _____
Vendor _____
Vendor Adds(incl post code) _____
Vendo Telephone _____

Warranty Service

1. In the course of normal use of the product, if the product is not damaged by human performance failure, from the date of purchase, consumers enjoy free warranty service, warranty period of 12 months;
2. Consumers cannot enjoy the free warranty rights under the following circumstances:

- Man-made damage
- Out of warranty period;
- Can not provide a valid proof of purchase
- At the end of the manual according to the requirements of use, maintenance, maintenance caused by product damage;
- Unauthorized disassembly, maintenance of the product or product water;
- Other damage caused by force majeure.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.