

EARPHONE MANUAL



TRUE WIRELESS TWS BLUETOOTH

(二) BASIC INFORMATION

1	Product Name	True Wireless TWS Bluetooth Earphone
2	Model	G11
3	Wear way	Half in-ear
4	Bluetooth version	Bluetooth 5.0
5	Support agreement	HSP/HFP/A2DP(SBC,ACC)/AVRCP
6	Frequency range	2.400GHz-2.483GHz
7	Transmission range	15m
8	Frequency response range	20Hz-20KHz
9	Microphone sensitivity	-42db $\pm$ 3db
10	Earphone capacity	30mAh
11	Charging box capacity	400mAh
12	Speaker impedance	32 Ω
13	Rated power	3mW
14	Driver element	13mm
15	Play time	About 3.5 hours + Charging box 5 cycle
16	Stand-by time	About 100 hours

3

Answer/hang up	Click the left/right
Reject	Long press the left/right for 1.5 seconds

3. Siri/Assistant

Wake up Siri/Assistant	Long press the left/right for 2 seconds
------------------------	---

4. Game/music mode

Game/music mode	Three-click the left
-----------------	----------------------

5. Light on/off

Light on/off	Three-click the right
--------------	-----------------------

4. Long press the left/right function key for 5 seconds to shut down, Long press the left/right function key for 2 seconds to power on, Put it in the charging case, close the cover, turn off the headset and charge,

5. not connected Automatic shutdown in 3 minutes

(五) WARNING TONE

POWER ON	WHITE LIGHT ON FOR 2 SECONDS
----------	------------------------------

5

(一) PRODUCT PHOTO



2

17	Charge current	DC 5V-300mA
18	Earbud charging time	About 1.5 hours
19	Charging box charging time	About 2 hours
20	Net weight	50g (including charging box)

(三) EQUIPMENT PAIRING

1. Set > Bluetooth > Open > Wait for scanning to find the device
2. Choose " G11 "
3. After pairing is successful, earphones will play the notification sound of successful connection

(四) COMMON OPERATION INSTRUCTIONS

Play/Pause	Click the left/right
Previous/next	Previous song: Double-click the left Next song: Double-click the right

2. Function definition in call state

4

Pairing status	Main earphone color breathing light, Sub-headphone white light flash time 5 seconds
Connection Status	Music pause: Lights off, play music: Color breathing light
Incoming call	White light flashes 2 times
Power off	Red light on for 2 seconds

(六) CHARGING BOX LIGHT & KEY

Open	battery power > 10% Color lights on for 10 seconds
Close	battery power < 10% Red light breathe for 10 seconds
Short press	Wake up light
Open the lid and press for 3 seconds	Blue light breathing Headphone pairing status(Put the earphones in the charging box)
Open the lid and press for 10 seconds	Green light on Headphone reset(Put the earphones in the charging box)

6

PRECAUTIONS

- Do not expose the product to rain or wet environment;
- Do not throw, to avoid product damage caused by falling;
- Do not disassemble, repair and transform the product;
- Do not use chemical solvent to wipe the product;
- Do not discard or put in high temperature (temperature above 60 degrees) and fire, so as not to cause danger.

(七) WARNING

In the process of using this product, please follow the safety precautions and use this product correctly to avoid personal injury, death and material damage. Please follow the following safety precautions to avoid fire, overheating, chemical leakage and explosion accidents:

- ① In order to reduce the risk of fire or battery damage, please do not let the product get wet or wet;
- ② In order to reduce the risk of fire, do not use blankets, blankets and other flammable items to cover the product;
- ③ In order to prevent product damage, it is strictly prohibited to disassemble the equipment, maintenance please consult the equipment after-sales service department;
- ④ Do not use the product under the condition of overheating;

- ⑤ Do not use any battery power supply and accessories other than those specified in this manual;
- ⑥ Do not use homemade batteries or modified batteries.

WARRANTY CARD

Customer name _____
Customer telephone _____
Customer address (including zip code) _____
Purchase time _____
Sales unit _____
Sales unit address (including Zip Code) _____
Sales unit telephone _____

WARRANTY SERVICE

- Man-made damage
- Out of warranty period;
- Can not provide a valid proof of purchase
- Failure to use, maintain or maintain the products according to the instructions;
- Unauthorized disassembly, maintenance of the product or product water;
- Other damage caused by force majeure.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.