

User Guide

Smart Bracelet

ID130HR

Smart Searching

Endless Exploring

Working condition for mobile

 iOS 7.1 & above

 Android 4.4 & above

 Support Bluetooth 4.0

Quick Start Guide

1. Download VeryFitPro app

The smart band need to pair with the smart phone through app. Before downloading, please refer to working condition for mobile.


Way to download 1: Searching the QR code, scan and download app.

Please use the QR code Scan tool to scan the following QR code and open the link and download app. In case there is any problem to open the link, please try to copy the link and open it by browser.

Way to download 2: Search in the phone market and download.


Please search and download the "VeryFitPro" from App Store or Google play store.





2. Device Activate & Charge

Make sure power is working normally before initial use. In case device is under low battery, connect the device to the charger. Device will automatically boot up (please connect the USB in normal DC port (5V-500mA) for charging as below. The host should be separated from the strap when charging).



USB charging port

How to Use

Key Definitions:

Tap: function switch

Long Press: activate, mode switch



Once the device connected to the app successfully, it will record and analyze your activities and sleep automatically, Touch the click toggle, the display order is as follows

1. Normal Mode

Time Mode

MON 01 12:45 PM

Heart rate mode

89

Training Mode

>>>

Step mode

12,000

Distance mode

6.00 KM

Calories Mode

6789

Activity Time Mode

1234 MIN

Alarm mode

12:45 PM

Find Phone

Note: alarm mode and find phone will only be displayed on the screen after switch ON in the APP.

2. Remote Camera Shoot Mode



Put the camera shoot ON in the APP, then device enter in remote shoot screen, control remote photograph shooting with following actions:

(lift wrist sense / tap screen) to shoot a picture.

3. Sport Mode

Sport start Notify mode

3

Stopwatch mode

12:45:45

Heart rate mode

89

Sport Step Mode

16,789

Sport Distance Mode

12.09 KM

Sport Calories Mode

6789

Sport Clock Mode

MON 01 12:45 PM

Long press 1S into the end of the movement

Sport stop Notify mode

3

4. Notification Mode

Incoming call notify

13523600

Message notify

Hello-Hel

Alarming notify

12:45 PM

Sedentary notify

Anti-lost notify

Low-power notify



Charging notify



Charge full notify



Notification Mode instruction :
1.Under incoming call, message notify mode, the screen will still display the last time text and sliding, when there is a new notification coming in.
2. If there is a call or message come, the device will force into call/message alert mode no matter under whatever other mode, after quit, it returns to previous mode.

Functions Instruction

Activities Record:

Record daily activities, you could check daily activities including steps, distance and calorie consumption in the app;

Sleep Monitoring:

Device could automatically recognize your state and monitoring the whole sleep progress with analyzing the deep sleep and light sleep hours;

Notification Alerts:

Alarm alert, call alert, sedentary alert, etc. by silent vibration;

Anti-Lost:

When the smart phone is beyond the Bluetooth range (5m), the device vibrates to remind.

Remote Camera Control:

Operation on the screen could control remote photograph shooting.

Heart Rate Monitoring:

Device monitors your heart rate status and help user make suitable exercise plan.

Device Data Storage:

The activity data will be cleared every 0:00am as a cycle, but the device itself could restore 7 days' data, after 7 days, the data will be cleared. We suggest user to sync data with app at least one time within 7 days during use.

FAQ

Can't find device when pairing device?

Please make sure the smart phone Bluetooth is ON and smart phone OS Android 4.4 & above and iOS 7.1 & above.

Please make sure the device is near the smart phone when pairing (normal 0.5m) and among the normal Bluetooth communication distance range (within 10m).

Please make sure the device is not under low battery. If there is still problem after full charge, please contact us.

Can't connect the device with app?

Some smart phone Bluetooth service will be abnormal when reboot. Please reboot the Bluetooth or reboot smart phone for pairing device.

Basic Specifications

Model:

ID130HR

CPU:

Nordic nRF51822QFAC

Sensor:

KIONIX KX022

HR Sensor:

Silicon labsSii142

Host Weight:

19g

Battery Type:

Polymer Rechargeable Li Battery

Battery Capacity:

45mAh

Data Sync:

Bluetooth 4.0

Working Temperature:

-20℃ - 40℃

Dustproof and Waterproof level:

IP67

Standby:

7days

Frequency bands:

2402-2480MHz

Maximum output power:

3.89dBm

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS



Correct Disposal of this product. This marking indicates that this product should not be dispose other household wastes throughout the EU. To prevent possible harm to the environment or human he from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.