


AGES:10+

PLS KEEP THESE INSTRUCTION FOR FUTURE REFERENCE

INSTRUCTIONS



OFF  ON Adjusting Knob

- 1.Put 3"AA"size batteries into the skateboard and 2"AAA"size batteries into the remote control as pictured.
- 2.Turn the black switch on the bottom of the skateboard to "ON".
- 3.The skateboard is now ready for use.Use the knob on the left side of the remote control to the skateboarder starts to move forward. Use the knob on the right side of the remote control to the skateboarder will rotate 360 degrees and when the skater falls, press the backward button and the skater will get up again.


49.86MHz

ATTENTION - FOR BEST RESULTS:

- 1.Please remove the batteries from the car and the remote control if the product will not be used for a long period of time.
- 2.Please keep the product dry.

⚠ WARNING: TO AVOID BATTERY LEAKAGE

- 1) Be sure to insert the batteries correctly, and always follow the toy/game and battery manufacturers' instructions.
- 2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- 3) Always remove weak or dead batteries from the product.
- 4) Remove the battery if the product is left unused for a long period of time.



FCC ID : 2AHGJJMSYZ3A2-49
FCC ID : 2AHGJJMSYZ3A2-49-1

49.86MHz

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference.
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changers or modifications to this unit not expressly approved by the party responsible for the compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part, 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.