

Artwork Dielines



Prop 65 Required?: Yes ☒ No ☐

Buyer: JG

REVISED

DATE: 10.13.21

BY: MM

Material: 20lb. Plain Paper
Uncoated

Trim Line

Emboss


Fold Line

Spot UV Varnish

Wireless headset

Charging the Earbuds

1. Place both Earbuds into their respective charging ports. If the charging case is charged, the LED's on the case will light up and start charging the Earbuds.
2. When the charging is completed, the Earbuds will show Blue LEDs and the case will show Green.
3. All LEDs will then turn off.



Front View

Main Function Button

Press and hold to power ON.

Press and hold to turn OFF until a voice prompt announces "turning off" both Earbuds and disconnects from your device or place both Earbuds into the charging case and close the lid. This will automatically turn off both Earbuds and disconnect from your device.

Tap once to Play or Pause music or audio.

Tap Left Earbud function button 2 times to turn down the volume and tap 3 times to turn up the volume.

Press and hold the Left Earbud Function button for 3 seconds to return to the previous track.

Main Function Button (cont.)


Press and hold the Right Earbud Function button for 3 seconds to skip to the next track.

Tap either Earbud Function button 3 times to turn on Siri®. Tap once more to turn off Siri®.

LED Battery Lights

Each of the 4 LED's will indicate 25%, 50%, 75%, and 100% charged.

Bottom View



Charging the Case

Using a Micro-USB to USB cable, connect to the USB port of a powered on computer or USB power adaptor (not included) to charge the case.

Linking Earbuds & Pairing Bluetooth

1. Remove both Earbuds from the charging case and they will automatically start searching for a connection from a Bluetooth® enabled device. Connect to "AirBass" on your device's Bluetooth® settings and a voice prompt will announce "Connected".

2. Press and hold down both Function buttons on each of the Earbuds until they start blinking Blue & Red. They will automatically pair with each other, once linked, connect to "AirBass" on your device's Bluetooth® settings and a voice prompt will announce "Connected".

3. Audio played through the connected Bluetooth device will now be heard through both earbuds. Use the controls on the connected device to play audio and adjust volume.

Speakerphone

1. To accept a call, tap the Function button once on either Earbud, or use the controls on the connected device. To end the call, tap the Function button once.

2. To reject the call, press and hold wither Function button for 3 seconds.

PLEASE NOTE: Due to the nature of true wireless earbuds, you may experience slight interruptions with your audio in areas with multiple 2.4Ghz bands or in high wireless traffic areas.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Additional Warnings

- WARNING: To prevent fire or shock hazards, do not expose this unit to rain or moisture.
- WARNING: Where the main plug or appliance coupler is used as the disconnect device, such disconnect device shall remain readily operable.
- Lithium batteries, like all rechargeable batteries, are recyclable and should be recycled or disposed of according to state and local guidelines. They should never be disposed of in normal household waste, and they should never be incinerated, as they might explode. Contact your local government for disposal or recycling practices in your area.
- This product meets and complies with all Federal regulations.
- To avoid hearing damage, make sure that the volume on your music player is turned down before connecting your headphones. After placing headphones in/on your ears, gradually turn up the volume until you reach a comfortable listening level.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Lynco Products® is under license.

Siri® is a trademark of Apple Inc.

WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov



www.PowerUpChargeOn.com

Lynco Products
1410 11th St. West, Milan, IL 61264
800-758-9244