


nubia

TWS T1

Bluetooth Earbuds

Package content



Charging box

1 pair of earbuds



Type-C charging cable




User guide

▲This product is made of professional health materials and has passed the strict skin allergy test. No harms to your body.
▲Due to individual differences, if you feel skin discomfort during wearing, please remove it and consult your doctor.


01

Product appearance



02

Earbud wearing



Operation mode

Power on (slow flashing white light)
Take out the earbud from the charging box and turn it on automatically, and the voice prompt "Power on" will appear.


Power off
Put the earbud back into the charging box, and it will automatically turn off and enter the charging state.

03

Pairing the earbud with the mobile device

1. For the first time of use, please keep the distance between TWS earbud and mobile phones (or other connected devices) within 1 m as closer as possible.
2. After taking out the earbud and entering the pairing mode, mobile phones open the Bluetooth list of the device, search for "Nubia TWS T1", click finish connection, and the phone connection success prompt tone is "pairing success".

*If the connection fails, put the earbud back into the charging box and take it out again. Repeat the above operation.
*If the distance between the two earbud s is beyond the range of the mobile phone at the same time, the earbud will enter the Bluetooth state. If it does not return to the mobile phone within 3 min, the two earbuds will automatically turn off.



04

Factory resetting (clear pairing records)

When the earbud is in the charging box, click the charging box twice quickly and press for 3 s for the second time to clear the pairing record between the earbud and the mobile phone.




05

Bi-ear touch mode

● Play / pause music
When connected, touch the L/R earbud once
● Play the next song
Touch the L/R earbud twice in music mode
● Play the last song
In the music playing state, touch the L/R earbud 3 times
● Answer / end a call
Touch the L/R earbud once when calling / calling
● Refuse to answer a call
When calling, press and hold the L/R earbud for 2 seconds

Game mode

When the mobile phone is connected, press and hold the touch panel of L/R earbud for 2s to enter the low delay mode. Operate again to switch back to the music mode.




06

Charging box instructions

Charging status of earbud and charging box:

1. Charging the earbud: put the earbud into the charging box, and the earbud will automatically turn off and start charging.
2. The charging box is connected to the TYPE-C to start charging. The white light flashes and goes out after being fully charged for 5 min.
3. Check the battery capacity: Take the earbud out of the charging box and put it back to check the battery capacity.




07

Charging box instructions

Charging status of earbud and charging box:

1. Charging the earbud: put the earbud into the charging box, and the earbud will automatically turn off and start charging.
2. The charging box is connected to the TYPE-C to start charging. The white light flashes and goes out after being fully charged for 5 min.
3. Check the battery capacity: Take the earbud out of the charging box and put it back to check the battery capacity.



08

Specifications and parameters

Product model:	BH4006	Available unit:	13.0mm	Bluetooth version:	5.1
Rated power:	5mW	Speaker sensitivity:	105±3dB@1kHz	Bluetooth effective distance:	10 m
Battery power:	Rechargeable lithium-ion battery	Frequency response range:	20Hz~20 kHz	Charging time:	earbud: 1.5h Charging box: 2h
Battery capacity:	earbud: 35mAh/3.7V Charging box: 400mAh/3.7V	Loudspeaker rated impedance:	32 Ω	Waterproof level:	IPX4
Charging:	5V ± 1A	Charging voltage:	5V ± 0.2A	Play time:	About 3h

PRECAUTIONS FOR USE

1. Do not use abrasive cleaners to clean this product.
2. Do not allow this product to be heated or close to fire sources such as cooking stoves.
3. Do not expose this product to direct sunlight for a long time.
4. Do not dispose of this product in the fire to avoid explosion.
5. Do not try to disassemble this product to make any modifications, because it does not contain any maintenance components.
6. If you do not plan to use this product for a long period of time, please store it in a dry environment and charge the earbuds at least once a month to extend its life and avoid extreme temperatures and dust.
7. Please use the safety-certified wiring harness provided or authorized to charge.
8. When using this product, please adjust the volume appropriately so as not to damage your hearing.
9. Please use this product correctly to avoid falling from high altitude or severe squeezing.
10. Children should be accompanied by adults to avoid accidental ingestion.
11. Keep away from extreme environments such as high temperature or humidity.

09

Disposal of your old earbud

● When the wheeled bin symbol is attached to a product, it means the product is covered by the European Directive 2012/19/EU.
● All electrical and electronic products should be disposed of separately from normal household waste via designated collection points provided by government or local authorities.
● The correct disposal of electrical and electronic products will help protect the environment and human health.

Declaration of RoHS 2.0 Compliance

Declaration of RoHS 2.0 Compliance
We're determined to reduce the impact we have on the environment and take responsibility for the earth we live on. So this document allows us to formally declare that the BH4006, manufactured by Nubia Technology Co., Ltd, fully complies with the European Parliament's RoHS (Restriction of Hazardous Substances) 2.0 Directive 2012/19/EU, with respect to all the following substances:
(1) Lead (Pb)
(2) Mercury (Hg)
(3) Cadmium (Cd)
(4) Hexavalent Chromium (Cr (VI))
(5) Polybrominated biphenyl (PBB)
(6) Polybrominated diphenyl ether (PBDE)
(7) Di(2-ethylhexyl) phthalate (DEHP)
(8) Dibutyl phthalate (DBP)
(9) Benzyl butyl phthalate (BBP)
(10) Diisobutyl phthalate (DIBP)
Our compliance is witnessed by written declaration from our suppliers. This confirms that any potential trace contamination levels of the substances listed above are below the maximum level set by EU 2011/65/EU, or are exempt due to their application.
The BH4006 manufactured by Nubia Technology Co., Ltd meets all the requirements of EU 2011/65/EU.

Safety warning

● Adapter shall be installed near the equipment and shall be easily accessible.
● The RedMagic TWS Bluetooth earbuds' normal operating temperature is 0°C - 45°C. In order to ensure the normal Bluetooth earbuds functions, do not use this Bluetooth earbuds outside the temperature range.
WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

10

Health and safety

The device meets international guidelines for exposure to radio waves. Your device is a radio transmitter and receiver. It's designed not to exceed the limits for exposure to radio waves recommended by international guidelines. RF exposure information: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Radiation exposure statement power is so low that no RF exposure calculation is needed. The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. Important safety information: For your own health and safety, please follow the radio frequency (RF) radiation exposure guidelines and keep your wearable phone no less than 5 mm away from your body. Failure to do this could mean that your RF exposure exceeds the guideline limits. How to limit your radio frequency (RF) exposure: The World Health Organization (WHO) gives the following advice to people who want to limit their exposure to RF radiation. Present scientific information does not indicate the need for any special precautions for the use of Bluetooth earbuds. If individuals are concerned, they may choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep Bluetooth earbuds away from the head and body. Further information on the subject can be obtained from the World Health Organization website at http://www.who.int/peh-emf/WHO_Fact_sheet_193: June 2000.

FAQ

1. Question: Why is there only one earbud with sound?
Answer: Put the two earbuds back into the charging box, and then take it out again to see if the earbuds resume the operation mode of both earbuds. If not, reset the earbuds to solve the problem.
2. Question: What to do if the phone prompts that the connection cannot be established?
Answer: Delete the pairing record between the phone and the earbuds, and then search again and perform pairing connection again after deleting.
3. Question: Why is there no sound when listening to songs/making calls?
Answer: If it is an Android device, click the setting icon on the right to enter the Bluetooth connection record, uncheck the two audio options and select again; if it is an iOS device, enter the audio call mode in the general auxiliary function setting, and reselect the automatic option. If not restored, delete the pairing record and try again.
4. Question: Why is there a delay in video/game?
Answer: Affected by the environment, network, and mobile phone codec speed, it will cause different degrees of delay when the mobile phone transmits audio data to the earbuds; (Turning on the game mode will increase the power consumption and decrease the use distance. It is recommended to use the normal Bluetooth mode in non-gaming state. When the real-time voice function is enabled in the game, the background sound clarity of the game will be affected because the current game software sets the Bluetooth transmission rate as the highest priority).
5. Question: Why does it get stuck/intermittent?
Answer: When using the earbuds, if there are a lot of Wi-Fi connections, 4G signals, high-power electrical appliances, etc., interference will occur, and the earbuds may be stuck or intermittent; it is recommended to change the environment and try to pair the connection again.

Specifications and parameters

Product model:	BH4006	Available unit:	13.0mm	Bluetooth version:	5.1
Rated power:	5mW	Speaker sensitivity:	105±3dB@1kHz	Bluetooth effective distance:	10 m
Battery power:	Rechargeable lithium-ion battery	Frequency response range:	20Hz~20 kHz	Charging time:	earbud: 1.5h Charging box: 2h
Battery capacity:	earbud: 35mAh/3.7V Charging box: 400mAh/3.7V	Loudspeaker rated impedance:	32 Ω	Waterproof level:	IPX4
Charging:	5V ± 1A	Charging voltage:	5V ± 0.2A	Play time:	About 3h

PRECAUTIONS FOR USE

1. Do not use abrasive cleaners to clean this product.
2. Do not allow this product to be heated or close to fire sources such as cooking stoves.
3. Do not expose this product to direct sunlight for a long time.
4. Do not dispose of this product in the fire to avoid explosion.
5. Do not try to disassemble this product to make any modifications, because it does not contain any maintenance components.
6. If you do not plan to use this product for a long period of time, please store it in a dry environment and charge the earbuds at least once a month to extend its life and avoid extreme temperatures and dust.
7. Please use the safety-certified wiring harness provided or authorized to charge.
8. When using this product, please adjust the volume appropriately so as not to damage your hearing.
9. Please use this product correctly to avoid falling from high altitude or severe squeezing.
10. Children should be accompanied by adults to avoid accidental ingestion.
11. Keep away from extreme environments such as high temperature or humidity.

Safety warning

● Adapter shall be installed near the equipment and shall be easily accessible.
● The RedMagic TWS Bluetooth earbuds' normal operating temperature is 0°C - 45°C. In order to ensure the normal Bluetooth earbuds functions, do not use this Bluetooth earbuds outside the temperature range.
WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

11

Health and safety

The device meets international guidelines for exposure to radio waves. Your device is a radio transmitter and receiver. It's designed not to exceed the limits for exposure to radio waves recommended by international guidelines. RF exposure information: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Radiation exposure statement power is so low that no RF exposure calculation is needed. The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. Important safety information: For your own health and safety, please follow the radio frequency (RF) radiation exposure guidelines and keep your wearable phone no less than 5 mm away from your body. Failure to do this could mean that your RF exposure exceeds the guideline limits. How to limit your radio frequency (RF) exposure: The World Health Organization (WHO) gives the following advice to people who want to limit their exposure to RF radiation. Present scientific information does not indicate the need for any special precautions for the use of Bluetooth earbuds. If individuals are concerned, they may choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep Bluetooth earbuds away from the head and body. Further information on the subject can be obtained from the World Health Organization website at http://www.who.int/peh-emf/WHO_Fact_sheet_193: June 2000.

FAQ

1. Question: Why is there only one earbud with sound?
Answer: Put the two earbuds back into the charging box, and then take it out again to see if the earbuds resume the operation mode of both earbuds. If not, reset the earbuds to solve the problem.
2. Question: What to do if the phone prompts that the connection cannot be established?
Answer: Delete the pairing record between the phone and the earbuds, and then search again and perform pairing connection again after deleting.
3. Question: Why is there no sound when listening to songs/making calls?
Answer: If it is an Android device, click the setting icon on the right to enter the Bluetooth connection record, uncheck the two audio options and select again; if it is an iOS device, enter the audio call mode in the general auxiliary function setting, and reselect the automatic option. If not restored, delete the pairing record and try again.
4. Question: Why is there a delay in video/game?
Answer: Affected by the environment, network, and mobile phone codec speed, it will cause different degrees of delay when the mobile phone transmits audio data to the earbuds; (Turning on the game mode will increase the power consumption and decrease the use distance. It is recommended to use the normal Bluetooth mode in non-gaming state. When the real-time voice function is enabled in the game, the background sound clarity of the game will be affected because the current game software sets the Bluetooth transmission rate as the highest priority).
5. Question: Why does it get stuck/intermittent?
Answer: When using the earbuds, if there are a lot of Wi-Fi connections, 4G signals, high-power electrical appliances, etc., interference will occur, and the earbuds may be stuck or intermittent; it is recommended to change the environment and try to pair the connection again.

Specifications and parameters

Product model:	BH4006	Available unit:	13.0mm	Bluetooth version:	5.1
Rated power:	5mW	Speaker sensitivity:	105±3dB@1kHz	Bluetooth effective distance:	10 m
Battery power:	Rechargeable lithium-ion battery	Frequency response range:	20Hz~20 kHz	Charging time:	earbud: 1.5h Charging box: 2h
Battery capacity:	earbud: 35mAh/3.7V Charging box: 400mAh/3.7V	Loudspeaker rated impedance:	32 Ω	Waterproof level:	IPX4
Charging:	5V ± 1A	Charging voltage:	5V ± 0.2A	Play time:	About 3h

PRECAUTIONS FOR USE

1. Do not use abrasive cleaners to clean this product.
2. Do not allow this product to be heated or close to fire sources such as cooking stoves.
3. Do not expose this product to direct sunlight for a long time.
4. Do not dispose of this product in the fire to avoid explosion.
5. Do not try to disassemble this product to make any modifications, because it does not contain any maintenance components.
6. If you do not plan to use this product for a long period of time, please store it in a dry environment and charge the earbuds at least once a month to extend its life and avoid extreme temperatures and dust.
7. Please use the safety-certified wiring harness provided or authorized to charge.
8. When using this product, please adjust the volume appropriately so as not to damage your hearing.
9. Please use this product correctly to avoid falling from high altitude or severe squeezing.
10. Children should be accompanied by adults to avoid accidental ingestion.
11. Keep away from extreme environments such as high temperature or humidity.

Safety warning

● Adapter shall be installed near the equipment and shall be easily accessible.
● The RedMagic TWS Bluetooth earbuds' normal operating temperature is 0°C - 45°C. In order to ensure the normal Bluetooth earbuds functions, do not use this Bluetooth earbuds outside the temperature range.
WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

12

Health and safety

The device meets international guidelines for exposure to radio waves. Your device is a radio transmitter and receiver. It's designed not to exceed the limits for exposure to radio waves recommended by international guidelines. RF exposure information: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Radiation exposure statement power is so low that no RF exposure calculation is needed. The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. Important safety information: For your own health and safety, please follow the radio frequency (RF) radiation exposure guidelines and keep your wearable phone no less than 5 mm away from your body. Failure to do this could mean that your RF exposure exceeds the guideline limits. How to limit your radio frequency (RF) exposure: The World Health Organization (WHO) gives the following advice to people who want to limit their exposure to RF radiation. Present scientific information does not indicate the need for any special precautions for the use of Bluetooth earbuds. If individuals are concerned, they may choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep Bluetooth earbuds away from the head and body. Further information on the subject can be obtained from the World Health Organization website at http://www.who.int/peh-emf/WHO_Fact_sheet_193: June 2000.

FAQ

1. Question: Why is there only one earbud with sound?
Answer: Put the two earbuds back into the charging box, and then take it out again to see if the earbuds resume the operation mode of both earbuds. If not, reset the earbuds to solve the problem.
2. Question: What to do if the phone prompts that the connection cannot be established?
Answer: Delete the pairing record between the phone and the earbuds, and then search again and perform pairing connection again after deleting.
3. Question: Why is there no sound when listening to songs/making calls?
Answer: If it is an Android device, click the setting icon on the right to enter the Bluetooth connection record, uncheck the two audio options and select again; if it is an iOS device, enter the audio call mode in the general auxiliary function setting, and reselect the automatic option. If not restored, delete the pairing record and try again.
4. Question: Why is there a delay in video/game?
Answer: Affected by the environment, network, and mobile phone codec speed, it will cause different degrees of delay when the mobile phone transmits audio data to the earbuds; (Turning on the game mode will increase the power consumption and decrease the use distance. It is recommended to use the normal Bluetooth mode in non-gaming state. When the real-time voice function is enabled in the game, the background sound clarity of the game will be affected because the current game software sets the Bluetooth transmission rate as the highest priority).
5. Question: Why does it get stuck/intermittent?
Answer: When using the earbuds, if there are a lot of Wi-Fi connections, 4G signals, high-power electrical appliances, etc., interference will occur, and the earbuds may be stuck or intermittent; it is recommended to change the environment and try to pair the connection again.

Specifications and parameters

Product model:	BH4006	Available unit:	13.0mm	Bluetooth version:	5.1
Rated power:	5mW	Speaker sensitivity:	105±3dB@1kHz	Bluetooth effective distance:	10 m
Battery power:	Rechargeable lithium-ion battery	Frequency response range:	20Hz~20 kHz	Charging time:	earbud: 1.5h Charging box: 2h
Battery capacity:	earbud: 35mAh/3.7V Charging box: 400mAh/3.7V	Loudspeaker rated impedance:	32 Ω	Waterproof level:	IPX4
Charging:	5V ± 1A	Charging voltage:	5V ± 0.2A	Play time:	About 3h

PRECAUTIONS FOR USE

1. Do not use abrasive cleaners to clean this product.
2. Do not allow this product to be heated or close to fire sources such as cooking stoves.
3. Do not expose this product to direct sunlight for a long time.
4. Do not dispose of this product in the fire to avoid explosion.
5. Do not try to disassemble this product to make any modifications, because it does not contain any maintenance components.
6. If you do not plan to use this product for a long period of time, please store it in a dry environment and charge the earbuds at least once a month to extend its life and avoid extreme temperatures and dust.
7. Please use the safety-certified wiring harness provided or authorized to charge.
8. When using this product, please adjust the volume appropriately so as not to damage your hearing.
9. Please use this product correctly to avoid falling from high altitude or severe squeezing.
10. Children should be accompanied by adults to avoid accidental ingestion.
11. Keep away from extreme environments such as high temperature or humidity.

Safety warning

● Adapter shall be installed near the equipment and shall be easily accessible.
● The RedMagic TWS Bluetooth earbuds' normal operating temperature is 0°C - 45°C. In order to ensure the normal Bluetooth earbuds functions, do not use this Bluetooth earbuds outside the temperature range.
WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

13

Health and safety

The device meets international guidelines for exposure to radio waves. Your device is a radio transmitter and receiver. It's designed not to exceed the limits for exposure to radio waves recommended by international guidelines. RF exposure information: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Radiation exposure statement power is so low that no RF exposure calculation is needed. The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. Important safety information: For your own health and safety, please follow the radio frequency (RF) radiation exposure guidelines and keep your wearable phone no less than 5 mm away from your body. Failure to do this could mean that your RF exposure exceeds the guideline limits. How to limit your radio frequency (RF) exposure: The World Health Organization (WHO) gives the following advice to people who want to limit their exposure to RF radiation. Present scientific information does not indicate the need for any special precautions for the use of Bluetooth earbuds. If individuals are concerned, they may choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep Bluetooth earbuds away from the head and body. Further information on the subject can be obtained from the World Health Organization website at http://www.who.int/peh-emf/WHO_Fact_sheet_193: June 2000.

FAQ

1. Question: Why is there only one earbud with sound?
Answer: Put the two earbuds back into the charging box, and then take it out again to see if the earbuds resume the operation mode of both earbuds. If not, reset the earbuds to solve the problem.
2. Question: What to do if the phone prompts that the connection cannot be established?
Answer: Delete the pairing record between the phone and the earbuds, and then search again and perform pairing connection again after deleting.
3. Question: Why is there no sound when listening to songs/making calls?
Answer: If it is an Android device, click the setting icon on the right to enter the Bluetooth connection record, uncheck the two audio options and select again; if it is an iOS device, enter the audio call mode in the general auxiliary function setting, and reselect the automatic option. If not restored, delete the pairing record and try again.
4. Question: Why is there a delay in video/game?
Answer: Affected by the environment, network, and mobile phone codec speed, it will cause different degrees of delay when the mobile phone transmits audio data to the earbuds; (Turning on the game mode will increase the power consumption and decrease the use distance. It is recommended to use the normal Bluetooth mode in non-gaming state. When the real-time voice function is enabled in the game, the background sound clarity of the game will be affected because the current game software sets the Bluetooth transmission rate as the highest priority).
5. Question: Why does it get stuck/intermittent?
Answer: When using the earbuds, if there are a lot of Wi-Fi connections, 4G signals, high-power electrical appliances, etc., interference will occur, and the earbuds may be stuck or intermittent; it is recommended to change the environment and try to pair the connection again.

Specifications and parameters

Product model:	BH4006	Available unit:	13.0mm	Bluetooth version:	5.1
Rated power:	5mW	Speaker sensitivity:	105±3dB@1kHz	Bluetooth effective distance:	10 m
Battery power:	Rechargeable lithium-ion battery	Frequency response range:	20Hz~20 kHz	Charging time:	earbud: 1.5h Charging box: 2h
Battery capacity:	earbud: 35mAh/3.7V Charging box: 400mAh/3.7V	Loudspeaker rated impedance:	32 Ω	Waterproof level:	IPX4
Charging:	5V ± 1A	Charging voltage:	5V ± 0.2A	Play time:	About 3h

PRECAUTIONS FOR USE

1. Do not use abrasive cleaners to clean this product.
2. Do not allow this product to be heated or close to fire sources such as cooking stoves.
3. Do not expose this product to direct sunlight for a long time.
4. Do not dispose of this product in the fire to avoid explosion.
5. Do not try to disassemble this product to make any modifications, because it does not contain any maintenance components.
6. If you do not plan to use this product for a long period of time, please store it in a dry environment and charge the earbuds at least once a month to extend its life and avoid extreme temperatures and dust.
7. Please use the safety-certified wiring harness provided or authorized to charge.
8. When using this product, please adjust the volume appropriately so as not to damage your hearing.
9. Please use this product correctly to avoid falling from high altitude or severe squeezing.
10. Children should be accompanied by adults to avoid accidental ingestion.
11. Keep away from extreme environments such as high temperature or humidity.

Safety warning

● Adapter shall be installed near the equipment and shall be easily accessible.
● The RedMagic TWS Bluetooth earbuds' normal operating temperature is 0°C - 45°C. In order to ensure the normal Bluetooth earbuds functions, do not use this Bluetooth earbuds outside the temperature range.
WARNING: Cancer and Reproductive Harm - www.P65Warnings.ca.gov.

14

Health and safety

The device meets international guidelines for exposure to radio waves. Your device is a radio transmitter and receiver. It's designed not to exceed the limits for exposure to radio waves recommended by international guidelines. RF exposure information: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. Radiation exposure statement power is so low that no RF exposure calculation is needed. The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. Important safety information: For your own health and safety, please follow the radio frequency (RF) radiation exposure guidelines and keep your wearable phone no less than 5 mm away from your body. Failure to do this could mean that your RF exposure exceeds the guideline limits. How to limit your radio frequency (RF) exposure: The World Health Organization (WHO) gives the following advice to people who want to limit their exposure to RF radiation. Present scientific information does not indicate the need for any special precautions for the use of Bluetooth earbuds. If individuals are concerned, they may choose to limit their own or their children's RF exposure by limiting the length of calls, or using "hands-free" devices to keep Bluetooth earbuds away from the head and body. Further information on the subject can be obtained from the World Health Organization website at http://www.who.int/peh-emf/WHO_Fact_sheet_193: June 2000.

FAQ

1. Question: Why is there only one earbud with sound?
Answer: Put the two earbuds back into the charging box, and then take it out again to see if the earbuds resume the operation mode of both earbuds. If not, reset the earbuds to solve the problem.
2. Question: What to do if the phone prompts that the connection cannot be established?
Answer: Delete the pairing record between the phone and the earbuds, and then search again and perform pairing connection again after deleting.
3. Question: Why is there no sound when listening to songs/making calls?
Answer: If it is an Android device, click the setting icon on the right to enter the Bluetooth connection record, uncheck the two audio options and select again; if it is an iOS device, enter the audio call mode in the general auxiliary function setting, and reselect the automatic option. If not restored, delete the pairing record and try again.
4. Question: Why is there a delay in video/game?
Answer: Affected by the environment, network, and mobile phone codec speed, it will cause different degrees of delay when the mobile phone transmits audio data to the earbuds; (Turning on the game mode will increase the power consumption and decrease the use distance. It is recommended to use the normal Bluetooth mode in non-gaming state. When the real-time voice function is enabled in the game, the background sound clarity of the game will be affected because the current game software sets the Bluetooth transmission rate as the highest priority).
5. Question: Why does it get stuck/intermittent?
Answer: When using the earbuds, if there are a lot of Wi-Fi connections, 4G signals, high-power electrical appliances, etc., interference will occur, and the earbuds may be stuck or intermittent; it is recommended to change the environment and try to pair the connection again.

Specifications and parameters

Product model:	BH4006	Available unit:	13.0mm	Bluetooth version:	5.1
Rated power:	5mW	Speaker sensitivity:	105±3dB@1kHz	Bluetooth effective distance:	10 m
Battery power:	Rechargeable lithium-ion battery	Frequency response range:	20Hz~20 kHz	Charging time:	earbud: 1.5h Charging box: 2h
Battery capacity:	earbud: 35mAh/3.7V Charging box: 400mAh/3.7V	Loudspeaker rated impedance:	32 Ω	Waterproof level:	IPX4
Charging:	5V ± 1A	Charging voltage:	5V ± 0.2A	Play time:	About 3h

PRECAUTIONS FOR USE

1. Do not use abrasive cleaners to clean this product.
2. Do not allow this product to be heated or close to fire sources such as cooking stoves.
3. Do not expose this product to direct sunlight for a long time.
4. Do not dispose of this product in the fire to avoid explosion.
5.